






FWM57



PHILIPS

Use this simple and quick guide to get started listening to your favorite music.




**For more detailed instructions see the following pages in the owner's manual.**

Gameport Operations .....	15
Basic Functions .....	16~17
Disc Operations .....	18~20
Tuner Operations .....	21
Timer Operations .....	22~23
Troubleshooting .....	25

## A Plug and Play (for tuner installation)

- 1 When you turn on the mains supply, "AUTO INSTALL - PRESS PLAY" is displayed.
- 2 Press ►|| on the system to start installation.
  - "INSTALL" is displayed, followed by "TUNER" and "AUTO".
  - **PROG** starts flashing.
  - When all the available radio stations are stored or the memory for 40 presets are used, the last preset radio station (or the first available RDS station) will be played.




## B Timer Operations

- 1 Press and hold **CLOCK•TIMER** until "SELECT CLOCK OR TIMER" is displayed.
- 2 Press ►| to change the display to "TIMER" and press **CLOCK•TIMER** again to confirm.
- 3 Press **CD** or **TUNER** to select the wake-up source.
- 4 Press ◀◀ or ▶▶ (for hours) and ◀ or ▶ (for minutes) repeatedly to set the wake-up time.
- 5 Press **CLOCK•TIMER** to store the setting.

**To exit without storing the setting**

- Press ■ on the system.



## C Disc operations

- 1 Press **DISC1**, **DISC2**, **DISC3**, **DISC4** or **DISC5** to open the corresponding disc tray.
- 2 Load a disc in each disc tray.
- 3 Press the disc button to close the disc tray.
- 4 Press ►|| to play the CD.

