



Philips
CD Soundmachine

Compact design

MP3-CD
Black

AZ300

Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The compact and portable Philips CD soundmachine lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

Enjoy your music from different sources

- Play MP3-CD, CD and CD-R/RW
- FM/MW (AM) stereo tuner

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- MP3 Link for portable music playback

PHILIPS

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: fast forward/backward, next/previous album search, next/previous track search, repeat/shuffle/program

Tuner/Reception/Transmission

- Tuner bands: FM, MW (AM)
- Antenna: FM antenna

Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2

Connectivity

- MP3 Link: 3.5mm stereo line in

Power

- Battery type: C size (LR14)

- Battery voltage: 1.5 V
- Number of batteries: 6
- Power supply: 110 - 127V and 220 - 240V AC voltage selectable

Accessories

- Cables/Connection: *Flat pin adaptor, power cord
- User Manual: English, Portuguese, Spanish
- Warranty: Warranty Certificate

Convenience

- Loader type: top

Dimensions

- Main unit width: 212 mm
- Main unit depth: 245 mm
- Main unit height: 130 mm
- Packaging width: 280 mm
- Packaging depth: 156 mm
- Packaging height: 246 mm
- Gross weight: 1.8 kg
- Weight: 1.5 kg




Highlights

Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3")". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2016-10-05

Version: 1.0.3

12 NC: 8670 000 83476
EAN: 87 12581 62439 2

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.
* Adaptor supplied is needed for all Latin American countries, except in Brazil.