



Philips  
CD Soundmachine with  
Dynamic Bass Boost

CD  
cassette

AZ127

## Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ127 lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

### **The ultimate listening experience**

- Play CD, CD-R and CD-RW discs
- Autostop cassette deck
- FM tuner for radio enjoyment

### **Easy to use**

- 20-track CD programmable
- CD Shuffle/Repeat for personalized music enjoyment
- Audio-in for easy portable music playback


### **Rich and clear sound**

- Dynamic Bass Boost for deep and dramatic sound

# PHILIPS

# Highlights

## Autostop cassette deck



Autostop cassette deck

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



## CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

## AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.

# Specifications

## Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20
- Number of decks: 1
- Cassette Deck Technology: Mechanical

## Tuner/Reception/Transmission

- Tuner Bands: FM
- Antenna: FM Antenna

## Sound

- Output power (RMS): 2 X 1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

## Loudspeakers

- Built-in speakers: 2

## Convenience

- Display Type: LCD

## Connectivity

- 3.5mm stereo line in: (AUDIO IN)

## Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Number of batteries: 6
- Mains power: 220V - 240V

## Accessories

- Quick start guide
- Warranty: Warranty leaflet

## Dimensions

- Packaging dimensions (W x H x D): 326 x 275 x 158 mm
- Product dimensions (W x H x D): 300 x 240 x 133 mm
- Weight: 2 kg
- Weight incl. Packaging: 2.4 kg



Issue date 2021-02-03

Version: 1.1.1

12 NC: 8670 001 62859  
EAN: 48 95229 10226 2

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)