




Specifications are subject to change without notice
© 2014 Koninklijke Philips Electronics N.V.
All rights reserved.

SDVI126X/55



Overview

EN


- ① VHF antenna
- ② UHF antenna
- ③ Coaxial cable(for TV receiver connection)

PT

- ① Antena VHF
- ② Antena UHF
- ③ Cabo coaxial (para conectar a TV)

ES

- ① Antena VHF
- ② Antena UHF
- ③ Cable coaxial (para conectar el televisor)



Always there to help you

SDVI126X/55

Enjoy your product and get support at
www.philips.com/support

Question?
Contact
Philips



EN User manual

ES Manual del usuario

PT Manual do Usuário

PHILIPS

EN

- 1 Connect one end of your coaxial cable to the signal output of the antenna.
- 2 Connect the other end to the input on the TV receiver.(Fig.1)

ES

- 1 Conecte uno de los extremos del cable coaxial a la salida de señal de la antena.
- 2 Conecte el otro extremo a la entrada del receptor de televisión.(Fig.1)

PT

- 1 Ligue uma das pontas do cabo coaxial à saída de sinal da antena.
- 2 Ligue a outra ponta à entrada no receptor do TV.(Fig.1)