

Philips
CD Soundmachine with
Dynamic Bass Boost

• MP3

AZ3830



CD Ripping and USB Direct playback

with convenient motorised CD tray

Simply slide your CD into the motorised CD tray and let the stylishly compact AZ3830 rip and store your music on your USB device or MP3 player. Enjoy powerful sound thanks to 2 x 4 W RMS power.

Build your own digital music collections

- Rip your favourite CDs to MP3
- Enjoy MP3/WMA music directly from your portable USB devices
- 10 hours of MP3-CD or 20 hours of WMA-CD music

Powerful sound you can hear and feel

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound
- Total power 2 x 4 W RMS

Easy to use

- One-touch MP3 digital recording - no computer needed
- Motorised CD loader for convenient access
- FM/MW digital tuner with 25 presets

PHILIPS

Specifications

Audio Playback

- Loader Type: Motorised, Tray
- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Reverse, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

Sound

- Output power (RMS): 2 x 4 W
- Sound System: Stereo
- Loudspeaker types: Bass Reflex Speaker System
- Sound Enhancement: Dynamic Bass Boost
- Speaker diameter: 3"
- Volume Control: rotary

Tuner/reception/transmission

- Tuner Bands: FM, MW
- Auto digital tuning
- Antenna: FM Antenna

Connectivity

- USB: USB host
- Aux in
- Headphones: 3.5 mm

Convenience

- Display Type: LCD
- Backlight
- Remote Control: Multi-functional

Power

- Mains power
- Battery type: LR20
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

- Included Accessories: AC Power Lead, User manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 410 x 187 x 307 mm
- Product dimensions (W x H x D): 358.4 x 140.6 x 260 mm
- Weight: 2.22 kg
- Weight incl. Packaging: 3.15 kg

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

One-touch MP3 recording

Simply plug in your USB mass storage device to the USB port on the Philips audio system and start recording your favourite music from CDs to your USB device or MP3 player - with one-touch operation and no computer needed.

Motorised CD loader

Motorised CD loader for convenient access



Issue date 2013-05-10

Version: 1.0.3

12 NC: 8670 000 25172
EAN: 87 12581 30131 6

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com