

Philips CD Soundmachine

USB

AZ1834

Playback your digital music via USB Direct

The sleek and portable design of AZ1834 allows you to enjoy your favorite MP3 / WMA music collections stored at portable music player without using headphone.

Enjoy your music from multiple sources

- USB Direct for MP3/ WMA music playback
- Play MP3/WMA-CD, CD and CD-RW

Easy to use

- FM/MW tuner for radio enjoyment
- CD shuffle/program/repeat for personalized music enjoyment
- Line-in connection for your portable music playback

Rich and clear sound

· Full range speakers for immersive and dynamic sound



Highlights

USB Direct



With the USB Direct mode, you can simply select the music on a USB device and playback all your content. All you have to do is plug in your USB device to playback music or export content from the

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

Full range speakers



The compact stereo speakers provide full range quality sound and allow you to listen freely. Enjoy

music anytime, anywhere, with built-in stereo speakers that allow the convenience and enjoyment of music playback.

FM/MW tuner



FM/MW (AM) stereo tuner

CD shuffle/program/repeat



The "Shuffle/Program/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle", "Program" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Line-in connection

MP3 line-in connectivity allows direct playback of MP3 content via your audio system. By simply connecting your portable MP3 player to the audio system via its built-in line-in jack, you can enjoy superb sound quality while playing your favorite music from your portable MP3 player.

Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

Connectivity

- USB: USB host
- 3.5mm stereo line in

Sound

- Sound System: Stereo
- Volume Control: rotary
- Output power (RMS): 2 x 1W
- Speaker diameter: 3"

Loudspeakers

- Finishing: Metal
- · Loudspeaker types: Loudspeakers
- Built-in speakers: 2

Convenience

• Display Type: LCD

Accessories

 Included accessories: 3.5mm stereo line in cable, AC Power Cord, User Manual, Warranty certificate

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Dimensions

- Packaging dimensions (W \times H \times D): 379 \times 246 \times 146 mm
- Product dimensions (W x H x D): 350 x 127 x 217 mm
- Weight: 2.2 kg
- Weight incl. Packaging: 2.7 kg











Issue date 2021-08-16

Version: 1.0.4

12 NC: 8670 000 53176 EAN: 87 12581 48487 3 © 2021 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com