MCM302


# Quick Start Guide






### What's in the Box?

You should find these items upon opening the box.












#### Set clock

In the standby mode, press and hold **CLOCK** to activate the clock setting mode.

→ The hour digits are displayed and begin to blink.

Press **CLOCK** to confirm the clock setting.

```
Press + VOL - to set the hour.
The minute digits are displayed and begin to blink.
Press + VOL - to set the minute.
```





#### Play from disc

Press CD to select the CD source.

Press OPEN/CLOSE.

→ The disc tray opens.

Place a disc onto the tray and press OPEN/CLOSE.

→ Ensure that the label is facing upwards.




3

Playback will start automatically.


 If play does not start, press I◄/▶I to select a track and then press ▶ II. đ

## Play from USB





#### Program and tune to radio stations



#### Тір

Detailed playback features and additional functions are described in the accompany owner's manual.



© Royal Philips Electronics N.V. 2009 All rights reserved.

http://www.philips.com

