








Register your product and get support at
www.philips.com/welcome

HTS3560




Quick Start

PHILIPS




Power cord




Power Cord




FM Antenna



Video Cable




HDMI Cable




1



①





2




3




4



5




6






AAA
x 2






1




2

3

4




HOME THEATER



5

6




HOME THEATER

Video Setup	Menu Language	English
Audio Setup	Audio	•
Network Setup	Subtitle	•
EasyLink Setup	Disc Menu	•
Preference Setup	Parental Control	•
Advanced Setup	Screen Saver	•
	Auto Subtitle Shift	•
	Change Password	•

7



8






HOME THEATER

Menu Language	Auto (ENG)
Audio	English
Subtitle	Русский
Disc Menu	Українська
Parental Control	
Screen Saver	
Auto Subtitle Shift	
Change Password	

DISC





FM







MP3



USB



www.philips.com/support



Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved.
sgsna_1027/51_v2



Be responsible
Respect copyrights

