

Philips Micro Hi-Fi System

MP3/WMA-CD playback USB Direct

MCM204

The new classic

with USB Direct playback

Specifically designed for those who truly appreciate the ultimate in style and technology, Philips MCM204 exudes finesse and quality. Enjoy MP3/WMA music from your portable player with USB Direct playback.

Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- Autostop cassette deck
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 8 W RMS total output power

Start the day your way

- Wake-up and sleep timer functions
- Digital tuning with 40 pre-set stations for extra convenience

Refined in sound and look

- Elegant wood-finished speakers
- Easy-to-use remote control included



MCM204/05

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.













Specifications

Sound

- Output Power: 2 x 4 W RMS/2 x 8 W music power • Sound Enhancement: Digital Sound Control 4
- modes, Dynamic Bass Boost

Loudspeakers

 Main Speaker: 3.5" woofer, Bass Reflex Speaker System

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable
- Loader Type: Top
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Electronic Speed
- Control • USB Direct Modes: Play/Pause, Stop, Previous/ Next, Fast Reverse/Fast Forward, Programme Play, Repeat, Shuffle

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro-Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM fixed pigtail antenna, MW
 - Antenna
- Aux in: Line-in, 3.5 mm
 Headphones: 3.5 mm

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM/MW Antenna, Guarantee booklet, Quick Use Guide
- Remote control: 24-key remote with Lithium
- battery
- Quick start guide: English
 User Manual: English
- Oser Manual: Engl

Dimensions

- Set dimensions (W x H x D): 146 x 228 x 216 mm
- Main speaker dimensions (W x H x D): 146 x 228 x 160 mm
- Packaging dimensions (W \times H \times D):
- 380 x 350 x 275 mm • Weight incl. Packaging: 5.3 kg

Power

• Power supply: 220-240 V, 50 Hz



Issue date 2017-04-04

© 2017 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Version: 3.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 31338 EAN: 87 12581 34449 8