

Philips  
CD Soundmachine

USB

AZ1834



## Enjoy music wherever you go

The sleek and portable design of AZ1834 allows you to enjoy your favorite MP3/WMA music collections stored at portable music player without using headphone.

### Enjoy your music from multiple sources

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW

### Rich and clear sound

- Full range speakers for immersive and dynamic sound

### Easy to use

- FM/MW tuner for radio enjoyment
- CD Shuffle/Repeat for personalized music enjoyment
- Line-in connection for your portable music playback

**PHILIPS**  
sense and simplicity

## Highlights

### USB Direct




With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

### Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.


### Full range speakers



The compact stereo speakers provide full range quality sound and allow you to listen freely. Enjoy

music anytime, anywhere, with built-in stereo speakers that allow the convenience and enjoyment of music playback.

### FM/MW tuner



FM/MW (AM) stereo tuner

### CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

### Line-in connection

MP3 line-in connectivity allows direct playback of MP3 content via your audio system. By simply connecting your portable MP3 player to the audio system via its built-in line-in jack, you can enjoy superb sound quality while playing your favorite music from your portable MP3 player.

## Specifications

### Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program

### Connectivity

- USB: USB host
- MP3 Link: 3.5mm stereo line in

### Tuner/Reception/Transmission

- Tuner bands: FM, MW
- Antenna: FM antenna

### Sound

- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

### Loudspeakers

- No. of built-in speakers: 2
- Speaker grille finishing: metal

### Convenience

- Loader type: top
- Display type: LCD display

### Accessories

- Cables/Connection: 3.5 mm stereo line in cable, power cord
- User Manual: English
- Others: User Manual
- Warranty: World Wide Guarantee booklet

### Power

- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: AC Input

### Dimensions

- Gross weight: 2.7 kg
- Packaging depth: 146 mm
- Packaging height: 246 mm
- Packaging width: 379 mm
- Weight: 2.2 kg
- Main unit depth: 217 mm
- Main unit height: 127 mm
- Main unit width: 350 mm



Issue date 2012-07-17

Version: 1.0.4

12 NC: 8670 000 53177  
EAN: 87 12581 48488 0

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)