





Register your product and get support at
www.philips.com/welcome

HTS3580



Quick Start





PHILIPS



Video Cable






FM Antenna



1


1



Stand
Screw
x 2



1



FRONT
LEFT

FRONT
CENTER


FRONT
RIGHT

SUBWOOFER



REAR
RIGHT




2




3




4




5





6






1




2

3

4




HOME THEATER



5

6




HOME THEATER

Video Setup	Menu Language	English
Audio Setup	Audio	•
Network Setup	Subtitle	•
EasyLink Setup	Disc Menu	•
Preference Setup	Parental Control	•
Advanced Setup	Screen Saver	•
	Auto Subtitle Shift	•
	Change Password	•

7



8






HOME THEATER

Menu Language	Auto (ENG)
Audio	English
Subtitle	Čeština
Disc Menu	Dansk
Parental Control	Deutsch
Screen Saver	Español
Auto Subtitle Shift	Français
Change Password	Italianoo

DISC





FM







MP3



USB



www.philips.com/support



Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved.
sgam_1023/12_v1



Be responsible
Respect copyrights

