

Question?
 Contact
 Philips



- | | |
|--------------------------------|-------------------------------------|
| EN Short User Manual | IT Manuale dell'utente breve |
| CS Krátká uživatelská příručka | NL Korte gebruikershandleiding |
| DA Kort brugervejledning | PL Krótka instrukcja obsługi |
| DE Kurzanleitung | PT Manual do utilizador resumido |
| EL Σύντομο εγχειρίδιο χρήσης | RU Краткое руководство пользователя |
| ES Manual de usuario corto | SK Stručný návod na používanie |
| FI Lyhyt käyttöopas | SV Kortfattad användarhandbok |
| FR Bref mode d'emploi | TR Kısa Kullanım Kılavuzu |
| HU Rövid használati útmutató | |

PHILIPS

!

Before using your product, read all accompanying safety information.

B

- 1
- 2
- 3
- 4

⏻

Switch to standby mode

🕒

1 SET TIME 2 sec.

2 **3**

Repeat steps 2-3 to set hour and minute.

🔔

1 AL 1/AL 2 2 sec.

2 **3**

Repeat steps 2-3 to set the minute, select an alarm source (buzzer, radio, or dock), and adjust volume.



📱

- 1
- 2
- 3

DOCK

SOURCE

Application Not Installed
 This accessory requires an application you do not have installed. Would you like to install it from the App store?
 No Yes

Registration
 Do you want to register your Philips product now?
 Yes No

Music library
 Sources
 Music library
 FM radio
 AUX
 Cancel

Clock & weather
 19°C
 Sleep timer
 15 mins
 30 mins
 60 mins
 Start

FM
 there is no info
 87.50

FM
 Add preset
 please select the record
 1
 2
 3
 Please enter the title
 Cancel Done

iPhone 5
 iPod touch 5th generation
 iPod nano 7th generation

All registered and unregistered trademarks are property of their respective owners.
 © 2013 Koninklijke Philips Electronics N.V.
 All rights reserved.

AJ7245D_12_Short User Manual_V1.0

🔊

VOL

📻

1 SOURCE

FM

2 A **2 B**

97.1 101.5
 101.5 101.6

2 sec.

☀️

SNOOZE BRIGHTNESS

400 → 400 → 400

ZZ

SLEEP

15 → 30 → 60 → 90 → 120
 OFF

🔄

AUX

1 SOURCE

2 AUDIO IN

🌐

User Manual

To download the full user manual, visit www.philips.com/support.

