




Philips
CD Soundmachine

CD, MP3-CD, USB, FM

Tape
2W



AZ328

Enjoy music wherever you go

You take pleasure in the simple things in life and delight in convenience. The compact and portable Philips CD soundmachine lets you indulge in the pleasures of enjoying your favorite music with the help of easy-to-use functions.

The ultimate listening experience

- USB Direct for MP3/WMA music playback
- Play MP3-CD, CD and CD-R/RW
- FM tuner for radio enjoyment
- Autostop cassette deck

Easy to use

- Audio-in for easy portable music playback
- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound

PHILIPS


Highlights

Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3")". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Autostop cassette deck



Autostop cassette deck

Dynamic Bass Boost




Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings -



from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, USB flash drive
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Number of decks: 1
- Cassette deck technology: mechanical
- USB Direct playback modes: fast backward/fast forward, previous/next, repeat, shuffle, program play, play/pause, stop

Tuner/Reception/Transmission

- Tuner bands: FM
- Antenna: FM antenna

Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers

- No. of built-in speakers: 2

Convenience

- Display type: LCD display
- Loader type: top

Connectivity

- Audio in (3.5mm)

Power

- Power supply: 220 - 240 V
- Battery type: C size (LR14)
- Number of batteries: 6
- Battery voltage: 1.5 V

Accessories

- Cables/Connection: power cord
- Others: Quick start guide
- Warranty: Warranty leaflet

Dimensions

- Packaging depth: 158 mm
- Packaging height: 275 mm
- Packaging width: 326 mm
- Gross weight: 2.4 kg
- Main unit depth: 240 mm
- Main unit height: 132 mm
- Main unit width: 299 mm
- Weight: 2 kg



Issue date 2022-04-29

Version: 1.0.5

12 NC: 8670 000 97888
EAN: 87 12581 66840 2

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com