

Philips CD Soundmachine

AZ1123

Music on the move

Compact and stylish, this all-in-one player plays all CDs including CD-R and CD-RW. Sit back and enjoy music convenience with its programmable 20 track replay.

Enjoy your music from different sources

- CD player
- Compatible with CD-Recordable and CD-ReWritable
- FM/MW stereo tuner

Easy to use

- CD shuffle/program/repeat
- Multi-functional LCD display
- Stereo headphone socket



AZ1123/78

Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Programmable Tracks: 20

Tuner/Reception/Transmission

- · Antenna: FM Antenna
- Tuner Bands: FM, MW

Sound

- Output power (RMS): 2x1W
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Convenience

- Display Type: LCD
- Display Digits: 2



Connectivity

• Headphone: 3.5 mm

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- · Mains power
- Number of batteries: 6

Accessories

 Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W \times H \times D): 397 \times 169 \times 246 mm
- Product dimensions (W \times H \times D): 350 \times 127 \times 217 mm
- Weight: 1.9 kg
- Weight incl. Packaging: 2.55 kg

Highlights

CD player CD player

- 1 .../ -

CD-R/RW Compatible
CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

FM/MW stereo tuner

FM/MW stereo tuner

CD shuffle/program/repeat

The "Shuffle/Program/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle", "Program" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Multi-functional LCD display

Multi-functional LCD display

Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.



Issue date 2015-01-22

© 2015 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Version: 3.1.10

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips N.V.

12 NC: 9073 101 02646 EAN: 87 10895 96625 2 or their respective owners.