

micro jukebox

hdd070

My wearable jukebox on the go

Enjoy up to 1000 songs and FM radio

Soundtrack your life with the hdd070 micro jukebox on the go. It's so small it can hide behind a credit card. With up to 1000 songs and FM radio to suit any mood, you'll never be bored. Wear it, or carry your music and data everyday.

Small and light makes it truly wearable

- Ultra lightweight and strong magnesium body
- Fashionable neck-strap - wear it everywhere!
- Dress up your player with colorful groovy stickers

Easy, intuitive music experience on the go

- Simple and easy-to-use interface menus
- SuperPlay™ provides hassle-free one-touch jukebox playback
- SuperScroll™ navigation finds songs in a simple, fast way

Your music, your data - on the go, everyday

- 2GB* capacity for music and data on the go
- Enjoy more music with built-in FM tuner
- USB mass storage to store and carry your data files
- 10 hours battery life**



GoGear™

PHILIPS

Technical specifications

Picture / Display

- Backlight color: White
- Indications: Battery status, DBB
- Lines of text: 5
- Resolution: 128 x 96 pixels
- Type: LCD

Sound

- Bass enhancement: Dynamic Bass boost
- Equalizer: 5-bands
- Equalizer settings: Rock, Pop, Jazz, Classic, Off
- Frequency response: 20 - 20 000Hz
- Output Power: 2 x 5mW (16 Ohm)
- Sensitivity: < 100dB
- THD: 0.01-0.1%
- Volume Control: Up/down, digital

Audio Playback

- Buffer memory: 32MB
- Compression format: MP3, WMA
- ID3-tag support
- MP3 bit rates: 8-320 kbps and VBR
- WMA bit rates: 32-192 kbps
- Sample rates:
8, 11.025, 16, 22.050, 32, 44.1, 48 kHz

Storage Media

- Built-in memory type: Hard disk
- Hard Disk Capacity: 2GB*
- Mass storage class compliant
- Music memory capacity: Up to 1000 songs

Tuner / Reception / Transmission

- Frequency range: 87.5 - 108 MHz
- Station presets: 10
- Tuner Bands: FM Stereo

Connectivity

- Computer support: PC
- DC in: 5V
- Front/side connections:
DC-in, Headphone out, USB type B port
- Stereo headphone 3.5 mm
- Internet connection options: Upgradeable
- Full-speed USB 2.0

Convenience

- Backlight: White superbright LED
- Battery charging indication
- Battery full indication
- Battery low indication
- Function: Keypad lock
- Headphone jack
- Language support:
Incl. English, French, Spanish, Dutch, German, Portugese, Swedish + more.
- Lines of text: 5
- SuperScroll™
- Volume control

Accessories

- AC/DC Adaptor/Charger:
Multi-voltage (AY3192)
- CD-ROM: with installer, PC SW, user manuals
- Headphones: SBC (HE570/77T)
- Printed User Manual
- USB cable (AY3911)
- Pouch (AY4217)
- User Guide on CD-ROM:
Incl. English, French, Spanish, Dutch, German, Portugese, Swedish + more.
- Warranty Card

Software

- DMM: for PC

Green Specifications

- Lead-free soldered product

System Requirements

- CD-ROM drive
- Hard disk space: 100MB
- PC OS:
Windows 98, 2000 (SP3 or above), ME, XP (SP1 or above)
- Processor: Pentium II or better
- RAM memory: 64MB
- Sound card
- Video card

Dimensions

- Clamshell dimensions (WxHxD):
7.9 x 11.8 x 3 inch
- Master carton dimensions (WxHxD):
13.4 x 10 x 10.3 inch
- Master carton quantity: 3
- Product dimensions (WxHxD):
2.1 x 3.3 x 0.7 inch
- Product weight: 3.3 oz

Power

- Adaptor type: 100-240 V
- Battery capacity: 750 mAh
- Battery type: Li-Ion
- Charging time: 4 hrs full, 2 hrs fast charge
- Rechargeable battery
- Battery replaceable by Philips service

Product highlights

SuperPlay™

SuperPlay™ lets you start enjoying your music quickly without the hassle of first selecting playlists or individual tracks. You can listen to all the music under top-level music library categories, such as Artists or Albums, by simply highlighting the category and pressing the Play button. The jukebox plays all the music according to the category sort order. You can also combine SuperPlay™ with Shuffle and Repeat to further enhance your music enjoyment.

SuperScroll™ navigation

Double action search keys allow easy speed control when scrolling through large libraries. You can choose to move through your playlist one song at a time or just press and hold down a little harder to SuperScroll™ swiftly to your desired track.

USB mass storage class

USB mass storage devices offer a convenient way to save, backup and move your files around. The jukebox connects to your computer using a USB connection and does not require any special software to be installed (Windows 98 needs drivers). The jukebox automatically shows up as a removable drive in Windows Explorer allowing you to simply drag and drop files to and from the jukebox.

* Available storage capacity will be less. Capacity based on 4 minutes per song and 64 kbps WMA or 128 kbps MP3 encoding.

** Battery life varies with use

Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

UPC 0 3784994843 9 (/17)

