





# User manual




#### Function overview of the keyboard

- 7. fn+ ▶ :: Play/Pause 8. fn+ ▶ :: Stop 9. fn+ ♠ : Homepage 10. fn+ □ : Email 11. fn+ □ : My computer 12. fn+ ℚ : Search
- 13. III Calculato 14. Number lock indicator 15. Caps lock indicator 16. Low battery indicator 17. Battery door




## Function overview of the mouse

- Scroll wheel
   Left and right buttons
   Wireless receiver. Optical sensor
   ON/OFF switch
   Battery door







3. Take out the receiver and Plug the receiver into the USB port of a PC. close the battery door

2023 © Top Victory Investments Limited . All rights reserved.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Limited , and Top Victory Investments Limited is the warrantor in relation to this product.

Specifications are subject to change without notice

Register your product and get support at: www.philips.com/welcome

### Packaging contents

- Wireless keyboard and mouse
   Wireless receiver
   User manual/warranty card
   1\*AAA battery (inside mouse)
   1\*AAA battery (inside keyboard)

### System requirement

- 1.1 x USB port 2. Windows\* 7,Windows\* 8,Windows\* 10 or later, Android 3.2 and above;

Note: Multimedia functions are partially invalid in different OS versions.

### Technical specifications

- 1. Connectivity: 2.4GHz wireless
  2. Working distance: about 15m
  3. Number of buttons: 3
  4. Button lifespan: 3 million clicks
  5. Keyboard keys lifespan: 8 million keystrokes
  6. Resolution: 1600 DPI
  7. Power supply: 1\*AA Philips battery(mouse).1\*AAA Philips battery(keyboard)
  8. Interface: USB wireless receiver
  9. Mouse size: 110.2x65.6348 mm
  10. Keyboard size: 447.7x136.2x22mm
  11. Product weight: 573g ± 10g
  12. Operating temperature range: 0 \* C to 40 \* C
  13. Operating humidity range: 10% 85%.

### Trouble shooting

- In Make sure that the USB wireless receiver of the product is correctly plugged into the USB port of the computer.

  2. Make sure the computer meets the minimum system requirement.

  3. If the distance between the product and the receiver exceeds an effective range, please reduce the distance for better performance.

If you can't solve the problem, please try to find the solution from Philips website or nearest retailer. Please do not disassemble the product by for

### Attention

- 1. Photoelectric technology can correctly detect the movement of mouse on most surfaces. Do not use the mouse on any reflective, transparent or unever
- surfaces.

  2. Please use dry and soft cloth to clean the product.
- 2. Please use up and soft clutter to clean the product.
  3. Do not disassemble the product by force.
  4. Do not direct the light from the bottom of the mouse to your eyes.
  5. Do not get in the rain or in the sun or fire.
  6. Do not flush directly with water.

### Important safety and compliance information



This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directive (2014/30/EU), RoHS directive (2011/65/EU) and Radio Equipment Directive (2014/53/EU) (for Radio Equipment). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment, these harmonized standards published under Directives of Official Journal of the European Union.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by furning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Receinator reclocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS CLASS B DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE - CAUSING FOI IIPMENT REGULI ATIONS

FCC Compliance Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this
device may not cause harmful interference, and (2) this device must accept any interference received, including
interference that may cause undesired operation.

CET APPAREIL NUMERIQUE DE LA CLASSE B RESPECTE TOUTES LES EXIGENCES DU REGLEMENT SUR LE MATERIEL BROUILLEUR DU CANADA.



Dear customer, Thank you for purchasing a Philips IT accessory product. To ensure you a reliable after-sales service, please read the following instructions carefully. This product warranty period is valid for one year from the date of purchase (the date of receipt of the return receipt and the invoice date of the buyer).

Register your product and get support at :

- The following situations are not covered by after-sales service:

  1. Unable to provide a valid warranty card and invoice (not including those that can prove the products is within the valid warranty period) or the alteration of the
- warranty without authorization.

  2. The product model and serial number on the warranty card are not in conformity with the physical product or without the distributor seal.
- 3. The model number, serial number or production date code on the product has 3. The model number, senal number or production date code on the product has been altered, removed or made illegible.

  4. The defect is the result of excessive use outside the intended purpose, e.g. non-stop use in a commercial environment.

  5. Damage due to not used in accordance with product instructions.

  6. Damage caused by the use of pirated software or computer virus during use.

  7. Damage caused by accident, damage, or repair from unauthorized service vendors.

- vendors.

  8. Damage caused by force majeure.

  9. The product does not work properly due to missing connection caused by accident, signal interference or other influential factors during use.

  10. For normal wear and tear defects, or by their nature consumable parts.

  11. The product does not function properly because it was not originally designed, manufactured or approved for use in the country where you use the product, which might occur when you imported the product.

If the functions of the product which you had purchased are defected or can not be used normally, please contact your local retailer or contact: Email: India.Callcentre@tpv-tech.com

Hotline service: 1800 425 6396

Opening hours: 10 a.m. to 9 p.m. from Monday to Saturday & 10 a.m. to 6 p.m. on

The serial number of the product filled in the form must be consistent with the actual product. This certificate the primary instrument for the after-sales service, please safe keep it. If you need technical support, please show this warranty card, and we will provide quality and professional services.

	Name			
Commodity Information	Place of origin			
	Model No.			
	Serial No.			
User info.	Name			
	Address			
	Tel.			
	Postcode			
Sales info.	Retailer			
	Address			
	Tel.			
	Postcode			
	Sale date			
	Invoice No.			
	Stamp & Signature			
Dear customer, the above information is to be filled in by the seller. Please cooperate with us. Thank you!  The following information shall be filled in by the maintenance agency and returned to the customer.				

	Maintenance company name		
		Address	
	Tel.		
	Maintenance info.	Postcode	
inio.	Document No.		
		Date	
	Signature		