


PHILIPS

Plastična putna
futrola

Philips Sonicare

Bela

CP0546/01



Ponesite četkicu za zube sa sobom

Proverite kompatibilnost ispod

Ova izdržljiva plastična futrola za putovanja omogućava higijensko odlaganje Philips Sonicare električne četkice za zube. Nosite je svuda.

Specifikacije

Zamenljivi deo

Uklapa se u oralnu higijenu: HX8273/20,

HX8454/81, HX8911/30, HX8912/02,
HX8915/01, HX8918/10, HX8923/34,
HX8932/74, HX8932/75, HX8932/76,
HX8941/10, HX8981/02, HX9110/02,
HX9111/12, HX9112/02, HX9112/12,
HX9112/52, HX9114/37, HX9141/07,
HX9141/51, HX9142/10, HX9142/32,
HX9170/10, HX9172/10, HX9172/14,
HX9172/38, HX9182/10, HX9192/29,
HX9192/30, HX9193/03, HX9193/04,
HX9193/05, HX9193/07, HX9194/08,
HX9194/53, HX9194/54, HX8911/35

Odgovara proizvodima za oralnu higijenu:

HX6632/21, HX6652/70, HX6681/07,
HX6711/64, HX6711/65, HX6711/68,
HX6712/06, HX6712/66, HX6712/67,
HX6713/11, HX6721/33, HX6721/35,
HX6721/45, HX6730/33, HX6731/02,
HX6731/03, HX6731/33, HX6732/02,

HX6732/37, HX6732/38, HX6732/42,
HX6732/74, HX6732/75, HX6761/03,
HX6782/33, HX6782/34, HX6908/84,
HX6911/07, HX6911/29, HX6911/77,
HX6911/80, HX6912/21, HX6912/32,
HX6912/44, HX6921, HX6921/02, HX6921/04,
HX6921/30, HX6921/31, HX6922/39, HX6932,
HX6932/10, HX6932/34, HX6932/36,
HX6938/48, HX6942, HX6942/04, HX6942/14,
HX6942/20, HX6952/71, HX6962/70,
HX6962/73, HX6963/74, HX6972/10,
HX6972/31, HX6972/34, HX6972/35,
HX6973/35, HX6982, HX6982/03, HX6982/10,
HX6986, HX6986/03, HX6992/01, HX6992/03,
HX6993/03

Pogodno za sledeće modele: HX1000/01,
HX6211/05, HX6221/22, HX6234, HX6234/35,
HX6235, HX6235/36, HX6252/70, HX6252/71,
HX6252/72, HX6252/73, HX6252/86,
HX6253/81, HX6253/82, HX6253/83,
HX6254/81, HX6315/71, HX6322/29,

HX6325/70, HX6352/45, HX6511/30,
HX6512/59, HX6513/08, HX6513/09,
HX6552/76, HX6552/77, HX6557/76,
HX6582/51, HX6589/37, HX6601/03,
HX6601/29, HX6611/27, HX6612/26,
HX6616/50, HX6616/51, HX6616/52,
HX6631/02, HX6631/13, HX6631/24,
HX6631/30, HX6632/15, HX6632/22,
HX6632/24, HX6632/25, HX6921/06,
HX6921/43, HX6922/03, HX6971/33,
HX6972/03, HX8911/01, HX8911/02,
HX8911/04, HX8911/22, HX8922/37,
HX8922/90, HX8962/05, HX8982/02,
HX9111/20, HX9111/21, HX9112/13,
HX9141/20, HX9142/31, HX9172/15,
HX9172/19, HX9182/18, HX9182/32,
HX9182/34, HX9191/06, HX9191/07,
HX9192/01, HX9192/02

