



# Contents



LCD display




Remote Control and AAA Batteries




Quick start guide



Power Cord




RS232 Cable



RS232 Daisy Chain Cable



IR Sensor Cable



AC Switch Cover




USB Cover



Cable Clip x 2PCS



Philips logo plate




CRD22 Wi-Fi module



\* Differences according to regions.  
Display design and accessories may differ from those illustrated above.






## 1 Unboxing




## 2 Control Panel




## 3 Input/Output Terminals




## 4 Connection



AC IN



AUDIO



DVI





HDMI



DP

## 5 Installation



M8 \* (15+X) mm  
(X=Thickness of Wall mount BKT)  
98BDL4650D: 1000mm x 400mm



6 Mounting in Portrait Orientation

PHILIPS


Signage Display

4000 Series

98BDL4650D



98BDL4650D: X=627.7 mm Y=8.8 mm



# Quick start



For more information, please visit:  
<https://www.philips.com/ppds>



Version: V1.00 2023-09-13

TPV USA Corp  
6525 Carnegie Blvd #200  
Charlotte, NC 28211  
USA

2023 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.



Q41G98M181311A