

PHILIPS




CD Soundmachine


6000 Series

TAZ6000






www.philips.com/welcome










6x1.5V
R14/UM2/C CELL





zzz





1

MENU
(MODE)



2

< / >

ALBUM/PRESET







LOW → MED → HIGH → OFF

3

OK











AURACAST




1

CD/BT



2

AURACAST




3





DAB



1

DAB/FM

DAB

2



TUNE



+

SCANNING

3



PROG/PRESET

DAB-P01

4



PROG/PRESET

P01


5



ALBUM/PRESET



FM



1

DAB/FM



FM

2



TUNE



87.60

3



PROG/PRESET


P01 - P30

4





ALBUM/PRESET


P01



FAV RT 2














Philips Entertainment



Download on the
App Store



GET IT ON
Google Play



philips.to/entapp



2024 © MMD Hong Kong Holding Limited. All rights reserved. Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.