



4



5



MultiView		SUB SOURCE POSSIBILITY (x1)			
MAIN SOURCE (x1)	Inputs	HDMI 1	HDMI 2	DisplayPort	
	HDMI 1	●	●	●	
	HDMI 2	●	●	●	
		DisplayPort	●	●	●



Register your product and get support at www.philips.com/support



FAQ



Software



User Manual

Version: 27M3N5540PQ1T
2024 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

HDMI

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

www.evnia.philips

Printed in China



Z03210055402R

EVNIA

Quick Start





27M3N5540P

Register your product and get support at www.philips.com/welcome


PHILIPS




Contents



Power



DP



Screw

EN The images shown are for illustrative purposes only. Actual product and accessory may vary by country or regions. Actual product and accessory shall prevail in kind.

SC 所有插图和产品配件仅为示意参考。因销售区域差异，产品可能不含有以上配件，具体以实物为准。



FR Les images sont uniquement fournies à des fins d'illustration. Le produit et les accessoires actuels peuvent différer selon le pays ou la région. Le produit et les accessoires réels prévaudront dans tous les cas.

JP 表示されている画像は説明のみを目的としています。実際の付属品は国や地域によって異なる場合がございます。

ES Las imágenes que se muestran son solo de carácter ilustrativo. El producto y los accesorios reales pueden variar según el país o las regiones. El producto real y el accesorio prevalecerán en especie.



KO 표시된 이미지는 이해를 돕기 위한 것으로 실제 제품 및 액세서리는 국가 또는 지역에 따라 다를 수 있습니다. 실제 제품 및 동봉된 액세서리를 확인하세요.

1




▲ CAUTION: Place the monitor face down on a smooth surface. Pay attention not to scratch or damage the screen.

Earphone hanger



2



3

