

PHILIPS



Television

Quick Start Guide



7200 Series



Tool needed
for assembly



43"/55" (Q4xL18) : x4
65" (M4xL20) : x4



1

43"/55"

65"

A

2

3

A Desk Placement

B Wall Placement

43"

55"/65"

Desk Placement (using table stand)

B

Diagonal (inch/cm)	X (mm)	Y (mm)	Screw Size	Screw Length (mm)
43" / 108	200	100	M6	9-10
55" / 139	200	100	M6	9-10
65" / 164	400	300	M8	12-22

Recommended Wall Distance

4

Get Connected

www.philips.to/smartTV

The Philips Smart TV app lets you switch channels and adjust the volume - just like a remote control.

5

Register and Support

www.philips.com/TVsupport

Register your TV, find out more, download the user manual and get support



English	Read the safety instructions.	Français	Lisez les consignes de sécurité.	Português	Leia as instruções de segurança.	Türkçe	Güvenlik talimatlarını okuyun.
Български	Прочетете инструкциите за безопасност.	Italiano	Leggere le istruzioni di sicurezza.	Română	Citiți instrucțiunile de siguranță.	Українська	Читайте інструкції з техніки безпеки.
Čeština	Přečtěte si bezpečnostní pokyny.	Қазақша	Қорғаныстық нұсқаулар.	Русский	Читайте инструкции по технике безопасности.	العربية	قراءة تعليمات السلامة.
Hrvatski	Pročitajte sigurnosne upute.	Latviešu	Izlasiet drošības norādījumus.	Srpski	Pročitajte bezbednosna uputstva.	עברית	קראו את הוראות הבטיחות.
Dansk	Læs sikkerhedsforskrifterne.	Lietuvių	Perskaitykite saugos instrukcijas.	Slovenščina	Preberite varnostna navodila.		
Deutsch	Lesen Sie die Sicherheitshinweise.	Magyar	Olvassa el a biztonsági utasításokat.	Slovenský	Prečítajte si bezpečnostné pokyny.		
Ελληνικά	Διαβάστε τις οδηγίες ασφαλείας.	Nederlands	Lees de veiligheidsvoorschriften.	Suomi	Lue turvaohjeet.		
Eesti	Lugege ohutusnõudeid.	Norsk	Les sikkerhetsforskriftene.	Svenska	Läs säkerhetsinstruktionerna.		
Español	Lea las instrucciones de seguridad.	Polski	Zapoznaj się z instrukcjami bezpieczeństwa.	ภาษาไทย	โปรดอ่านคำแนะนำด้านความปลอดภัย.		

