



PHILIPS





Television Quick Start Guide 6000 series



Tool needed
for assembly




24" (Q4xL14) x 4
40" (Q4xL18) x 4




A Desk Placement

B Wall Placement



Desk Placement (using table stand)




3
Get Connected





www.philips.to/smartTV
The Philips Smart TV app lets you
switch channels and adjust the
volume - just like a remote control.

4
Register and Support




www.philips.com/TVsupport
Register your TV, find out more,
download the user manual and
get support



Diagonal (inch/cm)	X (mm)	Y (mm)	Screw Size	Screw Length (mm)
24" / 60	200	200	M4	6-10
40" / 100	200	200	M4	8-10

Recommended Wall Distance



English
Български
Čeština
Hrvatski
Dansk
Deutsch
Ελληνικά
Eesti

Read the safety instructions.
Прочетете инструкциите за безопасност.
Přečtěte si bezpečnostní pokyny.
Pročitajte sigurnosne upute.
Læs sikkerhedsforskrifterne.
Lesen Sie die Sicherheitshinweise.
Διαβάστε τις οδηγίες ασφαλείας.
Lugege ohutusnõudeid.

Español
Français
Italiano
Қазақша
Latviešu
Lietuvių
Magyar
Nederlands
Norsk

Lea las instrucciones de seguridad.
Lisez les consignes de sécurité.
Leggere le istruzioni di sicurezza.
Қорғаныстық нұсқаулар.
Izlasiet drošības norādījumus.
Perskaitykite saugos instrukcijas.
Olvassa el a biztonság utasításokat.
Lees de veiligheidsvoorschriften.
Les sikkerhetsforskriftene.


Polski
Português
Română
Русский
Srpski
Slovenščina
Slovenský
Suomi

Zapoznaj się z instrukcjami bezpieczeństwa.
Leia as instruções de segurança.
Citiți instrucțiunile de siguranță.
Читайте инструкции по технике безопасности.
Pročitajte bezbednosna uputstva.
Preberite varnostna navodila.
Prečítajte si bezpečnostné pokyny.
Lue turvaohjeet.


Svenska
ภาษาไทย
Türkçe
Українська

Läs säkerhetsinstruktionerna.
โปรดอ่านคำแนะนำด้านความปลอดภัย
Güvenlik talimatlarını okuyun.
Читайте інструкції з техніки безпеки.
قراءة تعليمات السلامة.
קראו את הוראות הבטיחות


FSC Logo
H:12mm




POWER (UK)




NETWORK




DIGITAL AUDIO OUT




HDMI 2/3 (40")





HDMI 1 ARC (40")



ANTENNA (24")



SAT (EU) (24")



COMMON INTERFACE



USB 1/2



HDMI 2/3 (24")










HDMI 1 ARC (24")




ANTENNA (40")



SAT (EU) (40")





To install batteries, slide the battery door up.



Use 2x AAA LR03 1.5V (included)



Slide battery door back in place.



All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of TP Vision Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product. 2025 © TP Vision Europe B.V. All rights reserved. www.philips.com/welcome

先送样10PCS

QSG 放在EPS的上方：

CTN range	24"/40"6000 Series
Description	Quick Start Guide
Pages	2 pages
Paper spec	white (not 'grey') - 80gr/m² (minimum) matt/uncoated- recycled, with FSC logo 80g双胶纸，过FSC认证
Paper weight cover	—
Paper weight inside	—
Format	420 x 297 mm
Format (closed)	140 x 99 mm
Print	CMYK
Print on spine	—
Binding	—
Folding	See drawing

