

PHILIPS







Televisión

Guía de inicio rápido







Serie 6920



Herramienta necesaria para el ensamble




ST: Tornillo de rosca tipo cruz plano




B

Diagonal (pulgadas/cm)	X (mm)	Y (mm)	Tamaño del tornillo	Largo del tornillo (mm)
40"/100	200	200	ARRIBA: M4 ABAJO: ST4	9,5-10,5 9,5-10,5






1




Para instalar las baterías, deslice la tapadel compartimiento de las baterías hacia arriba.

2




Usa 2 pilas AAA
R03P 1,5 V (incluido)


3



Deslice la tapa del compartimiento nuevamente a su lugar.





1 2
3 4




English
Español


Read the safety instructions.
Lea la información de seguridad.




POWER




NETWORK




HDMI 2




HDMI 1
ARC




TV
ANTENNA




MINI AV-IN



USB-2
USB-1
5V 500mA



DIGITAL
AUDIO OUT



All registered and unregistered trademarks are property of their respective owners.
Specifications are subject to change without notice.
Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V.
and are used under license.
This product has been manufactured by and is sold under the responsibility of TP Vision
Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product.
2025 © TP Vision Europe B.V. All rights reserved.
www.philips.com/welcome