

包装清单



电子纸显示看板



快速使用指南




CR2450 锂电池


* Differences according to regions. / 不同地点项目可能会有差异。
Display design and accessories may differ from those illustrated above.
显示器设计及附件可能与所示图片有所差异。



1 产品介绍



① Power 按钮：
切换工作/休眠模式、恢复出厂页面
连续短按3次绿灯闪烁设备进入休眠模式；
休眠模式下短按1次绿灯亮起表示设备已唤醒
并进入工作模式；
只有在工作模式下才可进行蓝牙投图；
长按5秒恢复出厂画面；



② LED
③ 电池盖
请安装4颗CR2450纽扣电池后使用桌牌；
④ Reset 按钮：
短按1次重启系统

2 手机安装应用程序



电子纸显示看板


注意：
支持 Android、Harmony OS
请使用 Android、Harmony OS 手机浏览器扫描左侧 QR Code
下载安装电子纸显示看板APP。

PHILIPS

Tableaux Display

2000 Series

6BDL21501



快速使用指南



For more information, please visit:
请查看以下网站了解更多产品信息。
<https://www.philips.com/ppds>

3 内容图案投射至电子纸显示看板

准备工作

- 1、短按Power按钮唤醒设备，绿灯亮起表示已被唤醒处于工作模式。
- 2、请检查手机蓝牙是否开启，位置信息权限是否开启。

快速投图



- 1、选择5.79"桌牌（三色）设备进入模板页，选择模板点击“使用”进入模板详情页。
- 2、填写“模板内容”并选择“图片处理方式”后点击“投图至设备”进入设备列表页。
- 3、点击右上角“+”添加设备，选择在线的设备后点击“蓝牙投图”。
- 4、等待图片上传完成，查看设备刷新显示效果。



2024 © TOP Victory Investments Ltd. All rights reserved.
This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.
规格如有变更，恕不另行通知。

Version: V1.00 2024-03-14



Q41G06M181302A