






PHILIPS

Micro Music System
TAM4505M2




www.philips.com/welcome









1





2



3





- 1
- 2
- 3
- 4
- 5
- 6

PHILIPS


244






244 / 124


00:00


12:00

12:00










1 FM
DAB

2 A |◀◀/▶▶|

2 B |◀◀/▶▶|


 3sec.



DAB

↓

SCANNING


FM

87.5 






1




2






3




3






4



5





1

FM

BT

USB

CD

AUDIO IN


DAB




2

AURACAST BROADCASTER

A



Purple
Amber





3

AURACAST RECEIVER

B



AURACAST



SCANNING

C



AURACAST RECEIVER

AURACAST




SCANNING



4

A



B




C






A







B



C








- 1
- 2
- 3
- 4

12:28

00:00
TIMER

08:00
TIMER

08:00
TIMER



5 | ⏮⏮ / ⏭⏭ |

6 SLEEP
TIMER

7 | ⏮⏮ / ⏭⏭ |

8 SLEEP
TIMER

9 | ⏮⏮ / ⏭⏭ |

00 30

TIMER

DISC

TIMER

FM

TIMER





VOL 12

TIMER

VOL 00

TIMER

zzZ





Philips Entertainment






Download on the
App Store





GET IT ON
Google Play



philips.to/entapp







Source Control



Source

Bluetooth >



Auracast™ broadcasts



Preset stations



Source



CD



Bluetooth



Auracast™ receiver



FM



USB



Audio In

Cancel

OK

No Preset

There is no preset FM station. Please perform preset by using either local buttons or remote control.

Auto Preset

Manual Preset

Cancel



88.1MHz



88.1MHz



88.1MHz



88.1MHz



88.1MHz



88.1MHz



88.1MHz



Source

CD >



Auracast™ broadcasts



CD/MP3 programming



Playback mode

Repeat All >



Source

CD >



Auracast™ broadcasts



CD/MP3 programming



Playback mode

Repeat All >



CD/MP3 programming

Album

Track

T0011

A001

T0001

T0002

Add to List

Preview List

Save to device

Cancel

Playback mode

☐ Off

☐ Repeat One

☒ Repeat All

☐ Shuffle

Cancel

OK



Source

- ☐ CD
- ☐ Bluetooth
- ☒ Auracast™ receiver
- ☐ FM
- ☐ USB
- ☐ Audio In

Cancel

OK



Source Control



Source

Auracast™ receiver >



Auracast™ broadcasts >



Preset stations >



Music >



LE Audio compatible



Auracast™ broadcasts



- ☒ Unencrypted Auracast
- ☐ Encrypted Auracast



Auracast™ broadcasts



- ☐ Unencrypted Auracast
- ☒ Encrypted Auracast



Enter Password




Cancel

OK




Clock Setting

 24-Hr Time ☒

 Sync Clock ☐

 Clock >

 Timer Off >

 Sleep Timer Off >

Clock

03 04
04 05
05 06
06 07
07 08

Cancel

OK

Timer

05 02
06 03
07 04
08 05
09 06

Enable timer ☒

Wake-up source CD >

Wake-up volume 15 >

Save


Cancel



Sleep Timer

- ☐ Off
- ☐ 15 min
- ☒ 30 min
- ☐ 60 min
- ☐ 90 min
- ☐ 120 min

Cancel

OK







www.philips.com/support



2024 © MMD Hong Kong Holding Limited. All rights reserved. Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

TAM4505M2_ QSG_V1.0

