

PHILIPS

sonicare



Rechargeable
toothbrush

4100

Gently removes 5x more plaque

Pressure Sensor

4 brushing settings

Easy Start



HX4043/48

Essential Care for healthy teeth and gums

Gently removes up to 5x more plaque*

Switch to electric brushing effortlessly with the essential Philips Sonicare 4000 Series. Enjoy up to 5x more plaque removal vs a manual toothbrush

Brushing made effortless

- Easy switch to electric brushing
- Guided brushing sessions
- Choose your ideal cleaning experience

Designed for your lifestyle

- Keep brushing your best with brush head replacement reminder
- 21-day battery life

Feel the care of Sonicare

- Gently removes up to 5x more plaque*
- Sonicare Fluid Action
- Help protect your gums with our pressure sensor

4100

Rechargeable toothbrush

HX4043/48


Highlights

Say goodbye to plaque




This electric toothbrush comes our W brush head. It uses densely-packed bristles to deliver up to 5x more plaque removal*, while treating your whole mouth to a refreshing clean.

Sonicare Fluid Action



Philips Sonicare toothbrushes clean gently yet effectively and care for your teeth and gums with 31,000 bristle movements. Sonicare Fluid Action supports the bristles to clean by driving fluid deep between teeth and along the gumline.

Pressure Sensor




It's easy to brush too hard, so this Philips Sonicare toothbrush has a smart optic sensor to detect excessive pressure. If you're brushing too hard, it will let you know through gentle vibrations as a reminder to ease-off the pressure to help your gums stay protected.

Modes and intensities




Enjoy a pleasure clean with 4 brushing settings. Choose between Gentle and Clean mode and one of two intensity settings. Whether you want a little more vigor or a specific focus for your clean, you can have it.

Easy Start




Sonicare easy-start program is designed for those who are new to brushing with an electric toothbrush. The program gives you the option of a gradual, gentle increase in brushing power across your first 14 cleans.

SmartTimer & QuadPacer



Ace your session time with Sonicare's cleaning timers. Every 30 seconds, the BrushPacer will prompt you to clean a new area. After 2 minutes, the SmartTimer will indicate your session is complete.

Replacement Reminder



Did you know brush heads become less effective after three months? Dental professionals recommend changing your brush head regularly, that's why Philips Sonicare toothbrushes have a brush head replacement reminder. It tracks how often and how hard you brush, then reminds you to replace your brush head once it's time for a new one.

Battery life



Experience up to 21 days of regular brushing after one full charge. Bringing a new level of convenience to your brushing routine.

4100

Rechargeable toothbrush

HX4043/48

Specifications

Intensities

Low: For sensitive teeth and gums

Intensities

Medium: For an everyday clean

Power

Voltage: 100-240 V

Technical specifications

Battery: Rechargeable

Operating time (full to empty): 21 days

Energy Consumption: Standby without display
<0.5 W (automatically reached within 1 minute)

Battery type: Lithium ION

Design and finishing

Color: Marine Blue

Service

Warranty: 2-year limited warranty

Ease of use

Handle compatibility: Easy click-on brush heads

Battery indicator: Illuminated icon indicates
battery life

Handle: Slim ergonomic design

Timer: SmarTimer and QuadPacer

Items included

Handle: 1 4100 rechargeable toothbrush

Brush head: 1 Optimal White W

Travel case: 1

Charger: 1

Cleaning performance

Plaque removal: Up to 5x more plaque removal*

Modes

Clean: For exceptional everyday clean

Gum Health: Gently massages your gums

