

PHILIPS

Television

Quick Start Guide


8300 series










The actual accessories may vary from the illustrations, which are for reference only.








Tool needed
for assembly




55" (M4xL12) x 4
65" (M5xL15) x 4
75" (M5xL15) x 4



Images are for illustrative purpose.




B



Diagonal (inch/cm)	X (mm)	Y (mm)	Screw Size	Screw Length (mm)
55" / 138	300	200	M6	35-30
65" / 164	400	200	M6	35-30
75" / 189	400	300	M6	35-32


Recommended Wall Distance

7-10 cm





English

Read the safety instructions.




POWER
55" / 65"

POWER
75"



1



To install the battery,
slide the battery
cover downwards.

2




Use 2x AAA
LR03 1.5V (included)

3



Slide battery door
back in place.



All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of TP Vision Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product. 2025 © TP Vision Europe B.V. All rights reserved. www.philips.com/welcome

先送样

QSG 放在EPS的上方：

CTN range	55"/65"/75"8300 Series
Description	Quick Start Guide
Pages	2 pages
Paper spec	white (not 'grey') - 80gr/m² (minimum) matt/uncoated - recycled, 80g双胶纸
Paper weight cover	–
Paper weight inside	–
Format	420 x 297 mm
Format (closed)	420 x 99 mm
Print	CMYK
Print on spine	–
Binding	–
Folding	See drawing

