

PHILIPS

Television

Quick Start Guide





8500 Series

7314-550GFU-25051211



The actual accessories may differ from the illustrations, which are for reference purposes only.



Tool needed for assembly



M: Machine screw



1 50"/55"

65"/75"

2 50"/55"/65"/75"

A Desk Placement

B Wall Placement

3

A 50"/55"/65" 75"

Desk Placement (using table stand)

B

Diagonal (inch/cm)	X (mm)	Y (mm)	Screw Size	Screw Length (mm)
50"/126	300	300	Up: M6 Down: ST6	20.5~32 8~11.5
55"/139	300	300	Up: M6 Down: ST6	20.5~32 8~11.5
65"/164	300	300	Up: M6 Down: ST6	20.5~32 8~11.5
75"/189	500	300	Up: M8 Down: M8	22~29 22~29

1

Recommended Wall Distance

4 Register and Support




1




To install batteries, slide the battery door up.

2






Use 2x AAA R03 1.5V (included)

3



Click Slide battery door back in place.



English Read the safety instructions.
Bahasa Malaysia Baca arahan Keselamatan.
Bahasa Indonesia Baca petunjuk keselamatan.



Deutschh Lesen Sie die Sicherheitshinweise.
Français Lisez les consignes de sécurité.
Português Leia as instruções de segurança.

ภาษาไทย โปรดอ่านคำแนะนำด้านความปลอดภัย
Tiếng Việt Hãy đọc chỉ dẫn an toàn.
简体中文 请阅读安全说明。

العربية قراءة تعليمات السلامة.



50"/55"/65"/75"



All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of TP Vision Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product. 2025 © TP Vision Europe B.V. All rights reserved. www.philips.com/welcome