







大型顯示器

快速使用指南


7700系列




安裝所需工具





M: 機械螺釘




壁掛架自攻螺釘
1包(2顆)




(/96)




1 50"/55"




65"/75"




2




A 放置桌面




B 放置牆面




3




A




50" 55"




65"



放置桌面（使用底座）




75"




B

尺寸/對角線(inch/cm)	X (mm)	Y (mm)	螺釘大小	螺釘長度
50" / 126	300	300	UP: M6 Down: ST6	20.5-32 8-11.5
55" / 139	300	300	UP: M6 Down: ST6	20.5-32 8-11.5
65" / 164	300	300	UP: M6 Down: ST6	20.5-32 8-11.5
75" / 189	500	300	UP: M8 Down: M8	22-29 22-29


1



2




推薦的離牆距離



4

注冊和支持



www.philips.com/TVsupport

注冊您的電視，了解更多信息，下載用戶手冊獲得支持

1

安裝電池時，
將電池蓋向上
滑動。

2

使用2x AAA
1.5V (包括)

3

點擊
將電池蓋推回
原位

設備名稱：Philips LED智慧大型顯示器						
型號（型式）：50PUH7700/96/50PUH7710/96/55PUH7700/96/55PUH7710/96 65PUH7700/96/65PUH7710/96/75PUH7700/96/75PUH7710/96						
單元	限用物質及其化學符號					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ⁺⁶)	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
塑料外框	○	○	○	○	○	○
後殼	○	○	○	○	○	○
液晶面板	—	○	○	○	○	○
電路板組件	—	○	○	○	○	○
底座	○	○	○	○	○	○
電源線	—	○	○	○	○	○
其他線材	—	○	○	○	○	○
遙控器	—	○	○	○	○	○
備考1. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。						
備考2. “—” 係指該項限用物質為排除項目。						

English

Read the safety instructions.

繁體中文

請閱讀安全說明。

50"/55"/65"/75"