

594 mm

198 mm

料号及对应的二维码已加，请供应商仔细核对。如果和下单不符合，请及时和我联系

7314-500GFU-50705261

The actual accessories may differ from the illustrations, which are for reference purposes only.

PHILIPS









Television

Quick Start Guide

8500 Series




Tool needed for assembly




M: Machine screw


1 50"/55"




65"/75"




2 50"/55"/65"/75"




A Desk Placement




B Wall Placement




3




A



50"/55"/65" 75"




Desk Placement (using table stand)




B


Diagonal (inch/cm)	X (mm)	Y (mm)	Screw Size	Screw Length (mm)
50" / 126	300	300	Up:M6 Down:ST6	20.5~32 8~11.5
55" / 139	300	300	Up:M6 Down:ST6	20.5~32 8~11.5
65" / 164	300	300	Up:M6 Down:ST6	20.5~32 8~11.5
75" / 189	500	300	Up:M8 Down:M8	22~29 22~29




1



2



Recommended Wall Distance



4

Register and Support



www.philips.com/TVsupport

Register your TV, find out more, download the user manual and get support

裁切线，不印刷

