



PHILIPS


Television Quick Start Guide 5200 series



Tool needed for assembly



32" (BB4X12mm) x 2
43" (BB4X12mm) x 2




M: Machine screw
(32"/1 Pieces/bag)
(43"/1 Pieces/bag)



(/67, /70)



(/71, /74)



The actual accessories may differ from the illustrations, which are for reference purposes only.

M: Machine screw

ST: Flat tail self-tapping screw

1 32"/43"

2

3

A Desk Placement

B Wall Placement

4

(BB4X12mm) X 2

A

← BASE →

← BASE →

32"/43"

← BASE →

← BASE →

Desk Placement (using table stand)

B

Diagonal (inch/cm)	X (mm)	Y (mm)	Screw Size	Screw Length (mm)
32"/80	100	100	M4	7-8mm
43"/108	200	200	M6	7-8mm

Recommended Wall Distance


7-10 cm

4

Register and Support

www.philips.com/TVsupport

Register your TV, find out more, download the user manual and get support



English Read the safety instructions.

Bahasa Malaysia Baca arahan Keselamatan.

Bahasa Indonesia Baca petunjuk keselamatan.

العربية قراءة تعليمات السلامة.

Deutsch Lesen Sie die Sicherheitshinweise.




Français Lisez les consignes de sécurité.

Português Leia as instruções de segurança.

ภาษาไทย โปรดอ่านคำแนะนำด้านความปลอดภัย

Tiếng Việt Hãy đọc chỉ dẫn an toàn.

简体中文 请阅读安全说明。



PHILIPS

All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of TP Vision Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product. 2026 © TP Vision Europe B.V. All rights reserved. www.philips.com/welcome