Artwork: 170V7 Quick Start Guide
Extend: 4pp + 4pp
Size: Open: 594W x 210Hmm Close: 148.5W x 210H (mm)
Material: 100gsm White, woodfree coated
Printing: Both side printing - 2C x 2C – Pantone 3005C + Black
Finishing: Folded sheet
Date prepared: 15 Mar 2006



LCD Monitor 170V7

Quick start guide

1 Installation
2 Connectivity
3 Ergonomic Adjustments

PHILIPS

Display design may differ from that illustrated

Q4H5780-0413-22A

What's in the box

Monitor

Quick Start Guide

EDFU CD

Power cord

VGA cable

1 Installation

A Unfold the base



Put monitor face down on the safe surface.

Pull up the base.

B Fold the base

Push down the head of monitor.

C Cable management

Plug the power cord and VGA cable into monitor firmly.

2 Connectivity

A Monitor Connections

1 AC power input
2 VGA input
3 Kensington anti-thief lock

B VGA

For best performance, use your VGA input and ensure that your display settings are set at 1280 ×1024 @60Hz

C POWER

3 Ergonomic Adjustments

A Tilt



B Quick reference for control buttons



1 To switch monitor's power On and Off
2 To access OSD menu
3 To adjust the OSD menu
4 To adjust brightness of the display
5 To adjust OSD menu
6 AUTO Automatically adjust the horizontal position, vertical position, phase and clock settings.

Specifications are subject to change without notice.
Trademarks are property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V. All rights reserved.
www.philips.com

Need help?
User manual
Ein Benutzerhandbuch
Un manuel d'utilisation
Un manual de usuario
Un manuale d'uso
Gebruikershandleiding
Uživatelská příručka
Kullanım kılavuzu
Kasutusjuhend
Lietotāja rokasgrāmata
Naudotojo vadovas
Kasutusjuhend
Kullanım kılavuzu
Uživatelská příručka
Lietotāja rokasgrāmata
Naudotojo vadovas
Kullanım kılavuzu
Kasutusjuhend