Always there to help you

Register your product and get support at
www.philips.com/support

NC1

Question?
Contact
Philips

User manual

PHILIPS

Contents

1 Important safety instructions 2
Hearing Safety 2
General information 2

2 Your noise canceling on-ear headphones 3
What's in the box 3
Overview of your noise canceling headphones 3

3 Get started 5
Charge your headphones 5

4 Use your headset 6
Activate/Deactivate noise cancelation 6
Connect to airline audio systems 6

5 Technical data 7

6 Notice 8
Notice of compliance 8
Disposal of your old product and battery 8
Trademarks 9

1 Important safety instructions

Hearing Safety

Danger

- To avoid hearing damage, limit the time you use headphones at high volume and set the volume to a safe level. The louder the volume, the shorter the safe listening time is.

Be sure to observe the following guidelines when using your headset.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume continuously upwards as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations.
- Excessive sound pressure from earphones and headphones can cause hearing loss.
- Using headphones with both ears covered while driving is not recommended and may be illegal in some areas while driving.
- For your safety, avoid distractions from music or phone calls while in traffic or other potentially dangerous environments.

General information

To avoid damage or malfunction:

Caution

- Do not expose headphones to excessive heat.
- Do not drop your headphones.
- Headphones shall not be exposed to dripping or splashing.
- Do not allow your headphones to be submerged in water.
- Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives.
- If cleaning is required use a soft cloth, if necessary dampened with a minimum amount of water or diluted mild soap, to clean the product.
- The integrated battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Use only the Philips airline adapter to connect the headphones to airplane seat jacks. Do not use other airline adapters as they might not result in correct response or even result in personal injury such as burns or property damage due to overheating. Remove the adapter and disconnect immediately if you experience warming or loss of audio.
- Do not insert any plug into the power jack of the airplane seat because it may damage the headphones and result in personal injury.
- Never use your headphones when you are operating a motor vehicle, riding a bicycle, running or walking in traffic areas. It is dangerous and illegal in many places.

About operating and storage temperatures and humidity

- Operate or store in a place where temperature is between -15°C (5°F) and 55°C (131°F) (up to 90% relative humidity.
- Battery life may be shorter in high or low temperature conditions.

2 Your noise canceling on-ear headphones

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at **www.philips.com/welcome**.

What's in the box

Philips noise canceling on-ear headphones NC1



Audio cable with microphone and in-line control for handsfree calling



Airline adapter



USB charging cable (for charging only)



Travel case

Quick start guide

Overview of your noise canceling headphones



1. Feedforward microphone
2. 3.5mm audio input jack
3. Active noise canceling (ANC) on/off button
4. Microphone and in-line control for handsfree calling
5. Micro USB charging port
6. Charging indicator
7. ANC power indicator
8. Feedback microphone

3 Get started

Charge your headphones

Note

- Before you use your headphones for the first time, charge the battery for 5 hours for optimum battery capacity and lifetime.
- Use only the original USB charging cable to avoid any damage.
- You can operate the headphones normally during charging.
- Normally, a full charge takes 2 hours.
- When the battery level is low, the white LED will flash.

Connect the supplied USB charging cable to:

- the micro USB charging port on the headphones and;
- the charger/USB port of a computer.

↳ LED turns orange during charging and turns off when the headset is fully charged.

↳ LED turns white when ANC is on.

4 Use your headset



Activate/Deactivate noise cancelation

- Switch on the ANC on/off button to activate noise cancelation.
- Switch off the ANC on/off button to deactivate noise cancelation.
- When the battery level is empty or when the ANC function is not required, switch off the ANC on/off button to continue your call or listening to music.

Connect to airline audio systems

1 Connect the audio cable into the airline adapter.



2 Insert the adapter into the dual output jacks in the airplane seat.

- One 3.5mm jack
  Use the single plug. No adapter is needed.

- Two 3.5 jacks
  Use the 3.5mm dual plug airline adapter.

- One power jack and two 3.5mm jacks
  Use the 3.5mm dual plug airline adapter.
  Make sure you insert it into two 3.5 jacks.

5 Technical data

- Active noise cancelation: Hybrid (4 microphones)
- ANC play time: 30 hours
- Music and talk time: Unlimited
- Low battery warning: available

Note

- Specifications are subject to change without notice.

6 Notice

Notice of compliance

Notice for US

This set complies with the FCC rules, Part 15 and with 21 CFR 1040.10. Operation is subject to the following two conditions:

1. **This device may not cause harmful interference, and**
2. **This device must accept any interference received, including interference that may cause undesired operation.**

FCC rules

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Caution: Changes or modifications made to this equipment not expressly approved by Philips may void the FCC authorization to operate this equipment.

Model number: NC1

Trade Name: Philips

Responsible party:P&F USA, Inc. PO Box 2248 Alpharetta, GA 30023-2248; 1-866-310-0744

Notice for Canada:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

IC Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for uncontrolled environments.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Disposal of your old product and battery

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

This product may contain lead and mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact

your local authorities or visit www.recycle.philips.com.

This product contains non-removable batteries:

- Do not incinerate. Batteries may explode if overheated.
- For disposal or recycling information, please contact your local authorities or visit www.recycle.philips.com.

Remove the integrated battery

Note

- Make sure the headset is disconnected from the USB charging cable before removing the battery.

If there is no collection/recycling system for electronic products in your country, you can protect the environment by removing and recycling the battery before disposing the headset.



Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Trademarks

Bluetooth

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by WOOX Innovations Limited is under license.

Siri is a trademark of Apple Inc., registered in the U.S. and other countries.

Google

Google and the Google Logo are registered trademarks of Google Inc.

2015 © WOOX Innovations Limited. All rights reserved.

Philips and the Philips' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by WOOX Innovations Limited under license from Koninklijke Philips N.V.

UM_NC1_00_EN_V1.0
wk1506