PHILIPS

Soundbar

4000 Series

TAB4000

www.philips.com/welcome

EN Before using your Product, read all accompanying safety information

FR Avant d'utiliser votre produit, lisez toutes les informations de sécurité qui l'accompagnent

ES Antes de usar el producto, lea toda la información de seguridad que lo acompaña

Soundbar



Remote control
(AAA batteries x 2)



Wall mounting screws x2
Wall anchors x2



Wall mount template

Adapter: x1pcs



Quick start guide
Warranty card/Safety sheet

* Adapter and plug type vary by regions.
* The attached items and images may vary by regions.

1

EN Position the SoundBar/Wall mount the SoundBar (optional)

FR Placement / Montage mural (en option) de la barre de son

ES Colocar la barra de sonido/Montar la barra de sonido en la pared (opcional)





Suggested wall mounting height

You are suggested to install the TV first before wall mounting the soundbar.

With a TV preinstalled, wall mount the soundbar 50mm/2. 0’’ in distance from the bottom of the TV.

If you wall mount the soundbar first, drill 2 parallel holes (Ø 3-8 mm each according to wall type) in the wall.

The distance between the holes should be 640mm / 25.2“

2

EN Switch on the SoundBar

FR Allumez la barre de son

ES Encender la barra de sonido

❶



❷



❸



3

EN Connect the SoundBar

FR Connexion de la barre de son

ES Conectar la barra de sonido



4



EN Select the correct audio source

FR Sélectionnez la source audio appropriée

ES Seleccionar la fuente de audio correcta



5



EN Play other devices

FR Lecture d'autres appareils

ES Reproducir otros dispositivos



6

EN Play audio through Bluetooth

FR Lecture de l'audio via Bluetooth

ES Reproducir audio mediante Bluetooth



EN For more information about using this product, visit www.philips.com/support

FR Pour plus d'informations sur l'utilisation de ce produit, visitez www.philips.com/support

ES Para obtener más información sobre el uso de este producto, visite www.philips.com/support

Philips.com/TAB4000



Trademarks:

Roku TV Ready

✓Simple setup
✓One remote
✓Quick settings

EN: If you have a Roku TV™, simply plug in the HDMI cable to the ARC ports and follow the Roku TV Ready™ on-screen instructions. Roku, the Roku logo, Roku TV, Roku TV Ready, and the Roku TV Ready logo are trademarks and/or registered trademarks of Roku, Inc. This product is Roku TV Ready-supported in the United States, Canada, United Kingdom, Mexico and Brazil. Countries are subject to change. For the most current list of countries in which this product is Roku TV Ready-supported, please email rokutvready@roku.com.

FR: Si vous avez un Roku TV™ , la configuration est simple. Utilisez juste le câble inclus pour brancher votre barre de son au port HDMI ARC de votre télé et suivez les instructions à l'écran. Roku TV, Roku TV Ready et le logo Roku TV Ready sont des marques de commerce de Roku Inc. Ce produit est certifié Roku TV Ready au/en états-Unis, Canada, Royaume-Uni, Mexique et Brésil. La liste de pays peut varier. Pour obtenir la liste la plus récente des pays dans lesquels ce produit est pris en charge par Roku TV Ready, veuillez envoyer un courriel à rokutvready@roku.com.

ES: Si tienes una Roku TV™, la configuración es fácil. Solo tienes que usar el cable incluido para conectar la barra de sonido al puerto HDMI ARC de la TV y seguir las instrucciones queaparecen en pantalla. Roku TV, Roku TV Ready y el logotipo de Roku TV Ready son marcas comerciales de Roku, Inc. Este producto es compatible con Roku TV Ready en Estados Unidos, canadá, reino unido, méxico y brasil. Los países están sujetos a cambios. Para obtener la lista más actualizada de países en los que este producto es compatible con Roku TV, envía un correo electrónico a rokutvready@roku.com.

HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by MMD Hong Kong Holding Limited is under license. Other trademarks and trade names are those of their respective owners.

Specifications are subject to change without notice. Please visit www.Philips.com/support for the latest updates and documents.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

TAB4000/37_QSG_V2.0_250311