



## www.philips.com/welcome

EN User manual 1

Customer care and warranty 23

Troubleshooting & FAQs 27

## **Table of Contents**

1.	Important
2.	Setting up the monitor
3.	Image Optimization123.1 SmartImage123.2 SmartContrast13
4.	PowerSensor™14
5.	Built-in Webcam with Microphone
6.	Technical Specifications18 6.1 Resolution & Preset Modes21
7.	Power Management22
8.	Customer care and warranty . 23 8.1 Philips' Flat Panel Monitors Pixel Defect Policy
9.	Troubleshooting & FAQs

## 1. Important

This electronic user's guide is intended for anyone who uses the Philips monitor. Take time to read this user manual before you use your monitor. It contains important information and notes regarding operating your monitor.

The Philips guarantee applies provided the product is handled properly for its intended use, in accordance with its operating instructions and upon presentation of the original invoice or cash receipt, indicating the date of purchase, dealer's name and model and production number of the product.

# 1.1 Safety precautions and maintenance

## Warnings

Use of controls, adjustments or procedures other than those specified in this documentation may result in exposure to shock, electrical hazards and/or mechanical hazards.

Read and follow these instructions when connecting and using your computer monitor.

Excessive sound pressure from earphones and headphones can cause hearing loss. Adjustment of the equalizer to maximum increases the earphones and headphones output voltage and therefore the sound

## Operation

pressure level.

 Please Keep the monitor out of direct sunlight, very strong bright lights and away from any other heat source. Lengthy exposure to this type of environment may result in discoloration and damage to the monitor.

- Remove any object that could fall into ventilation holes or prevent proper cooling of the monitor's electronics.
- Do not block the ventilation holes on the cabinet.
- When positioning the monitor, make sure the power plug and outlet are easily accessible.
- If turning off the monitor by detaching the power cable or DC power cord, wait for 6 seconds before attaching the power cable or DC power cord for normal operation.
- Please use approved power cord provided by Philips all the time. If your power cord is missing, please contact with your local service center. (Please refer to Service contact information listed in Important information manual.)
- Operate under the specified power supply. Be sure to operate the monitor only with the specified power supply. Use of an incorrect voltage will cause malfunction and may cause fire or electric shock.
- Protect the cable. Do not pull or bend the power cable and signal cable. Do not place the monitor or any other heavy objects on the cables, if damaged, the cables may cause fire or electric shock.
- Do not subject the monitor to severe vibration or high impact conditions during operation.
- Do not knock or drop the monitor during operation or transportation.
- Excessive usage of monitor can cause eye discomfort, it's better to take shorter breaks more often at your workstation than longer breaks and less often; for example a 5-10 minute break after 50-60-minute continuous screen use is likely to

be better than a 15-minute break every two hours. Try to keep your eyes from eye strain while using the screen for a constant period of time by:

- Looking at something varying distances after a long period focusing on the screen.
- Conscious Blinking often while you work.
- Gently closing and rolling your eyes to relax.
- Reposition your screen to appropriate height and angle according to your height.
- Adjusting the brightness and contrast to appropriate level.
- Adjusting the environment lighting similar to that of your screen brightness, avoid the fluorescent lighting, and surfaces that don't reflect too much light.
- Seeing a doctor if your symptoms.

### Maintenance

- To protect your monitor from possible damage, do not put excessive pressure on the LCD panel. When moving your monitor, grasp the frame to lift; do not lift the monitor by placing your hand or fingers on the LCD panel.
- Unplug the monitor if you are not going to use it for an extensive period of time.
- Unplug the monitor if you need to clean it with a slightly damp cloth.
   The screen may be wiped with a dry cloth when the power is off.
   However, never use organic solvent, such as, alcohol, or ammonia-based liquids to clean your monitor.
- To avoid the risk of shock or permanent damage to the set, do

- not expose the monitor to dust, rain, water, or excessive moisture environment.
- If your monitor gets wet, wipe it with dry cloth as soon as possible.
- If foreign substance or water gets in your monitor, please turn the power off immediately and disconnect the power cord. Then, remove the foreign substance or water, and send it to the maintenance center.
- Do not store or use the monitor in locations exposed to heat, direct sunlight or extreme cold.
- In order to maintain the best performance of your monitor and use it for a longer lifetime, please use the monitor in a location that falls within the following temperature and humidity ranges.
  - Temperature: 0-40°C 32-104°F
  - · Humidity: 20-80% RH

## Important information for Burn-in/ Ghost image

- Always activate a moving screen saver program when you leave your monitor unattended. Always activate a periodic screen refresh application if your monitor will display unchanging static content. Uninterrupted display of still or static images over an extended period may cause "burn in", also known as "after-imaging" or "ghost imaging", on your screen.
- "Burn-in", "after-imaging", or "ghost imaging" is a well-known phenomenon in LCD panel technology. In most cases, the "burned in" or "after-imaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.

## Warning

Failure to activate a screen saver, or a periodic screen refresh application may result in severe "burn-in" or "afterimage" or "ghost image" symptoms that will not disappear and cannot be repaired. The damage mentioned above is not covered under your warranty.

### Service

- The casing cover should be opened only by qualified service personnel.
- If there is any need for any document for repair or integration, please contact with your local service center. (Please refer to Service contact information listed in Important information manual.)
- For transportation information, please refer to "Technical Specifications".
- Do not leave your monitor in a car/ trunk under direct sun light.

## Note

Consult a service technician if the monitor does not operate normally, or you are not sure what procedure to take when the operating instructions given in this manual have been followed.

## 1.2 Notational Descriptions

The following subsections describe notational conventions used in this document.

### Notes, Cautions and Warnings

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold or italic type. These blocks contain notes, cautions or warnings. They are used as follows:

## Note

This icon indicates important information and tips that help you make better use of your computer system.

## Caution

This icon indicates information that tells you how to avoid either potential damage to hardware or loss of data.

## Warning

This icon indicates the potential for bodily harm and tells you how to avoid the problem.

Some warnings may appear in alternate formats and may not be accompanied by an icon. In such cases, the specific presentation of the warning is mandated by the relevant regulatory authority.

# 1.3 Disposal of product and packing material

Waste Electrical and Electronic Equipment-WEEE



This marking on the product or on its packaging illustrates that, under European Directive 2012/19/EU governing used electrical and electronic appliances, this product may not be disposed of with normal household waste. You are responsible for disposal of this equipment through a designated waste electrical and electronic equipment collection. To determine the locations for dropping off such waste electrical and electronic, contact your local government office, the waste disposal organization that serves your household or the store at which you purchased the product.

Your new monitor contains materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount to be disposed of.

All redundant packing material has been omitted. We have done our utmost to make the packaging easily separable into mono materials.

Please find out about the local regulations on how to dispose of your old monitor and packing from your sales representative.

Taking back/Recycling Information for Customers

Philips establishes technically and economically viable objectives to optimize the environmental performance of the organization's product, service and activities.

From the planning, design and production stages, Philips emphasizes the important of making products that can easily be recycled. At Philips, end-of-life management primarily entails participation in national take-back initiatives and recycling programs whenever possible, preferably in cooperation with competitors, which recycle all materials (products and related packaging material) in accordance with all Environmental Laws and taking back program with the contractor company.

Your display is manufactured with high quality materials and components which can be recycled and reused.


To learn more about our recycling program please visit

http://www.philips.com/a-w/about/sustainability.html

## 2. Setting up the monitor

## 2.1 Installation

Package contents




\*Different according to region


- Install the base
- 1. Place the monitor face down on a smooth surface. Pay attention not to scratch or damage the screen.



- 2. Hold the stand with both hands.
  - (1) Gently attach the stand to the VESA mount area until the latch locks the stand.
  - (2) Gently attach the base to the stand.
  - (3) Use your fingers to tighten the screw located at the bottom of the base, and secure the base to the stand tightly.




Warnings



### Setting up the monitor


Connecting to your PC

## 2X1B7QPJEB:



- Mensington anti-theft lock
- 2 Audio input
- 3 Earphone jack
- 4 Display port input
- **5** HDMI input
- **6** VGA input
- **7** AC power input
- **8** Power Switch
- 9 USB upstream
- **(i)** USB fast charger/USB downstream

## 2X1B7QPJKEB:



- 1 Kensington anti-theft lock
- 2 Audio input
- 3 Earphone jack
- 4 Display port input
- **5** HDMI input
- **6** VGA input
- **7** AC power input
- 8 Power Switch
- **9** USB upstream
- **10** USB downstream
- 11 USB fast charger/USB downstream

### Connect to PC

- 1. Connect the power cord to the back of the monitor firmly.
- 2. Turn off your computer and unplug its power cable.
- Connect the monitor signal cable to the video connector on the back of your computer.
- Plug the power cord of your computer and your monitor into a nearby outlet.
- 5. Turn on your computer and monitor. If the monitor displays an image, installation is complete.


## Note


USB 2.4Ghz wireless devices, such as, wireless mouse, keyboard, and headphones, maybe have interference by the high-speed signal of USB 3.0 devices, which may result in a decreased efficiency of the radio transmission. Should this happen, please try the following methods to help reduce the effects of interference.

- Try to keep USB2.0 receivers away from USB3.0 connection port.
- Use a standard USB extension cable or USB hub to increase the space between your wireless receiver and the USB3.0 connection port.

## 2.2 Operating the monitor


1 Description of the control buttons 2X1B7QPJEB:





0	Ф	Switch monitor's power ON and OFF.
2	■/OK	Access the OSD menu. Confirm the OSD adjustment.
3	$\blacktriangle$	Adjust the OSD menu.
4	SENSOR	PowerSensor
6	€	Change the signal input source.
6	•	Return to previous OSD level.
7	町	SmartImage hot key. There are 7 modes to select: Office, Photo, Movie, Game, Economy, LowBlue Mode,Off.

### 2X1B7OPJKEB:



	,	8			
@/∢	⊕/▼	SENSOR/A	⊜/ок	Ф	
				1	
96	6	4	2	0	

0	Ф	Switch monitor's power ON and OFF.		
2	■/OK	Access the OSD menu. Confirm the OSD adjustment.		
3	$\blacksquare$	Adjust the OSD menu.		
4	SENSOR	PowerSensor		
6	•	Change the signal input source.		
6	4	Return to previous OSD level.		
7	SmartImage hot key. There are 7 modes to select:  Office, Photo, Movie, Game, Economy, LowBlue Mode,Off.			
8	Webcam activity light			
9	2.0 Megapixel Webcam			
10	Microphone			

2 Description of the On Screen Display

What is On-Screen Display (OSD)?

On-Screen Display (OSD) is a feature in all Philips LCD monitors. It allows an end user to adjust screen performance or select functions of the monitors directly through an on-screen instruction window. A user friendly on screen display interface is shown as below:




Basic and simple instruction on the control keys

In the OSD shown above, you can press 
▼ ▲ buttons at the front bezel of the monitor to move the cursor, and press 
OK button to confirm the choice or change.

### The OSD Menu

Below is an overall view of the structure of the On-Screen Display. You can use this as a reference when you want to work your way around the different adjustments later on.



### 3 Resolution notification


This monitor is designed for optimal performance at its native resolution, 1920 × 1080 @ 60 Hz. When the monitor is powered on at a different resolution, an alert is displayed on screen: Use 1920 × 1080 @ 60 Hz for best results.

Display of the native resolution alert can be switched off from Setup in the OSD


(On Screen Display) menu.

## Physical Function

Tilt



### Swivel




#### Setting up the monito

## Height adjustment




### Pivot




# 2.3 Remove the Base Assembly for VESA Mounting

Before you start disassembling the monitor base, please follow the instructions below to avoid any possible damage or injury.


1. Extend the monitor base to its maximum height.



 Place the monitor face down on a smooth surface. Pay attention not to scratch or damage the screen. Then lift the monitor stand.




While keeping the release button pressed, tilt the base and slide it out.



## 2. Setting up the monitor



This monitor accepts a 100mm x 100mm VESA-Compliant mounting interface. VESA Mounting Screw M4. Always contact manufacturer for wall-mount installation.



## 3. Image Optimization

## 3.1 SmartImage

### What is it?

SmartImage provides presets that optimize display for different types of content, dynamically adjusting brightness, contrast, color and sharpness in real time. Whether you're working with text applications, displaying images or watching a video, Philips SmartImage delivers great optimized monitor performance.


## 2 Why do I need it?

You want a monitor that delivers optimized display all your favorite types of content, SmartImage software dynamically adjust brightness, contrast, color and sharpness in real time to enhance your monitor viewing experience.

## 3 How does it work?

SmartImage is an exclusive, leading edge Philips technology that analyzes the content displayed on your screen. Based on a scenario you select, SmartImage dynamically enhances the contrast, color saturation and sharpness of images to enhance the contents being displayed - all in real time with the press of a single button.

4 How to enable SmartImage?



- 1. Press to launch the SmartImage on screen display.
- Keep pressing ▼ ▲ to toggle among Office, Photo, Movie, Game, Economy and Off.
- The SmartImage on screen display will remain on screen for 5 seconds, or you can also press "OK" to make confirmation.

There are seven modes to select: Office, Photo, Movie, Game, Economy, LowBlue Mode and Off.



 Office: Enhances text and dampens brightness to increase readability and reduce eye strain. This mode significantly enhances readability and productivity when you're working with spreadsheets. PDF

### Image Optimization

files, scanned articles or other general office applications.

- Photo: This profile combines color saturation, dynamic contrast and sharpness enhancement to display photos and other images with outstanding clarity in vibrant colors - all without artifacts and faded colors
- Movie: Ramped up luminance, deepened color saturation, dynamic contrast and razor sharpness displays every details in darker areas of your videos without color washout in brighter areas maintaining a dynamic natural values for the ultimate video display.
- Game: Turn on over drive circuit for best response time, reduce jaggy edges for fast moving objects on screen, enhance contrast ratio for bright and dark scheme, this profile delivers the best gaming experience for gamers.
- Economy: Under this profile, brightness, contrast are adjusted and backlighting finetuned for just right display of everyday office applications and lower power consumption.
- LowBlue Mode: LowBlue Mode for easy on-the-eyes productivity Studies have shown that just as ultra-violet rays can cause eye damage, shortwave length blue light rays from LED displays can cause eye damage and affect vision over time. Developed for wellbeing, Philips LowBlue Mode setting uses a smart software technology to reduce harmful shortwave blue light.
- Off: No optimization by SmartImage.

## Note

Philips LowBlue mode, mode 2 compliance with TUV Low Blue Light certification, you can have this mode by simply press the hotkey 7, then press to select LowBlue Mode, see above SmartImage selection steps.

### 3.2 SmartContrast

### 1 What is it?

Unique technology that dynamically analyzes displayed content and automatically optimizes a Monitor's contrast ratio for maximum visual clarity and viewing enjoyment, stepping up backlighting for clearer, crisper and brighter images or dimming backlighting for clear display of images on dark backgrounds.

## 2 Why do I need it?

You want the very best visual clarity and viewing comfort for every type of content. SmartContrast dynamically controls contrast and adjusts backlighting for clear, crisp, bright gaming and video images or displays clear, readable text for office work. By reducing your monitor's power consumption, you save on energy costs and extend the lifetime of your monitor.

### 3 How does it work?

When you activate SmartContrast, it will analyse the content you are displaying in real time to adjust colors and control backlight intensity. This function will dynamically enhance contrast for a great entertainment experience when viewing videos or playing games.


## 4. PowerSensor™

### How does it work?

- PowerSensor works on principle of transmission and reception of harmless "infrared" signals in order to detect user-presence.
- When the user is in front of the monitor, the monitor operates normally, at the predetermined settings that the user has set- i.e. brightness, contrast, color, etc
- Assuming that the monitor was set to 100% of brightness for example, when the user leaves his seat and is no longer in front of the monitor, the monitor automatically reduces the power consumption upto 80%.

## User present in front User not present





Power consumption as illustrated above is for reference purpose only

## 2 Setting

### Default settings

PowerSensor is designed to detect the presence of the user located between 30 and 100 cm (12 and 40 inches) from the display and within five degrees left or right of the monitor.


### Custom settings

If you prefer to be in a position outside the perimeters listed above, choose a higher strength signal for optimal detection efficiency: The higher the setting, the stronger the detection signal. For maximum PowerSensor efficiency and proper detection, please position yourself directly in front of your monitor.


 If you choose to position yourself more than 100 cm or 40 inches from the monitor use the maximum

- detection signal for distances up to 120 cm or 47 inches. (Setting 4)
- Since some dark colored clothing tends to absorb infrared signals even when the user is within 100 cm or 40 inches of the display, step up signal strength when wearing black or other dark clothes.


### Hot key



### Sensor distance



### Landscape/Portrait mode



Above illustrations are for reference purpose only, may not reflect the exact display of this model.

## 3 How to adjust settings

If PowerSensor is not operating correctly inside or outside the default range, here's how to fine-tune detection:

- Press the PowerSensor hot key.
- · You will find the adjustment bar.
- Adjust the PowerSensor detection adjustment to Setting 4 and press OK.
- Test the new setup to see if PowerSensor properly detects you in your current position.
- PowerSensor function is designed to work in Landscape mode (horizontal position) only. After PowerSensor turn on it, it will automatically turn Off if the monitor is used in Portrait mode (90 degree/vertical position); it will automatically turn ON if monitor is

### 4. PowerSensor™

returned to its default Landscape position.




A manually selected PowerSensor mode will remain operational unless and until it is readjusted or the default mode is recalled. If you find that the PowerSensor is excessively sensitive to nearby motion for some reason, please adjust to a lower signal strength. Keep sensor lens clean, if the sensor lens is dirty, wipe it with alcohol to avoid reducing of distance detection.

# 5. Built-in Webcam with Microphone

(Available for 2X1B7QPJKEB)

Note USB connection between the monitor and PC is required for the webcam to operate.

The webcam allows you to hold interactive video and audio conference calls over the internet. It provides the most convenient and easiest way for Business persons to communicate with other colleagues around the world, saving a lot time and money. Depending on the software used, it also allows you to take photos, share files or use microphone only without enabling webcam. The microphone and activity light are on the side of the webcam on the bezel of the display.




## 5.1 PC system requirements

- Operating system: Microsoft
  Windows 7, Microsoft Windows
  Vista, Microsoft Windows XP
  (SP2), and any other OS whichever
  support UVC/UAC (USB Video Class
  compliant / Audio Class compliant)
  under USB 2.0 standard
- Processor: 1.6GHz or above
- RAM: 512MB (for XP) / 1GB(for Vista and Windows7)
- Hard disk space: minimum 200MB
- USB: USB 2.0 or above, UVC/UAC support

## 5.2 Using the device

Philips monitor with webcam device transmits video and sound data through USB port. It can be enabled by simply connecting your USB cable from your PC to the USB upstream of USB hub on the side IO of monitor.



- Connect your USB cable to upstream of USB hub on the side IO of monitor from PC side.
- Turn on your PC and make sure your internet connection is working properly.
- Download and enable free online chatting software such as Skype, Internet Messenger, or equivalent. You can also subscribe to dedicated software in case of more sophisticated usage like multi conferencing, etc.
- The webcam is ready to be used for chat or make the phone call through internet service.
- Make the call by following the instruction of the software program.

## Note

To set up a video call, you must have a reliable Internet connection, an ISP, and software like Internet messenger or video phone call program. Make sure the person that you are calling has compatible video-calling software. The video and audio performance quality depends on the bandwidth available on both ends. The person you are calling must have similar capability of devices and software.

## 6. Technical Specifications

Picture/Display			
Monitor Panel Type	IPS Technology		
Backlight	LED		
Panel Size	221B7: 21.5" W (54.6 cm) 231B7: 23" W (58.4 cm)		
Aspect Ratio	16:9		
Pixel Pitch	221B7: 0.248(H) mm x 0.248(V) mm 231B7: 0.265(H) mm x 0.265(V) mm		
Contrast Ratio (typ.)	1,000:1		
Optimum Resolution	1920 x 1080 @ 60 Hz		
Viewing Angle	178° (H) / 178° (V) @ C/R > 10		
Display Colors	16.7 M		
Flicker Free	Yes		
Picture Enhancement	SmartImage		
Vertical Refresh Rate	50 Hz - 76 Hz		
Horizontal Frequency	30 kHz - 83 kHz		
sRGB	YES		
LowBlue Mode	YES		
Connectivity			
Signal Input/Output	VGA( Analog), HDMI 1.4(Digital), DisplayPort 1.2		
USB	USB 3.0×3 includes 1 fast charger(2X1B7QPJKEB) USB 3.0×2 includes 1 fast charger(2X1B7QPJEB)		
Input Signal	Separate Sync, Sync on Green		
Audio In/Out	PC audio-in,headphone out		
Convenience			
Built-in speaker	2 W x 2		
Built-in webcam	2.0 megapixel camera with Microphone and LED indicator(2X1B7QPJKEB)		
User Convenience	©7/◀ ⊕/▼ SENSOR/▲ ■/OK Ů		
OSD Languages	English, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, Korean		
Other Convenience	VESA mount(100×100mm), Kensington Lock		
Plug & Play Compatibility DDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS			
Stand			
Tilt	-5 / +20 degree		
Swivel	-175 / +175 degree		
Height adjustment	130mm		
Pivot	90 degree		

Power (221B7)				
Consumption	AC Input Voltage at 100VAC , 60Hz	AC Input Voltage at 115VAC , 60Hz	AC Input Voltage at 230VAC, 50Hz	
Normal Operation	17.9W (typ.)	17.8W (typ.)	17.7W (typ.)	
Sleep (Standby)	<0.3W	<0.3W	<0.3W	
Off	<0.3W	<0.3W	<0.3W	
Off (AC switch)	O W	O W	O W	
Heat Dissipation*	AC Input Voltage at 100VAC , 60Hz	AC Input Voltage at 115VAC , 60Hz	AC Input Voltage at 230VAC, 50Hz	
Normal Operation	61.2 BTU/hr (typ.)	60.8 BTU/hr (typ.)	60.3 BTU/hr (typ.)	
Sleep (Standby)	<1.02 BTU/hr <1.02 BTU/hr <1.02 BTU/hr			
Off	<1.02 BTU/hr <1.02 BTU/hr <1.02 BTU/hr			
Off (AC switch)	O BTU/hr O BTU/hr O BTU/hr			
On Mode(ECO mode)	10.7W (typ.)			
PowerSensor	3.6W (typ.)			
Power LED indicator	On mode: White, Standby/Sleep mode: White (blinking)			
Power Supply	Built-in, 100-240V AC, 50-60Hz			
Power(231B7)				
Consumption	AC Input AC Input AC Input			

Power(231B7)					
Consumption	AC Input Voltage at 100VAC , 60Hz	AC Input Voltage at 115VAC , 60Hz	AC Input Voltage at 230VAC, 50Hz		
Normal Operation	18.95W (typ.)	18.80W (typ.)	19.61W (typ.)		
Sleep (Standby)	<0.3W	<0.3W	<0.3W		
Off	<0.3W	<0.3W	<0.3W		
Off (AC switch)	OW OW OV		O W		
Heat Dissipation*	AC Input AC Input AC Input Voltage at Voltage at 100VAC, 60Hz 115VAC, 60Hz 230VAC, 50Hz				
Normal Operation	64.68 BTU/hr (typ.)	64.17 BTU/hr (typ.)	66.92 BTU/hr (typ.)		
Sleep (Standby)	<1.02 BTU/hr	<1.02 BTU/hr	<1.02 BTU/hr		
Off	<1.02 BTU/hr	<1.02 BTU/hr	<1.02 BTU/hr		
Off (AC switch)	O BTU/hr O BTU/hr O BTU/hr				
On Mode(ECO mode)	11.4W (typ.)				
PowerSensor	3.9W (typ.)				
Power LED indicator	Power LED indicator  On mode: White, Standby/Sleep mode: White (blinking)				
Power Supply	Built-in, 100-240V AC, 50-60Hz				

Dimensions           Product with stand (WxHxD)         490 x 473 x 220 mm (221B7) 523 x 486 x 220 mm (231B7)           Product without stand (WxHxD)         490 x 302 x 52 mm (231B7)           Product with packaging (WxHxD)         552 x 464 x 187 mm (221B7) 585 x 482 x 187 mm (231B7)           Product with stand         5.075 kg (221B7) 5.330 kg (231B7)           Product without stand         2.980 kg (221B7) 3.235 kg (231B7)           Product with packaging         7.047 kg (221B7) 7.447 kg (231B7)           Operating Condition         7.047 kg (221B7) 7.447 kg (231B7)           Operating Condition         20% to 80%           Relative humidity (operation)         20% to 80%           Atmospheric pressure (operation)         700 to 1060hPa           Temperature range (Non-operation)         -20°C to 60°C           Relative humidity (Non-operation)         10% to 90%           Atmospheric pressure (Non-operation)         500 to 1060hPa           Environmental and energy ROHS         YES           EPEAT         YES (Refer to note 1 for more details)
(WxHxD)         523 x 486 x 220 mm (231B7)           Product without stand (WxHxD)         490 x 302 x 52 mm (231B7)           Product with packaging (WxHxD)         552 x 464 x 187 mm (221B7)           Froduct with packaging (WxHxD)         552 x 464 x 187 mm (231B7)           Weight         85 x 482 x 187 mm (231B7)           Product with stand         5.075 kg (221B7)           5.330 kg (231B7)         2.980 kg (221B7)           3.235 kg (231B7)         7.047 kg (221B7)           7.447 kg (231B7)         7.447 kg (231B7)           Operating Condition           Temperature range (operation)         0°C to 40 °C           Relative humidity (operation)         20% to 80%           Atmospheric pressure (operation)         700 to 1060hPa           Temperature range (Non-operation)         -20°C to 60°C           Relative humidity (Non-operation)         10% to 90%           Atmospheric pressure (Non-operation)         500 to 1060hPa           Environmental and energy ROHS         YES
Product without stand (WxHxD)  Product with packaging (WxHxD)  Product with packaging (WxHxD)  S52 x 464 x 187 mm (221B7) (S55 x 482 x 187 mm (231B7)  Product with stand  Product with stand  Froduct without stand  Product with packaging  Product with stand  Product with
(WXHXD)         523 x 320 x 52 mm (231B7)           Product with packaging (WXHXD)         552 x 464 x 187 mm (221B7)           585 x 482 x 187 mm (231B7)           Weight         5.075 kg (221B7)           Product with stand         2.980 kg (221B7)           3.235 kg (231B7)           Product with packaging         7.047 kg (221B7)           7.447 kg (231B7)           Operating Condition           Temperature range (operation)         0°C to 40 °C           Relative humidity (operation)         20% to 80%           Atmospheric pressure (operation)         700 to 1060hPa           Temperature range (Non-operation)         -20°C to 60°C           Relative humidity (Non-operation)         10% to 90%           Atmospheric pressure (Non-operation)         500 to 1060hPa           Environmental and energy         FNON to 1060hPa
Product with packaging (WxHxD)  Weight  Product with stand  Product without stand  Product with packaging  Product without stand  Product with packaging  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with stand  Product with stand  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with stand  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with stand  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with packaging  Product with stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Product with packaging  Product with packaging  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  Produc
Weight  Product with stand  5.075 kg (221B7) 5.330 kg (231B7)  Product without stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  7.047 kg (221B7) 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)
WeightProduct with stand5.075 kg (221B7) 5.330 kg (231B7)Product without stand2.980 kg (221B7) 3.235 kg (231B7)Product with packaging7.047 kg (221B7) 7.447 kg (231B7)Operating ConditionTemperature range (operation)0°C to 40 °CRelative humidity (operation)20% to 80%Atmospheric pressure (operation)700 to 1060hPaTemperature range (Non-operation)-20°C to 60°CRelative humidity (Non-operation)10% to 90%Atmospheric pressure (Non-operation)500 to 1060hPaEnvironmental and energy ROHSYES
Product with stand  5.075 kg (221B7) 5.330 kg (231B7)  Product without stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  7.047 kg (221B7) 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Temperature range (Non-operation)  Tomperature range (Non-operation)  Atmospheric pressure (Non-operation)  Fivironmental and energy  ROHS  YES
Product with stand  5.330 kg (231B7)  2.980 kg (221B7) 3.235 kg (231B7)  7.047 kg (221B7) 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (10% to 90%)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  5.330 kg (231B7)  2.980 kg (221B7) 3.235 kg (231B7)  7.047 kg (221B7) 7.447 kg (231B7)  2.980 kg (221B7) 3.235 kg (231B7)  7.047 kg (221B7) 7.447 kg (231B7)  2.980 kg (221B7) 3.235 kg (231B7)  7.047 kg (221B7) 7.447 kg (231B7)  2.980 kg (221B7) 3.235 kg (231B7)  7.047 kg (221B7) 7.447 kg (231B7)  2.980 kg (221B7) 2.980 kg (231B7)  2.980 kg (221B7) 2.980 kg (231B7) 2.980 kg (221B7) 2.980 kg (21B7)
Product without stand  2.980 kg (221B7) 3.235 kg (231B7)  Product with packaging  7.047 kg (221B7) 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  YES
Product without stand  3.235 kg (231B7)  7.047 kg (221B7) 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Relative humidity (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Furironmental and energy  ROHS  YES
Product with packaging  7.047 kg (221B7) 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Temperature range (Non-operation)
Product with packaging 7.447 kg (231B7)  Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  7.447 kg (231B7)  7.447 kg (231B7)  0°C to 40°C  20% to 80%  700 to 1060hPa  500 to 1060hPa
Operating Condition  Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  YES
Temperature range (operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  O°C to 40 °C  20% to 80%  20% to 1060hPa  700 to 1060hPa  10% to 90%  500 to 1060hPa
(operation)  Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  YES
Relative humidity (operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  20% to 80%  700 to 1060hPa  700 to 1060hPa  10% to 90%  500 to 1060hPa
(operation)  Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  20% to 80%  700 to 1060hPa  -20°C to 60°C  10% to 90%  500 to 1060hPa
Atmospheric pressure (operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  700 to 1060hPa  -20°C to 60°C  10% to 90%  500 to 1060hPa
(operation)  Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  700 to 1060hPa  -20°C to 60°C  10% to 90%  500 to 1060hPa
Temperature range (Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  Temperature range -20°C to 60°C  10% to 90%  10% to 90%  500 to 1060hPa
(Non-operation)  Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  PO C to 60 C  10% to 90%  10% to 90%  500 to 1060hPa  YES
Relative humidity (Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  10% to 90%  500 to 1060hPa
(Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  10% to 90%  500 to 1060hPa
(Non-operation)  Atmospheric pressure (Non-operation)  Environmental and energy  ROHS  YES
(Non-operation)  Environmental and energy  ROHS  YES
(Non-operation)  Environmental and energy  ROHS  YES
ROHS YES
1.2
FDEAT VEC (Defer to make 1 for make a lateila)
EPEAT YES (Refer to note 1 for more details)
Packaging 100% recyclable
Specific Substances 100% PVC BFR free housing
EnergyStar YES
Compliance and standards
CE Mark, FCC Class B, SEMKO, cETLus, CU-EAC,
TCO Certified EDGE,TUV-GS,TUV-ERGO, EPA, WEEE,
Regulatory Approvals UKRAINIAN,ICES-003,SASO,KUCAS
* This product regulation compliance respectively
relates to the sales area.
Cabinet
Color Black
Finish Texture

### 6 Technical Specifications



- EPEAT rating is valid only where Philips registers the product. Please visit <u>www.epeat.net</u> for registration status in your country.
- This data is subject to change without notice. Go to <u>www.philips.</u> <u>com/support</u> to download the latest version of leaflet.
- 3. USB hub is only support mouse or keyboard to wake up the system while on power saving mode.

## 6.1 Resolution & Preset Modes

Maximum Resolution 1920 x 1080 @ 60 Hz (analog input) 1920 x 1080 @ 60 Hz (digital input)

2 Recommended Resolution 1920 x 1080 @ 60 Hz (digital input)

H. freq (kHz)	Resolution	V. freq (Hz)
31.47	720 x 400	70.09
31.47	640 x 480	59.94
35.00	640 x 480	66.67
37.86	640 x 480	72.81
37.50	640 x 480	75.00
35.16	800 x 600	56.25
37.88	800 x 600	60.32
46.88	800 x 600	75.00
48.08	800 x 600	72.19
47.73	832 x 624	74.55
48.36	1024 x 768	60.00
56.48	1024 x 768	70.07
60.02	1024 x 768	75.03
44.77	1280 x 720	59.86
60	1280 x 960	60
63.89	1280 x 1024	60.02
79.98	1280 x 1024	75.03
55.94	1440 x 900	59.89
65.29	1680 x 1050	59.95
67.50	1920 x 1080	60.00

## ♠ Note

Please notice that your display works best at native resolution of 1920 x 1080 @ 60Hz. For best display quality,please follow this resolution recommendation.

## Power Management

If you have VESA DPM compliance display card or software installed in your PC, the monitor can automatically reduce its power consumption when not in use. If an input from a keyboard, mouse or other input device is detected, the monitor will 'wake up' automatically. The following table shows the power consumption and signaling of this automatic power saving feature:

### 221B7

Power Management Definition								
VESA Mode	Video	H-sync	V-sync	Power Used	LED Color			
Active	ON	Yes	Yes	17.9W (typ.) 48W (max.)	White			
Sleep (Standby)	OFF	No	No	0.3W (typ.)	White (blink)			
Switch Off	OFF	-	-	OW (typ.)	OFF			

#### 231B7

Power Management Definition							
VESA Mode	Video	H-sync	V-sync	Power Used	LED Color		
Active	ON	Yes	Yes	19.6W (typ.) 60W (max.)	White		
Sleep (Standby)	OFF	No	No	0.3W (typ.)	White (blink)		
Switch Off	OFF	-	-	OW (typ.)	OFF		

The following setup is used to measure power consumption on this monitor.

Native resolution: 1920 × 1080

Contrast: 50%

- Brightness: 100%
- Color temperature: 6500k with full white pattern




### ♠ Note

This data is subject to change without notice.

# 8. Customer care and warranty

## 8.1 Philips' Flat Panel Monitors Pixel Defect Policy

Philips strives to deliver the highest quality products. We use some of the industry's most advanced manufacturing processes and practice stringent quality control. However, pixel or sub pixel defects on the TFT Monitor panels used in flat panel monitors are sometimes unavoidable. No manufacturer can guarantee that all panels will be free from pixel defects, but Philips guarantees that any monitor with an unacceptable number of defects will be repaired or replaced under warranty. This notice explains the different types of pixel defects and defines acceptable defect levels for each type. In order to qualify for repair or replacement under warranty, the number of pixel defects on a TFT Monitor panel must exceed these acceptable levels. For example. no more than 0.0004% of the subpixels on a monitor may be defective. Furthermore, Philips sets even higher quality standards for certain types or combinations of pixel defects that are more noticeable than others. This policy is valid worldwide.



### Pixels and Sub pixels

A pixel, or picture element, is composed of three sub pixels in the primary colors


of red, green and blue. Many pixels together form an image. When all sub pixels of a pixel are lit, the three colored sub pixels together appear as a single white pixel. When all are dark, the three colored sub pixels together appear as a single black pixel. Other combinations of lit and dark sub pixels appear as single pixels of other colors.

## Types of Pixel Defects


Pixel and sub pixel defects appear on the screen in different ways. There are two categories of pixel defects and several types of sub pixel defects within each category.

## **Bright Dot Defects**

Bright dot defects appear as pixels or sub pixels that are always lit or 'on'. That is, a bright dot is a sub-pixel that stands out on the screen when the monitor displays a dark pattern. There are the types of bright dot defects.



One lit red, green or blue sub pixel.



### Two adjacent lit sub pixels:

- Red + Blue = Purple
- Red + Green = Yellow
- Green + Blue = Cyan (Light Blue)

### 8.Customer care and warranty



Three adjacent lit sub pixels (one white pixel).

## **⊜** Note

A red or blue bright dot must be more than 50 percent brighter than neighboring dots while a green bright dot is 30 percent brighter than neighboring dots.


### **Black Dot Defects**

Black dot defects appear as pixels or sub pixels that are always dark or 'off'. That is, a dark dot is a sub-pixel that stands out on the screen when the monitor displays a light pattern. These are the types of black dot defects.



## **Proximity of Pixel Defects**

Because pixel and sub pixels defects of the same type that are near to one another may be more noticeable, Philips also specifies tolerances for the proximity of pixel defects.



### 8.Customer care and warranty

### Pixel Defect Tolerances

In order to qualify for repair or replacement due to pixel defects during the warranty period, a TFT Monitor panel in a Philips flat panel monitor must have pixel or sub pixel defects exceeding the tolerances listed in the following tables.

BRIGHT DOT DEFECTS	ACCEPTABLE LEVEL
1 lit subpixel	3
2 adjacent lit subpixels	1
3 adjacent lit subpixels (one white pixel)	0
Distance between two bright dot defects*	>15mm
Total bright dot defects of all types	3
BLACK DOT DEFECTS	ACCEPTABLE LEVEL
1 dark subpixel	5 or fewer
2 adjacent dark subpixels	2 or fewer
3 adjacent dark subpixels	0
Distance between two black dot defects*	>15mm
Total black dot defects of all types	5 or fewer
TOTAL DOT DEFECTS	ACCEPTABLE LEVEL
Total bright or black dot defects of all types	5 or fewer



1 or 2 adjacent sub pixel defects = 1 dot defect.

## 8.2 Customer Care & Warranty

For warranty coverage information and additional support requirements valid for your region, please visit www.philips.com/support website for details or contact your local Philips Customer Care Center.

For extended warranty, if you would like to extend your general warranty period, an Out of Warranty service package is offered via our Certified Service Center.

For Warranty Period please refer to Warranty Statement in Important Information Manual.

If you wish to make use of this service, please be sure to purchase the service within 30 calendar days of your original purchase date. During the extended warranty period, the service includes pickup, repair and return service, however the user will be responsible for all costs accrued.

If the Certified Service Partner cannot perform the required repairs under the offered extended warranty package, we will find alternative solutions for you, if possible, up to the extended warranty period you have purchased.

Please contact our Philips Customer Service Representative or local contact center (by Consumer care number) for more details.

Philips Customer Care Center number listed below.

•	Local Standard		Extended Warranty	•	Total Warranty Period
	Warranty Period		Period		
•	Depend on	•	+ 1 Year	•	Local Standard warranty period
	different Regions				+1
			+ 2 Years		Local Standard warranty period
					+2
			+ 3 Years	•	Local Standard warranty period
					+3

<sup>\*\*</sup>Proof of original purchase and extended warranty purchase required.

## Note

- 1. Please refer to important information manual for regional service hotline, which is available on the Philips website support page.
- 2. Spare parts are available for use in the repair of the product for minimum threeyear from your original purchase date or 1 year after the end of production, whichever is longer.

# Troubleshooting & FAOs

## 9.1 Troubleshooting

This page deals with problems that can be corrected by a user. If the problem still persists after you have tried these solutions, contact Philips customer service representative.

## 1 Common Problems

### No Picture (Power LED not lit)

- Make sure the power cord is plugged into the power outlet and into the back of the monitor.
- First, ensure that the power button on the front of the monitor is in the OFF position, then press it to the ON position.

### No Picture (Power LED is White)

- Make sure the computer is turned on.
- Make sure the signal cable is properly connected to your computer.
- Make sure the monitor cable has no bent pins on the connect side. If yes, repair or replace the cable.
- The Energy Saving feature may be activated

### Screen says



 Make sure the monitor cable is properly connected to your computer. (Also refer to the Quick Start Guide).

- Check to see if the monitor cable has bent pins.
- Make sure the computer is turned on

### AUTO button doesn't function

 The auto function is applicable only in VGA-Analog mode. If the result is not satisfactory, you can do manual adjustments via the OSD menu.



The Auto Function is not applicable in DVI-Digital mode as it is not necessary.

### Visible signs of smoke or sparks

- Do not perform any troubleshooting steps
- Disconnect the monitor from mains power source immediately for safety
- Contact with Philips customer service representative immediately.

## 2 Imaging Problems

### Image is not centered

- Adjust the image position using the "Auto" function in OSD Main Controls.
- Adjust the image position using the Phase/Clock of Setup in OSD Main Controls. It is valid only in VGA mode

### Image vibrates on the screen

 Check that the signal cable is properly securely connected to the graphics board or PC.

## Vertical flicker appears



- Adjust the image using the "Auto" function in OSD Main Controls.
- Eliminate the vertical bars using the Phase/Clock of Setup in OSD

Main Controls. It is valid only in VGA mode.

## Horizontal flicker appears



- Adjust the image using the "Auto" function in OSD Main Controls.
- Eliminate the vertical bars using the Phase/Clock of Setup in OSD Main Controls. It is valid only in VGA mode.

## Image appears blurred, indistinct or too dark

 Adjust the contrast and brightness on On-Screen Display.

# An "after-image", "burn-in" or "ghost image" remains after the power has been turned off.

- Uninterrupted display of still or static images over an extended period may cause "burn in", also known as "after-imaging" or "ghost imaging", on your screen. "Burn-in", "after-imaging", or "ghost imaging" is a well-known phenomenon in LCD panel technology. In most cases, the "burned in" or "after-imaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.
- Always activate a moving screen saver program when you leave your monitor unattended.
- Always activate a periodic screen refresh application if your LCD monitor will display unchanging static content.
- Failure to activate a screen saver, or a periodic screen refresh application may result in severe "burn-in" or "after-image" or "ghost image" symptoms that will not disappear

and cannot be repaired. The damage mentioned above is not covered under your warranty.

## Image appears distorted. Text is fuzzy or blurred.

 Set the PC's display resolution to the same mode as monitor's recommended screen native resolution.

## Green, red, blue, dark, and white dots appears on the screen

- The remaining dots are normal characteristic of the liquid crystal used in today's technology, Please refer the pixel policy for more detail.
- \* The "power on" light is too strong and is disturbing
- You can adjust "power on" light using the power LED Setup in OSD main Controls

For further assistance, refer to the Service contact information listed in Important information manual and contact Philips customer service representative.

\* Functionality different according to display.

## 9.2 General FAQs

Q1: When I install my monitor what should I do if the screen shows 'Cannot display this video mode'?

Ans.: Recommended resolution for this monitor: 1920 x 1080 @ 60 Hz.

- Unplug all cables, then connect your PC to the monitor that you used previously.
- In the Windows Start Menu, select Settings/Control Panel. In the Control Panel Window, select the Display icon. Inside the Display Control Panel, select the 'Settings' tab. Under the setting tab, in box labelled 'desktop area', move the sidebar to 1920 x 1080 pixels.
- Open 'Advanced Properties' and set the Refresh Rate to 60 Hz, then click OK.
- Restart your computer and repeat step 2 and 3 to verify that your PC is set at 1920 x 1080 @ 60 Hz.
- Shut down your computer, disconnect your old monitor and reconnect your Philips LCD monitor.
- Turn on your monitor and then turn on your PC.

Q2: What is the recommended refresh rate for LCD monitor?

Ans.: Recommended refresh rate in LCD monitors is 60 Hz, In case of any disturbance on screen, you can set it up to 75 Hz to see if that removes the disturbance.

Q3: What are the .inf and .icm files on the CD-ROM? How do I install the drivers (.inf and .icm)?

Ans.: These are the driver files for your monitor. Follow the instructions in your user manual to install the drivers. Your computer may ask

you for monitor drivers (.inf and .icm files) or a driver disk when you first install your monitor. Follow the instructions to insert the companion CD-ROM included in this package. Monitor drivers (.inf and .icm files) will be installed automatically.

Q4: How do I adjust the resolution?

Ans.: Your video card/graphic driver and monitor together determine the available resolutions. You can select the desired resolution under Windows® Control Panel with the "Display properties".

Q5: What if I get lost when I am making monitor adjustments via OSD?

Ans.: Simply press the OK button, then select 'Reset' to recall all of the original factory settings.

Q6: Is the LCD screen resistant to scratches?

Ans.: In general it is recommended that the panel surface is not subjected to excessive shocks and is protected from sharp or blunt objects. When handling the monitor, make sure that there is no pressure or force applied to the panel surface side. This may affect your warranty conditions.

Q7: How should I clean the LCD surface?

Ans.: For normal cleaning, use a clean, soft cloth. For extensive cleaning, please use isopropyl alcohol. Do not use other solvents such as ethyl alcohol, ethanol, acetone, hexane, etc.

Q8: Can I change the color setting of my monitor?

### 9.Troubleshooting & FAQs

Ans.: Yes, you can change your color setting through OSD control as the following procedures,

- Press "OK" to show the OSD (On Screen Display) menu
- Press "Down Arrow" to select the option "Color" then press "OK" to enter color setting, there are three settings as below.
  - 1. Color Temperature: The six settings are 5000K, 6500K, 7500K, 8200K, 9300K and 11500K. With settings in the 5000K range the panel appears "warm, with a red-white color tone", while a 11500K temperature yields "cool, bluewhite toning".
  - 2. sRGB: This is a standard setting for ensuring correct exchange of colors between different device (e.g. digital cameras, monitors, printers, scanners, etc).
  - 3. User Define: The user can choose his/her preference color setting by adjusting red, green blue color.

## Note

A measurement of the color of light radiated by an object while it is being heated. This measurement is expressed in terms of absolute scale, (degrees Kelvin). Lower Kevin temperatures such as 2004K are red; higher temperatures such as 9300K are blue. Neutral temperature is white, at 6504K.

Q9: Can I connect my LCD monitor to any PC, workstation or Mac?

Ans.: Yes. All Philips LCD monitors are fully compatible with standard PCs, Macs and workstations. You may need a cable adapter to connect the monitor to your Mac system. Please contact your

Philips sales representative for more information.

Q10: Are Philips LCD monitors Plugand- Play?

Ans.: Yes, the monitors are Plug-and-Play compatible with Windows 10/8.1/8/7, Mac OSX

Q11: What is Image Sticking, or Image Burn-in, or After Image, or Ghost Image in LCD panels?

Ans.: Uninterrupted display of still or static images over an extended period may cause "burn in", also known as "after-imaging" or "ghost imaging", on your screen. "Burn-in", "after-imaging", or "ghost imaging" is a well-known phenomenon in LCD panel technology. In most cases, the "burned in" or "atter-imaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.

Always activate a moving screen saver program when you leave your monitor unattended.
Always activate a periodic screen refresh application if your LCD monitor will display unchanging static content.

## Warning

Failure to activate a screen saver, or a periodic screen refresh application may result in severe "burn-in" or "afterimage" or "ghost image" symptoms that will not disappear and cannot be repaired. The damage mentioned above is not covered under your warranty.


Q12: Why is my Display not showing sharp text, and is displaying jagged characters?

### 9.Troubleshooting & FAQs

Ans.: Your LCD monitor works best at its native resolution of 1920 x 1080 @ 60 Hz. For best display, please use this resolution.

Q13: How to unlock/lock my hot key?

Ans.: Please press **/OK** for 10 seconds to unlock/lock the hot key, by doing so, your monitor pops out "Attention" to show the unlock/lock status as shown below illustrators.



Q14: Where can I find Important Information manual mentioned in EDFU?

Ans.: Important Information manual can be download on the Philips website support page.



2019 © TOP Victory Investment Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

Version: M72X1BE1L