

Brilliance

240B7

ΕN



Table of Contents

1.	Important11.1Safety precautions and maintenance11.2Notational Descriptions31.3Disposal of product and packing material4
2.	Setting up the monitor
3.	Image Optimization123.1SmartImage123.2SmartContrast13
4.	PowerSensor™14
5.	Daisy-chain function16
6.	Technical Specifications
7.	Power Management22
8.	Customer care and warranty . 23 8.1 Philips' Flat Panel Monitors Pixel Defect Policy23 8.2 Customer Care & Warranty26
9.	Troubleshooting & FAQs 27 9.1 Troubleshooting

1. Important

This electronic user's guide is intended for anyone who uses the Philips monitor. Take time to read this user manual before you use your monitor. It contains important information and notes regarding operating your monitor.

The Philips guarantee applies provided the product is handled properly for its intended use, in accordance with its operating instructions and upon presentation of the original invoice or cash receipt, indicating the date of purchase, dealer's name and model and production number of the product.

1.1 Safety precautions and maintenance

Warnings

Use of controls, adjustments or procedures other than those specified in this documentation may result in exposure to shock, electrical hazards and/or mechanical hazards.

Read and follow these instructions when connecting and using your computer monitor.

Excessive sound pressure from earphones and headphones can cause hearing loss. Adjustment of the

equalizer to maximum increases the earphones and headphones output voltage and therefore the sound

pressure level.

Operation

 Please Keep the monitor out of direct sunlight, very strong bright lights and away from any other heat source. Lengthy exposure to this type of environment may result in discoloration and damage to the monitor.

- Keep the display away from oil. Oil may damage the plastic cover of the display and void the warranty.
- Remove any object that could fall into ventilation holes or prevent proper cooling of the monitor's electronics.
- Do not block the ventilation holes on the cabinet.
- When positioning the monitor, make sure the power plug and outlet are easily accessible.
- If turning off the monitor by detaching the power cable or DC power cord, wait for 6 seconds before attaching the power cable or DC power cord for normal operation.
- Please use approved power cord provided by Philips all the time. If your power cord is missing, please contact with your local service center. (Please refer to Service contact information listed in Important information manual.)
- Operate under the specified power supply. Be sure to operate the monitor only with the specified power supply. Use of an incorrect voltage will cause malfunction and may cause fire or electric shock.
- Protect the cable. Do not pull or bend the power cable and signal cable. Do not place the monitor or any other heavy objects on the cables, if damaged, the cables may cause fire or electric shock.
- Do not subject the monitor to severe vibration or high impact conditions during operation.
- To avoid potential damage, for example the panel peeling from the bezel, ensure that the monitor does not tilt downward by more than -5 degrees. If the -5 degree downward tilt angle maximum is exceeded, the

Important

monitor damage will not be covered under warranty.

- Do not knock or drop the monitor during operation or transportation.
- Excessive usage of monitor can cause eye discomfort, it's better to take shorter breaks more often at your workstation than longer breaks and less often; for example a 5-10 minute break after 50-60-minute continuous screen use is likely to be better than a 15-minute break every two hours. Try to keep your eyes from eye strain while using the screen for a constant period of time by :
 - Looking at something varying distances after a long period focusing on the screen.
 - Conscious Blinking often while you work.
 - Gently closing and rolling your eyes to relax.
 - Reposition your screen to appropriate height and angle according to your height.
 - Adjusting the brightness and contrast to appropriate level.
 - Adjusting the environment lighting similar to that of your screen brightness, avoid the fluorescent lighting, and surfaces that don't reflect too much light.
 - Seeing a doctor if your symptoms.

Maintenance

To protect your monitor from possible damage, do not put excessive pressure on the LCD panel. When moving your monitor, grasp the frame to lift; do not lift the monitor by placing your hand or fingers on the LCD panel.

- Oil-based cleaning solutions may damage the plastic parts and void the warranty.
- Unplug the monitor if you are not going to use it for an extensive period of time.
- Unplug the monitor if you need to clean it with a slightly damp cloth. The screen may be wiped with a dry cloth when the power is off. However, never use organic solvent, such as, alcohol, or ammonia-based liquids to clean your monitor.
- To avoid the risk of shock or permanent damage to the set, do not expose the monitor to dust, rain, water, or excessive moisture environment.
- If your monitor gets wet, wipe it with dry cloth as soon as possible.
- If foreign substance or water gets in your monitor, please turn the power off immediately and disconnect the power cord. Then, remove the foreign substance or water, and send it to the maintenance center.
- Do not store or use the monitor in locations exposed to heat, direct sunlight or extreme cold.
- In order to maintain the best performance of your monitor and use it for a longer lifetime, please use the monitor in a location that falls within the following temperature and humidity ranges.
 - Temperature: 0-40°C 32-104°F
 - Humidity: 20-80% RH

Important information for Burn-in/ Ghost image

 Always activate a moving screen saver program when you leave your monitor unattended. Always activate a periodic screen refresh application if your monitor will display unchanging static content.

Important

Uninterrupted display of still or static images over an extended period may cause "burn-in", also known as "after-imaging" or "ghost imaging", on your screen.

"Burn-in", "after-imaging", or "ghost imaging" is a well-known phenomenon in LCD panel technology. In most cases, the "burn-in" or "after-imaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.

Warning

Failure to activate a screen saver, or a periodic screen refresh application may result in severe "burn-in" or "afterimage" or "ghost image" symptoms that will not disappear and cannot be repaired. The damage mentioned above is not covered under your warranty.

Service

- The casing cover should be opened only by qualified service personnel.
- If there is any need for any document for repair or integration, please contact with your local service center. (Please refer to Service contact information listed in Important information manual.)
- For transportation information, please refer to "Technical Specifications".
- Do not leave your monitor in a car/ trunk under direct sun light.

Note

Consult a service technician if the monitor does not operate normally, or you are not sure what procedure to take when the operating instructions given in this manual have been followed.

1.2 Notational Descriptions

The following subsections describe notational conventions used in this document.

Notes, Cautions and Warnings

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold or italic type. These blocks contain notes, cautions or warnings. They are used as follows:

Note

This icon indicates important information and tips that help you make better use of your computer system.

Caution

This icon indicates information that tells you how to avoid either potential damage to hardware or loss of data.

Warning

This icon indicates the potential for bodily harm and tells you how to avoid the problem.

Some warnings may appear in alternate formats and may not be accompanied by an icon. In such cases, the specific presentation of the warning is mandated by the relevant regulatory authority.

1.3 Disposal of product and packing material

Waste Electrical and Electronic Equipment-WEEE



This marking on the product or on its packaging illustrates that, under European Directive 2012/19/EU governing used electrical and electronic appliances, this product may not be disposed of with normal household waste. You are responsible for disposal of this equipment through a designated waste electrical and electronic equipment collection. To determine the locations for dropping off such waste electrical and electronic, contact your local government office. the waste disposal organization that serves your household or the store at which you purchased the product.

Your new monitor contains materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount to be disposed of.

All redundant packing material has been omitted. We have done our utmost to make the packaging easily separable into mono materials.

Please find out about the local regulations on how to dispose of your old monitor and packing from your sales representative. Taking back/Recycling Information for Customers

Philips establishes technically and economically viable objectives to optimize the environmental performance of the organization's product, service and activities.

From the planning, design and production stages, Philips emphasizes the important of making products that can easily be recycled. At Philips, endof-life management primarily entails participation in national take-back initiatives and recycling programs whenever possible, preferably in cooperation with competitors, which recycle all materials (products and related packaging material) in accordance with all Environmental Laws and taking back program with the contractor company.

Your display is manufactured with high quality materials and components which can be recycled and reused.

To learn more about our recycling program please visit

http://www.philips.com/a-w/about/ sustainability.html

2. Setting up the monitor

2.1 Installation

1 Package contents









* CD





*Audio



*HDMI


*VGA

*Different according to region


- 2 Install the base
- 1. Place the monitor face down on a smooth surface. Pay attention not to scratch or damage the screen.



- 2. Hold the stand with both hands.
 - (1) Gently attach the stand to the VESA mount area until the latch locks the stand.
 - (2) Gently attach the base to the stand.
 - (3) Use your fingers to tighten the screw located at the bottom of the base, and secure the base to the stand tightly.




Warnings




3 Connecting to your PC

240B7QPJEB:



- Kensington anti-theft lock
- 2 Audio input
- 3 Earphone jack
- 4 DisplayPort input
- 5 HDMI input
- 6 VGA input
- AC power input
- 8 Power Switch
- 9 USB upstream
- USB fast charger/USB downstream

240B7QPTEB:





2. Setting up the monitor

Connect to PC

- 1. Connect the power cord to the back of the monitor firmly.
- 2. Turn off your computer and unplug its power cable.
- 3. Connect the monitor signal cable to the video connector on the back of your computer.
- Plug the power cord of your computer and your monitor into a nearby outlet.
- 5. Turn on your computer and monitor. If the monitor displays an image, installation is complete.

- 2.2 Operating the monitor
- 1 Description of the control buttons





0	ወ	Switch monitor's power ON and OFF.
0	■/OK	Access the OSD menu. Confirm the OSD adjustment.
3		Adjust the OSD menu.
4	SENSOR	PowerSensor
6	Ð	Change the signal input source.
6	•	Return to previous OSD level.
Ø	۲	SmartImage hot key. There are 7 modes to select: Office, Photo, Movie, Game, Economy, LowBlue Mode,Off.

2. Setting up the monitor

2 Description of the On Screen Display

What is On-Screen Display (OSD)?

On-Screen Display (OSD) is a feature in all Philips LCD monitors. It allows an end user to adjust screen performance or select functions of the monitors directly through an on-screen instruction window. A user friendly on screen display interface is shown as below:

Off •
•

Basic and simple instruction on the control keys

In the OSD shown above, you can press ▼ ▲ buttons at the front bezel of the monitor to move the cursor, and press OK button to confirm the choice or change.

The OSD Menu

Below is an overall view of the structure of the On-Screen Display. You can use this as a reference when you want to work your way around the different adjustments later on.

Note

If this display has "DPS" for ECO design, the default setting is "ON" mode: it makes the screen looks slightly dim; for optimum brightness, enter to the OSD to set "DPS" to "OFF" mode.

Main menu	Sub menu	
- PowerSensor	- On	0, 1, 2, 3, 4
- LowBlue Mode	Off On	1, 2, 3
	L_ Off	
- Input	VGA	
	- HDMI	
	DisplayPort Mini DP (available for selecti	ve models)
- Picture	Picture Format	
	- Brightness	<u> </u>
	Contrast	0~100
	- Sharpness	<u> </u>
	SmartResponse	- Off, Fast, Faster, Fastest
	- SmartContrast	On, Off
	Gamma	- 1.8, 2.0, 2.2, 2.4, 2.6
	 Pixel Orbiting 	— On, Off
	 Over Scan 	— On, Off
	DPS (available for select	- On, Off ive models)
- Audio	- Volume	0~100
	- Stand-Alone	— On, Off
	- Mute	- On, Off
	- Audio Source	Audio In, HDMI, DisplayPort, Mini DP (available for selective mode)
- Color	Color Temperature	 5000K, 6500K, 7500K, 8200K, 9300K, 11500K
	sRGB	D. I.O. 100
	User Define	Red: 0~100
		Green: 0~100
		Blue: 0~100
— Language	Maryar, Nederlands, P	iñol, EMŋnixî, Français, Italiano, iortuguês, Português do Brasil, a, Suomi, Türkçe, Čeština, 體中文,日本語, 한국어
 OSD Settings 	Horizontal	0~100
	- Vertical	0~100
	- Transparency	- Off, 1, 2, 3, 4
	OSD Time Out	
- Setup	- Auto	
	- H.Position	0~100
	- V.Position	0~100
	- Phase	- 0~100
	- Clock	
	Resolution Notificat	ion — On Off
	DP Out Multi-Stream (available for select	n — Clone, Extend
	Displayport (available for select)	- 1.1, 1.2
	Reset	— Yes, No
	1	

3 Resolution notification

This monitor is designed for optimal performance at its native resolution, 1920×1200 (a) 60 Hz. When the monitor is powered on at a different resolution, an alert is displayed on screen: Use 1920×1200 (a) 60 Hz for best results.


Display of the native resolution alert can be switched off from Setup in the OSD

(On Screen Display) menu.

4 Physical Function

Tilt

240B7QPJEB



Swivel




Height adjustment

240B7QPJEB




240B7QPTEB



240B7QPTEB



Pivot




Warning

- To avoid potential screen damage, such as panel peeling, ensure that the monitor does not tilt downward by more than -5 degrees.
- Do not press the screen while adjusting the angle of the monitor. Grasp only the bezel.


2.3 Remove the Base Assembly for VESA Mounting

Before you start disassembling the monitor base, please follow the instructions below to avoid any possible damage or injury.


1. Extend the monitor base to its maximum height.



2. Place the monitor face down on a smooth surface. Pay attention not to scratch or damage the screen. Then lift the monitor stand.





3. While keeping the release button pressed, tilt the base and slide it out.



Note

This monitor accepts a 100mm x 100mm VESA-Compliant mounting interface. VESA Mounting Screw M4. Always contact manufacturer for wall-mount installation.





* Display design may differ from those illustrated.

Warning

- To avoid potential screen damage, such as panel peeling, ensure that the monitor does not tilt downward by more than -5 degrees.
- Do not press the screen while adjusting the angle of the monitor. Grasp only the bezel.

3. Image Optimization

3.1 SmartImage

1 What is it?


SmartImage provides presets that optimize display for different types of content, dynamically adjusting brightness, contrast, color and sharpness in real time. Whether you're working with text applications, displaying images or watching a video, Philips SmartImage delivers great optimized monitor performance.

2 Why do I need it?

You want a monitor that delivers optimized display all your favorite types of content, SmartImage software dynamically adjust brightness, contrast, color and sharpness in real time to enhance your monitor viewing experience.

3 How does it work?

SmartImage is an exclusive, leading edge Philips technology that analyzes the content displayed on your screen. Based on a scenario you select, SmartImage dynamically enhances the contrast, color saturation and sharpness of images to enhance the contents being displayed – all in real time with the press of a single button. 4 How to enable SmartImage?



- 1. Press 🗇 to launch the SmartImage on screen display.
- Keep pressing ▼ ▲ to toggle among Office, Photo, Movie, Game, Economy, LowBlue Mode and Off.
- 3. The SmartImage on screen display will remain on screen for 5 seconds, or you can also press "OK" to make confirmation.

There are seven modes to select: Office, Photo, Movie, Game, Economy, LowBlue Mode and Off.



 Office: Enhances text and dampens brightness to increase readability and reduce eye strain. This mode significantly enhances readability and productivity when you're working with spreadsheets, PDF

3. Image Optimizatior

files, scanned articles or other general office applications.

- Photo: This profile combines color saturation, dynamic contrast and sharpness enhancement to display photos and other images with outstanding clarity in vibrant colors

 all without artifacts and faded colors.
- Movie: Ramped up luminance, deepened color saturation, dynamic contrast and razor sharpness displays every details in darker areas of your videos without color washout in brighter areas maintaining a dynamic natural values for the ultimate video display.
- Game: Turn on over drive circuit for best response time, reduce jaggy edges for fast moving objects on screen, enhance contrast ratio for bright and dark scheme, this profile delivers the best gaming experience for gamers.
- Economy: Under this profile, brightness, contrast are adjusted and backlighting finetuned for just right display of everyday office applications and lower power consumption.
- LowBlue Mode: LowBlue Mode for easy on-the-eyes productivity Studies have shown that just as ultra-violet rays can cause eye damage, shortwave length blue light rays from LED displays can cause eye damage and affect vision over time. Developed for wellbeing, Philips LowBlue Mode setting uses a smart software technology to reduce harmful shortwave blue light.
- Off: No optimization by SmartImage.

Note

Philips LowBlue mode, mode 2 compliance with TUV Low Blue Light certification, you can have this mode by simply press the hotkey ⑦, then press ▲ to select LowBlue Mode, see above SmartImage selection steps.

3.2 SmartContrast

1 What is it?

Unique technology that dynamically analyzes displayed content and automatically optimizes a Monitor's contrast ratio for maximum visual clarity and viewing enjoyment, stepping up backlighting for clearer, crisper and brighter images or dimming backlighting for clear display of images on dark backgrounds.

2 Why do I need it?

You want the very best visual clarity and viewing comfort for every type of content. SmartContrast dynamically controls contrast and adjusts backlighting for clear, crisp, bright gaming and video images or displays clear, readable text for office work. By reducing your monitor's power consumption, you save on energy costs and extend the lifetime of your monitor.

3 How does it work?

When you activate SmartContrast, it will analyse the content you are displaying in real time to adjust colors and control backlight intensity. This function will dynamically enhance contrast for a great entertainment experience when viewing videos or playing games.

4. PowerSensor™

1 How does it work?

- PowerSensor works on principle of transmission and reception of harmless "infrared" signals in order to detect user-presence.
- When the user is in front of the monitor, the monitor operates normally, at the predetermined settings that the user has set- i.e. brightness, contrast, color, etc
- Assuming that the monitor was set to 100% of brightness for example, when the user leaves his seat and is no longer in front of the monitor, the monitor automatically reduces the power consumption upto 80%.

User present in front User not present



Power consumption as illustrated above is for reference purpose only

2 Setting

Default settings

PowerSensor is designed to detect the presence of the user located between 30 and 100 cm (12 and 40 inches) from the display and within five degrees left or right of the monitor.

Custom settings


If you prefer to be in a position outside the perimeters listed above, choose a higher strength signal for optimal detection efficiency: The higher the setting, the stronger the detection signal. For maximum PowerSensor efficiency and proper detection, please position yourself directly in front of your monitor.

 If you choose to position yourself more than 100 cm or 40 inches from the monitor use the maximum detection signal for distances up to 120 cm or 47 inches. (Setting 4)


• Since some dark colored clothing tends to absorb infrared signals even when the user is within 100 cm or 40 inches of the display, step up signal strength when wearing black or other dark clothes.







Landscape/Portrait mode



Above illustrations are for reference purpose only, may not reflect the exact display of this model.

3 How to adjust settings

If PowerSensor is not operating correctly inside or outside the default range, here's how to fine-tune detection:

- Press the PowerSensor hot key.
- You will find the adjustment bar.
- Adjust the PowerSensor detection adjustment to Setting 4 and press OK.
- Test the new setup to see if PowerSensor properly detects you in your current position.
- PowerSensor function is designed to work in Landscape mode (horizontal position) only. After PowerSensor turn on it, it will automatically turn Off if the monitor is used in Portrait mode (90 degree/vertical position); it will automatically turn ON if monitor is returned to its default Landscape position.

Note

A manually selected PowerSensor mode will remain operational unless and until it is readjusted or the default mode is recalled. If you find that the PowerSensor is excessively sensitive to nearby motion for some reason, please adjust to a lower signal strength. Keep sensor lens clean, if the sensor lens is dirty, wipe it with alcohol to avoid reducing of distance detection.


5. Daisy-chain function (Available for 240B7QPTEB)

Daisy-chain enables multiple monitor connections

This Philips display is equipped with DisplayPort 1.2 interface which enables daisy-chaining to multiple displays. Now you can daisy chain and use multiple monitors via a single cable from one display to the next.

How to daisy chain display

- Connect DisplayPort cable to mini DP or DP port from laptop
- To daisy chain to the 2nd display, connect DisplayPort cable to min DP or DP port from the first display DP out port
- Repeat above steps, you can daisy chain multiple displays
- Refer below table for the numbers of multiple display chaining



Note

1. Depending on the capabilities of your graphic cards, you should be able to daisy chain multiple displays with various configurations. Your display configurations will depend on your graphic card capabilities. Please check with your graphic card vendor and always update your graphic card driver.

2. There are two modes available when you daisy chaining: "Clone" and "Extend", enter the following OSD manual path for the selection: OSD / Setup / DP Out Multi-Stream / Clone, Extend.

	Auto	Clone
	H.Position	Extend
.	V.Position	•
Language	Phase	•
	Clock	•
OSD Settings	Resolution Notification	n.
*	DP Out Multi-Stream	•
Setup	Display Port	•
	Reset	•
	Information	•
•		

Display Resolution (standard 60 Hz)		Maximum number of display chaining(including 1st motherboard connection display)		
		Clone mode (DP1.1 or DP1.2)	Extend mode (DP1.2)	
1680 x 1050	DisplayPort1.1	5	5	
1920 x 1080 (1080p) or 1920 x 1200	DisplayPort1.1	4	4	
2560 x 1600(WQXGA)	DisplayPort1.1	2	2	
3840 x 2160(Ultra HD, 4K) or 4096 x2160 (4K x 2K)	DisplayPort1.2	1	N/A	

6. Technical Specifications

Monitor Panel TypeIPS TechnologyBacklightLEDPanel Size24.1" W (61.1 cm)Aspect Ratio16:10Pixel Pitch0.270(H) mm x 0.270(V) mmSmartContrast20,000,000:1Optimum Resolution1920 x 1200 @ 60 HzViewing Angle178' (H) /178' (V) @ C/R > 10Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzsRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDM11.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPTEB: USB 3.0-4 includes 1 fast charger 240B7QPTEB.Jubas240B7QPTEB. USB 3.0-4 includes 1 fast chargerAudio In/OutPC audio-in, headphone outConvenienceEmglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Taditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100-100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPTEB: 150mmTilt240B7QPTEB: 150mmPivot90 degree	Picture/Display			
Panel Size24.1" W (61.1 cm)Aspect Ratio16:10Pixel Pitch0.270(H) mm x 0.270(V) mmSmartContrast20,000,000:1Optimum Resolution1920 x 1200 @ 60 HzViewing Angle178° (H) / 178° (V) @ C/R > 10Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzSRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPTEB: USB 3.0×2 includes 1 fast chargerInput /OutputVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPTEB: USB 3.0×2 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand-175 / +175 degreeSwivel-175 / +175 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPTEB: 150mm		IPS Technology		
Aspect Ratio16:10Pixel Pitch $0.270(H) mm \times 0.270(V) mm$ SmartContrast $20,000,00:1$ Optimum Resolution1920 x 1200 @ 60 HzViewing Angle178' (H) / 178' (V) @ C/R > 10Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzSRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0*2 includes 1 fast charger 240B7QPTEB: USB 3.0*2 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenience $\emptyset/4 $	Backlight	LED		
Pixel Pitch $0.270(H) mm \times 0.270(V) mm$ SmartContrast $20,000,000:1$ Optimum Resolution $1920 \times 1200 @ 60 Hz$ Viewing Angle $178^{\circ} (H) / 178^{\circ} (V) @ C/R > 10$ Display Colors $16.7 M (6 bit+FRC)$ Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate $50 Hz - 76 Hz$ Horizontal Frequency $30 kHz - 99 kHz$ SRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerJust SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceED/<	Panel Size	24.1" W (61.1 cm)		
SmartContrast20,000,000:1Optimum Resolution1920 x 1200 @ 60 HzViewing Angle178' (H) / 178' (V) @ C/R > 10Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzSRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPJEB: USB 3.0×4 includes 1 fast charger 240B7QPTEB. USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceED/4< O/V Built-in speaker2 W x 2User ConvenienceED/4< O/V OSD LanguagesDolsh, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStandTilt240B7QPJEB: -5 / +20 degreeSwivel-175 / +175 degreeWivel-175 / +175 degreeHeight adjustment240B7QPTEB: 150mm	Aspect Ratio			
Optimum Resolution1920 x 1200 @ 60 HzViewing Angle178' (H) / 178' (V) @ C/R > 10Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzsRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport 0ut(240B7QPTEB)USB240B7QPJEB: USB 3.0*2 includes 1 fast charger 240B7QPTEB: USB 3.0*4 includes 1 fast chargerAudio In/OutPC audio-in, headphone outConvenience	Pixel Pitch	0.270(H) mm x 0.270(V) mm		
Viewing Angle 178° (H) / 178° (V) @ $C/R > 10$ Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzSRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenience	SmartContrast	20,000,000:1		
Display Colors16.7 M (6 bit+FRC)Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzsRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0-2 includes 1 fast charger 240B7QPTEB: USB 3.0-2 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeFilt240B7QPJEB: 130mm 240B7QPTEB: 150mm	Optimum Resolution	1920 x 1200 @ 60 Hz		
Flicker FreeYesPicture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzSRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0+2 includes 1 fast charger 240B7QPTEB: USB 3.0+4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeFilt240B7QPJEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 150mm	Viewing Angle	178° (H) / 178° (V) @ C/R > 10		
Picture EnhancementSmartImageVertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzsRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degreeTilt240B7QPJEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	Display Colors	16.7 M (6 bit+FRC)		
Vertical Refresh Rate50 Hz - 76 HzHorizontal Frequency30 kHz - 99 kHzsRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degreeTilt240B7QPJEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPJEB: 150mm	Flicker Free	Yes		
Horizontal Frequency30 kHz - 99 kHzsRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPTEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeFilt240B7QPTEB: 130mm 240B7QPTEB: 150mm	Picture Enhancement	SmartImage		
sRGBYESLowBlue ModeYESConnectivityVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceImput SignalBuilt-in speaker2 W x 2User ConvenienceImplies, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeTilt240B7QPJEB: 130mm 240B7QPTEB: 150mm	Vertical Refresh Rate	50 Hz - 76 Hz		
LowBlue ModeYESConnectivitySignal Input/OutputVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceBuilt-in speaker2 W x 2User ConvenienceØ/▲●/♥Stopp LanguagesØ/▼Other ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStandTilt240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 150mm	Horizontal Frequency	30 kHz - 99 kHz		
ConnectivitySignal Input/OutputVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceBuilt-in speaker2 W × 2User ConvenienceImput Signal, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeTilt240B7QPJEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	sRGB	YES		
Signal Input/OutputVGA(Analog), HDMI 1.4(Digital), DisplayPort 1.2, mini DP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceBuilt-in speaker2 W × 2User ConvenienceImage: Image:	LowBlue Mode	YES		
Signal Input/OutputDP 1.2(240B7QPTEB), Displayport Out(240B7QPTEB)USB240B7QPJEB: USB 3.0×2 includes 1 fast charger 240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceBuilt-in speaker2 W × 2User ConvenienceED/< ●/▼ storn, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeTilt240B7QPJEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 150mm	Connectivity			
USB240B7QPTEB: USB 3.0×4 includes 1 fast chargerInput SignalSeparate Sync, Sync on GreenAudio In/OutPC audio-in, headphone outConvenienceBuilt-in speaker2 W x 2User ConvenienceImage: Image: Ima	Signal Input/Output			
Audio In/OutPC audio-in, headphone outConvenienceBuilt-in speaker2 W x 2User ConvenienceImploit Imploit Impl	USB			
ConvenienceBuilt-in speaker2 W x 2User ConvenienceImp/ ●/▼ StNSR/▲ Imp/ Imp/ Imp/ Imp/ Imp/ Imp/ Imp/ Imp/	Input Signal	Separate Sync, Sync on Green		
Built-in speaker2 W x 2User ConvenienceImp/ < ⊕/▼ SNXR/▲ Imp/ < Imp/	Audio In/Out	PC audio-in, headphone out		
User ConvenienceImp/< ⊕/▼ stxxx/A Imp/A	Convenience			
OSD LanguagesEnglish, German, Spanish, Greek, French, Italian, Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	Built-in speaker	2 W x 2		
OSD LanguagesHungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese, Japanese, KoreanOther ConvenienceVESA mount(100×100mm), Kensington LockPlug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degreeTilt240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPTEB: 130mm 240B7QPTEB: 150mm	User Convenience			
Plug & Play CompatibilityDDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS XStand240B7QPJEB: -5 / +20 degreeTilt240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	OSD Languages	Hungarian, Dutch, Portuguese, Brazil Portuguese, Polish, Russian, Swedish, Finnish, Turkish, Czech, Ukranian, Simplified Chinese, Traditional Chinese,		
StandTilt240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	Other Convenience	VESA mount(100×100mm), Kensington Lock		
Tilt240B7QPJEB: -5 / +20 degree 240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	Plug & Play Compatibility	DDC/CI, sRGB, Windows 10/8.1/8/7, Mac OS X		
Titt240B7QPTEB: -5 / +30 degreeSwivel-175 / +175 degreeHeight adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	Stand			
Height adjustment240B7QPJEB: 130mm 240B7QPTEB: 150mm	Tilt			
Alight adjustment 240B7QPTEB: 150mm	Swivel	-175 / +175 degree		
Pivot 90 degree	Height adjustment			
	Pivot	90 degree		

6.Technical Specifications

Power(240B7QPJEB)					
	AC Input	AC Input	AC Input		
Consumption	Voltage at	Voltage at	Voltage at		
			230VAC, 50Hz		
Normal Operation	25.7W (typ.)	25.5W (typ.)	26.2W (typ.)		
Sleep (Standby mode)	0.5W	0.5W	0.5W		
Off mode	0.3W	0.3W	0.3W		
Off mode (AC switch)	OW	0 W	0 W		
	AC Input	AC Input	AC Input		
Heat Dissipation*	Voltage at	Voltage at	Voltage at		
	100VAC , 60Hz	115VAC , 60Hz	230VAC, 50Hz		
Normal Operation	87.72 BTU/hr	87.02 BTU/hr	89.41 BTU/hr		
· .	(typ.)	(typ.)	(typ.)		
Sleep (Standby mode)	1.71 BTU/hr	1.71 BTU/hr	1.71 BTU/hr		
Off mode	1.02 BTU/hr	1.02 BTU/hr	1.02 BTU/hr		
Off mode (AC switch)	0 BTU/hr	0 BTU/hr	0 BTU/hr		
On Mode (ECO mode)	15W (typ.)				
PowerSensor	5.3W (typ.)				
Power LED indicator	On mode: White, Standby/Sleep mode: White				
	(blinking)				
Power Supply Built-in, 100-240V AC, 50-60Hz					
Power(240B7QPTEB)	1				
	AC Input	AC Input	AC Input		
Power(240B7QPTEB) Consumption	Voltage at	Voltage at	Voltage at		
Consumption	Voltage at 100VAC , 60Hz	Voltage at 115VAC , 60Hz	Voltage at 230VAC, 50Hz		
Consumption Normal Operation	Voltage at 100VAC , 60Hz 26.61W (typ.)	Voltage at 115VAC , 60Hz 25.30W (typ.)	Voltage at 230VAC, 50Hz 25.48W (typ.)		
Consumption Normal Operation Sleep (Standby mode)	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W	Voltage at 115VAC , 60Hz 25.30W (typ.) 0.5W	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W		
Consumption Normal Operation Sleep (Standby mode) Off mode	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W	Voltage at 115VAC , 60Hz 25.30W (typ.) 0.5W 0.3W	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W		
Consumption Normal Operation Sleep (Standby mode)	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W 0.3W 0 W	Voltage at 115VAC , 60Hz 25.30W (typ.) 0.5W 0.3W 0.3W 0 W	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0.3W 0 W		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch)	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W 0.3W 0 W AC Input	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0.3W 0 W AC Input	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0.3W 0 W AC Input		
Consumption Normal Operation Sleep (Standby mode) Off mode	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0.3W 0 W AC Input Voltage at	Voltage at 115VAC, 6OHz 25.30W (typ.) 0.5W 0.3W 0.3W 0 W AC Input Voltage at	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0.3W 0 W AC Input Voltage at		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation*	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC, 60Hz	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 60Hz	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch)	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC, 60Hz 90.83 BTU/hr	Voltage at 115VAC , 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC , 60Hz 86.35 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC, 60Hz 90.83 BTU/hr (typ.)	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 60Hz 86.35 BTU/hr (typ.)	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.)		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode)	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC, 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 60Hz 86.35 BTU/hr (typ.) 1.71 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode) Off mode	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC , 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr	Voltage at 115VAC, 6OHz 25.3OW (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 6OHz 86.35 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch)	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC , 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 60Hz 86.35 BTU/hr (typ.) 1.71 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) On Mode (ECO mode)	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC , 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr 15.2W (typ.)	Voltage at 115VAC, 6OHz 25.3OW (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 6OHz 86.35 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode) Off mode Off mode Off mode (AC switch) On Mode (ECO mode) PowerSensor	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC, 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr 15.2W (typ.) 5.4W (typ.)	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 60Hz 86.35 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) On Mode (ECO mode)	Voltage at 100VAC , 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC , 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 1.02 BTU/hr 0 BTU/hr 15.2W (typ.) 5.4W (typ.) On mode: White,	Voltage at 115VAC, 6OHz 25.3OW (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 6OHz 86.35 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr		
Consumption Normal Operation Sleep (Standby mode) Off mode Off mode (AC switch) Heat Dissipation* Normal Operation Sleep (Standby mode) Off mode Off mode Off mode (AC switch) On Mode (ECO mode) PowerSensor	Voltage at 100VAC, 60Hz 26.61W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 100VAC, 60Hz 90.83 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr 15.2W (typ.) 5.4W (typ.)	Voltage at 115VAC, 60Hz 25.30W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 115VAC, 60Hz 86.35 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr Standby/Sleep mc	Voltage at 230VAC, 50Hz 25.48W (typ.) 0.5W 0.3W 0 W AC Input Voltage at 230VAC, 50Hz 86.97 BTU/hr (typ.) 1.71 BTU/hr 1.02 BTU/hr 0 BTU/hr		

Dimensions	
Product with stand	533 x 514 x 257 mm (240B7QPJEB)
(WxHxD)	533 x 549 x 257 mm (240B7QPTEB)
Product without stand	533 x 360 x 57 mm
(WxHxD)	533 X 360 X 57 mm
Product with packaging	595 x 520 x 187 mm (240B7QPJEB)
(WxHxD)	595 x 520 x 224 mm (240B7QPTEB)
Weight	
	6.37 kg (240B7QPJEB)
Product with stand	6.57 kg (240B7QPTEB)
	4.07 kg (240B7QPJEB)
Product without stand	4.14 kg (240B7QPTEB)
	8.85 kg (240B7QPJEB)
Product with packaging	9.25 kg (240B7QPTEB)
	9.23 kg (240b/QFTEb)
Operating Condition	
Temperature range	0°C to 40 °C
(operation)	
Relative humidity	20% to 80%
(operation)	20% (0.00%)
Atmospheric pressure	700 to 1060hPa
(operation)	700 to 100011Pa
Temperature range	
(Non-operation)	-20°C to 60°C
Relative humidity	
(Non-operation)	10% to 90%
Atmospheric pressure	
(Non-operation)	500 to 1060hPa
· ·	
Environmental and energy ROHS	YES
Packaging	100% recyclable
Specific Substances	100% PVC BFR free housing
Cabinet	
Color	Black/Black
Finish	Texture

Note

- 1. This data is subject to change without notice. Go to <u>www.philips.com/support</u> to download the latest version of leaflet.
- 2. USB hub is only support mouse or keyboard to wake up the system while on power saving mode.

6.1 Resolution & Preset Modes

1 Maximum Resolution

1920 x 1200 @ 60 Hz (analog input) 1920 x 1200 @ 60 Hz (digital input)

2 Recommended Resolution

1920 x 1200 @ 60 Hz (digital input)

H. freq (kHz)	Resolution	V. freq (Hz)
31.47	720 x 400	70.09
31.47	640 x 480	59.94
35.00	640 x 480	66.67
37.86	640 x 480	72.81
37.50	640 x 480	75.00
35.16	800 x 600	56.25
37.88	800 x 600	60.32
46.88	800 x 600	75.00
48.08	800 x 600	72.19
47.73	832 x 624	74.55
48.36	1024 x 768	60.00
56.48	1024 x 768	70.07
60.02	1024 x 768	75.03
44.77	1280 x 720	59.86
60	1280 x 960	60
63.89	1280 x 1024	60.02
79.98	1280 x 1024	75.03
55.94	1440 x 900	59.89
65.29	1680 x 1050	59.95
67.50	1920 x 1080	60.00
74.07	1920 x 1200	59.95

Note

Please notice that your display works best at native resolution of 1920 x 1200 @ 60Hz. For best display quality,please follow this resolution recommendation.

7. Power Management

If you have VESA DPM compliance display card or software installed in your PC, the monitor can automatically reduce its power consumption when not in use. If an input from a keyboard, mouse or other input device is detected, the monitor will 'wake up' automatically. The following table shows the power consumption and signaling of this automatic power saving feature:

240B7QPJEB:

Power Management Definition						
VESA Mode	Video	H-sync	V-sync	Power Used	LED Color	
Active	ON	Yes	Yes	26.7W (typ.) 59W (max.)	White	
Sleep (Standby mode)	OFF	No	No	0.5W (typ.)	White (blink)	
Off mode (AC switch)	OFF	-	-	OW (typ.)	OFF	

240B7QPTEB:

Power Management Definition						
VESA Mode	Video	H-sync	V-sync	Power Used	LED Color	
Active	ON	Yes	Yes	26.9 W (typ.) 65 W (max.)	White	
Sleep (Standby mode)	OFF	No	No	0.5W (typ.)	White (blink)	
Off mode (AC switch)	OFF	-	-	OW (typ.)	OFF	

The following setup is used to measure power consumption on this monitor.

- Native resolution: 1920 x 1200
- Contrast: 50%
- Brightness: 80%
- Color temperature: 6500k with full
 white pattern


Note

This data is subject to change without notice.

8. Customer care and warranty

8.1 Philips' Flat Panel Monitors Pixel Defect Policy

Philips strives to deliver the highest quality products. We use some of the industry's most advanced manufacturing processes and practice stringent quality control. However, pixel or sub pixel defects on the TFT Monitor panels used in flat panel monitors are sometimes unavoidable. No manufacturer can guarantee that all panels will be free from pixel defects, but Philips guarantees that any monitor with an unacceptable number of defects will be repaired or replaced under warranty. This notice explains the different types of pixel defects and defines acceptable defect levels for each type. In order to gualify for repair or replacement under warranty, the number of pixel defects on a TFT Monitor panel must exceed these acceptable levels. For example, no more than 0.0004% of the sub pixels on a monitor may be defective. Furthermore, Philips sets even higher guality standards for certain types or combinations of pixel defects that are more noticeable than others. This policy is valid worldwide.



Pixels and Sub pixels

A pixel, or picture element, is composed of three sub pixels in the primary colors


of red, green and blue. Many pixels together form an image. When all sub pixels of a pixel are lit, the three colored sub pixels together appear as a single white pixel. When all are dark, the three colored sub pixels together appear as a single black pixel. Other combinations of lit and dark sub pixels appear as single pixels of other colors.

Types of Pixel Defects


Pixel and sub pixel defects appear on the screen in different ways. There are two categories of pixel defects and several types of sub pixel defects within each category.

Bright Dot Defects

Bright dot defects appear as pixels or sub pixels that are always lit or 'on'. That is, a bright dot is a sub-pixel that stands out on the screen when the monitor displays a dark pattern. There are the types of bright dot defects.



One lit red, green or blue sub pixel.



Two adjacent lit sub pixels:

- Red + Blue = Purple
- Red + Green = Yellow
- Green + Blue = Cyan (Light Blue)



Three adjacent lit sub pixels (one white pixel).

Note

À red or blue bright dot must be more than 50 percent brighter than neighboring dots while a green bright dot is 30 percent brighter than neighboring dots.


Black Dot Defects

Black dot defects appear as pixels or sub pixels that are always dark or 'off'. That is, a dark dot is a sub-pixel that stands out on the screen when the monitor displays a light pattern. These are the types of black dot defects.



Proximity of Pixel Defects

Because pixel and sub pixels defects of the same type that are near to one another may be more noticeable, Philips also specifies tolerances for the proximity of pixel defects.



Pixel Defect Tolerances

In order to qualify for repair or replacement due to pixel defects during the warranty period, a TFT Monitor panel in a Philips flat panel monitor must have pixel or sub pixel defects exceeding the tolerances listed in the following tables.

BRIGHT DOT DEFECTS	ACCEPTABLE LEVEL
1 lit subpixel	3
2 adjacent lit subpixels	1
3 adjacent lit subpixels (one white pixel)	0
Distance between two bright dot defects*	>15mm
Total bright dot defects of all types	3
BLACK DOT DEFECTS	ACCEPTABLE LEVEL
1 dark subpixel	5 or fewer
2 adjacent dark subpixels	2 or fewer
3 adjacent dark subpixels	0
Distance between two black dot defects*	>15mm
Total black dot defects of all types	5 or fewer
TOTAL DOT DEFECTS	ACCEPTABLE LEVEL
Total bright or black dot defects of all types	5 or fewer

Note

1 or 2 adjacent sub pixel defects = 1 dot defect

8.2 Customer Care & Warranty

For warranty coverage information and additional support requirements valid for your region, please visit www.philips.com/support website for details or contact your local Philips Customer Care Center.

For extended warranty, if you would like to extend your general warranty period, an Out of Warranty service package is offered via our Certified Service Center.

For Warranty Period please refer to Warranty Statement in Important Information Manual.

If you wish to make use of this service, please be sure to purchase the service within 30 calendar days of your original purchase date. During the extended warranty period, the service includes pickup, repair and return service, however the user will be responsible for all costs accrued.

If the Certified Service Partner cannot perform the required repairs under the offered extended warranty package, we will find alternative solutions for you, if possible, up to the extended warranty period you have purchased.

Please contact our Philips Customer Service Representative or local contact center (by Consumer care number) for more details.

•	Local Standard Warranty Period	•	Extended Warranty Period	•	Total Warranty Period
•	Depend on different Regions	•	+ 1 Year	•	Local Standard warranty period +1
		•	+ 2 Years	•	Local Standard warranty period +2
		•	+ 3 Years	•	Local Standard warranty period +3

Philips Customer Care Center number listed below.

**Proof of original purchase and extended warranty purchase required.

Note

Please refer to important information manual for regional service hotline, which is available on the Philips website support page.

9. Troubleshooting & FAQs

9.1 Troubleshooting

This page deals with problems that can be corrected by a user. If the problem still persists after you have tried these solutions, contact Philips customer service representative.

1 Common Problems

No Picture (Power LED not lit)

- Make sure the power cord is plugged into the power outlet and into the back of the monitor.
- First, ensure that the power button on the front of the monitor is in the OFF position, then press it to the ON position.

No Picture (Power LED is White)

- Make sure the computer is turned on.
- Make sure the signal cable is properly connected to your computer.
- Make sure the monitor cable has no bent pins on the connect side. If yes, repair or replace the cable.
- The Energy Saving feature may be activated

Screen says



• Make sure the monitor cable is properly connected to your computer. (Also refer to the Quick Start Guide).

- Check to see if the monitor cable has bent pins.
- Make sure the computer is turned on.

AUTO button doesn't function

• The auto function is applicable only in VGA-Analog mode. If the result is not satisfactory, you can do manual adjustments via the OSD menu.

Note

The Auto Function is not applicable in DVI-Digital mode as it is not necessary.

Visible signs of smoke or sparks

- Do not perform any troubleshooting steps
- Disconnect the monitor from mains
 power source immediately for safety
- Contact with Philips customer
 service representative immediately.

2 Imaging Problems

Image is not centered

- Adjust the image position using the "Auto" function in OSD Main Controls.
- Adjust the image position using the Phase/Clock of Setup in OSD Main Controls. It is valid only in VGA mode.

Image vibrates on the screen

• Check that the signal cable is properly securely connected to the graphics board or PC.

Vertical flicker appears



- Adjust the image using the "Auto" function in OSD Main Controls.
- Eliminate the vertical bars using the Phase/Clock of Setup in OSD

9.Troubleshooting & FAQs

Main Controls. It is valid only in VGA mode.

Horizontal flicker appears

×	×
은 글	
	÷

- Adjust the image using the "Auto" function in OSD Main Controls.
- Eliminate the vertical bars using the Phase/Clock of Setup in OSD Main Controls. It is valid only in VGA mode.

Image appears blurred, indistinct or too dark

• Adjust the contrast and brightness on On-Screen Display.

An "after-image", "burn-in" or "ghost image" remains after the power has been turned off.

- Uninterrupted display of still or static images over an extended period may cause "burn-in", also known as "after-imaging " or "ghost imaging", on your screen. "Burn-in", "afterimaging", or "ghost imaging" is a well-known phenomenon in LCD panel technology. In most cases, the "burn-in" or "after-imaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.
- Always activate a moving screen saver program when you leave your monitor unattended.
- Always activate a periodic screen refresh application if your LCD monitor will display unchanging static content.
- Failure to activate a screen saver, or a periodic screen refresh application may result in severe "burn-in" or "after-imaging" or "ghost imaging" symptoms that will not disappear

and cannot be repaired. The damage mentioned above is not covered under your warranty.

Image appears distorted. Text is fuzzy or blurred.

 Set the PC's display resolution to the same mode as monitor's recommended screen native resolution.

Green, red, blue, dark, and white dots appears on the screen

 The remaining dots are normal characteristic of the liquid crystal used in today's technology, Please refer the pixel policy for more detail.

* The "power on" light is too strong and is disturbing

 You can adjust "power on" light using the power LED Setup in OSD main Controls.

For further assistance, refer to the Service contact information listed in Important information manual and contact Philips customer service representative.

* Functionality different according to display.

9.2 General FAQs

- Q1: When I install my monitor what should I do if the screen shows 'Cannot display this video mode'?
- Ans.: Recommended resolution for this monitor: 1920 x 1200 @ 60 Hz.
- Unplug all cables, then connect your PC to the monitor that you used previously.
- In the Windows Start Menu, select Settings/Control Panel. In the Control Panel Window, select the Display icon. Inside the Display Control Panel, select the 'Settings' tab. Under the setting tab, in box labelled 'desktop area', move the sidebar to 1920 x 1200 pixels.
- Open 'Advanced Properties' and set the Refresh Rate to 60 Hz, then click OK.
- Restart your computer and repeat step 2 and 3 to verify that your PC is set at 1920 x 1200 @ 60 Hz.
- Shut down your computer, disconnect your old monitor and reconnect your Philips LCD monitor.
- Turn on your monitor and then turn on your PC.
- Q2: What is the recommended refresh rate for LCD monitor?
- Ans.: Recommended refresh rate in LCD monitors is 60 Hz, In case of any disturbance on screen, you can set it up to 75 Hz to see if that removes the disturbance.
- Q3: What are the .inf and .icm files on the CD-ROM? How do I install the drivers (.inf and .icm)?
- Ans.: These are the driver files for your monitor. Follow the instructions in your user manual to install the drivers. Your computer may ask

you for monitor drivers (.inf and .icm files) or a driver disk when you first install your monitor. Follow the instructions to insert the companion CD-ROM included in this package. Monitor drivers (.inf and .icm files) will be installed automatically.

Q4: How do I adjust the resolution?

- Ans.: Your video card/graphic driver and monitor together determine the available resolutions. You can select the desired resolution under Windows[®] Control Panel with the "Display properties".
- Q5: What if I get lost when I am making monitor adjustments via OSD?
- Ans.: Simply press the OK button, then select 'Reset' to recall all of the original factory settings.

Q6: Is the LCD screen resistant to scratches?

Ans.: In general it is recommended that the panel surface is not subjected to excessive shocks and is protected from sharp or blunt objects. When handling the monitor, make sure that there is no pressure or force applied to the panel surface side. This may affect your warranty conditions.

Q7: How should I clean the LCD surface?

- Ans.: For normal cleaning, use a clean, soft cloth. For extensive cleaning, please use isopropyl alcohol. Do not use other solvents such as ethyl alcohol, ethanol, acetone, hexane, etc.
- Q8: Can I change the color setting of my monitor?

9.Troubleshooting & FAQs

- Ans.: Yes, you can change your color setting through OSD control as the following procedures,
- Press "OK" to show the OSD (On Screen Display) menu
- Press "Down Arrow" to select the option "Color" then press "OK" to enter color setting, there are three settings as below.
 - Color Temperature: The six settings are 5000K, 6500K, 7500K, 8200K, 9300K and 11500K. With settings in the 5000K range the panel appears "warm, with a red-white color tone", while a 11500K temperature yields "cool, bluewhite toning".
 - 2. sRGB: This is a standard setting for ensuring correct exchange of colors between different device (e.g. digital cameras, monitors, printers, scanners, etc).
 - 3. User Define: The user can choose his/her preference color setting by adjusting red, green blue color.

Note

A measurement of the color of light radiated by an object while it is being heated. This measurement is expressed in terms of absolute scale, (degrees Kelvin). Lower Kevin temperatures such as 2004K are red; higher temperatures such as 9300K are blue. Neutral temperature is white, at 6504K.

- Q9: Can I connect my LCD monitor to any PC, workstation or Mac?
- Ans.: Yes. All Philips LCD monitors are fully compatible with standard PCs, Macs and workstations. You may need a cable adapter to connect the monitor to your Mac system. Please contact your

Philips sales representative for more information.

Q10: Are Philips LCD monitors Plugand- Play?

- Ans.: Yes, the monitors are Plug-and-Play compatible with Windows 10/8.1/8/7, Mac OSX
- Q11: What is Image Sticking, or Image Burn-in, or After Image, or Ghost Image in LCD panels?
- Ans.: Uninterrupted display of still or static images over an extended period may cause "burn-in", also known as "after-imaging" or "ghost imaging", on your screen. "Burn-in", "afterimaging", or "ghost imaging" is a well-known phenomenon in LCD panel technology. In most cases, the "burn-in" or "afterimaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.

Always activate a moving screen saver program when you leave your monitor unattended. Always activate a periodic screen refresh application if your LCD monitor will display unchanging static content.

Warning

Failure to activate a screen saver, or a periodic screen refresh application may result in severe "burn-in" or "afterimage" or "ghost image" symptoms that will not disappear and cannot be repaired. The damage mentioned above is not covered under your warranty.

Q12: Why is my Display not showing sharp text, and is displaying jagged characters?

- Ans.: Your LCD monitor works best at its native resolution of 1920 x 1200 @ 60 Hz. For best display, please use this resolution.
- Q13: How to unlock/lock my hot key?
- Ans.: Please press **■/OK** for 10 seconds to unlock/lock the hot key, by doing so, your monitor pops out "Attention" to show the unlock/lock status as shown below illustrators.

Attention	
Monitor control unlocked	
Attention	
Monitor control locked	

- Q14: Where can I find Important Information manual mentioned in EDFU?
- Ans.: Important Information manual can be download on the Philips website support page.



2020 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

Version: M7240BE1T