

PHILIPS

人体传感器

1000 Series

TAI1105/93



www.philips.com/welcome



2021 © MMD Hong Kong Holding Limited. All rights reserved. Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

TAI1105/93



产品概述

TAI1105/93为用户提供了灵敏的动静探测功能，可单独使用，也可配套其他无线设备使用，配合无线网关，通过无线通信来控制其它无线设备（例如灯光、窗帘、报警器等）。被广泛应用于家庭、影剧院、办公楼等场合。TAI1105/93的无线红外动静探头使用电池供电，用户需要做的仅仅是把它安装在适合的位置，并接入系统。

技术参数

产品名称	人体传感器
额定电压	DC 3V (CR123A 电池)
探测角度	90°
最大探测区域	8m
安装高度	2.2m
工作温度	-10°C~55°C
工作湿度	≤80%RH (无冷凝)
通讯协议	Zigbee
产品尺寸	φ48.4mmx53.4mm

注意事项

- 为确保正确使用本产品，墙面开关必须由专业电工安装拆卸
- 安装或拆卸墙面开关前必须要切断电源总闸，以防触电
- 安装或拆卸本产品所控制的灯或灯具前必须要切断电源总闸以防触电
- 本产品在安装和使用过程中需要远离火源和水源
- 本产品不能在潮湿环境中使用（比如浴室）

使用说明

使用准备

- 1 手机连入WIFI ---> 智能手机 --->WIFI无线路
由器LAN口 ---> 智能主机WAN口

确保产品在智能主机（网关）Zigbee网络的有效覆盖范围内
以保证产品与智能主机（网关）Zigbee网络之间的有效连接

***确保智能主机已添加**

- 2 下载并打开App

在应用商店搜索“智家生活“或扫描外包装/产品说明书上的
二维码下载安装App

如第一次下载使用，请点击“注册”按钮注册账号；如已有账
号则点击“登录”按钮。

入网设置

注：添加设备之前需要添加网关

- 1 将设备与电源连接，同时确保手机已连接到网络；
- 2 打开智家生活App，在“智能网关”页面，点击“添加子设备”按钮；
- 3 取出电源绝缘片，产品通电，红色指示灯慢闪一分钟自检
- 4 长按SET按钮5S以上，直至指示灯闪烁，按照app说明添加设备
- 5 添加成功后，即可在“我的家”列表中找到设备。

功能设置

配网成功后，可以进入产品设置页面进行功能设置。