TAW6205 & TAW6505 User Manual Addendum

Thank you for purchasing Philips TAW6205 & TAW6505.

This document provides additional and updated information about the products. Please read this document as well as the user manual before using the product.

1. Bluetooth pairing

Note: This product with Play-Fi CAP version 506.3.0.063 or 506.3.0.077 requires Play-fi/Wi-fi connection to be set up and functioning before Bluetooth pairing is allowed to operate. Please follow the instructions in the chapter "Connect" in TAW6205 and TAW6505 user manual to complete Play-fi/Wi-fi setup when the product is used for the first time.

Bluetooth pairing procedure:

- 1. Press and hold 🖇 button at the back cabinet for 8 seconds to enter the Bluetooth pairing mode
- 2. Find the device with name XXXXX-BT in available device list in your phone/tablet (XXXXX is the name chosen during Play-Fi setup).
- 3. Select XXXXX-BT and wait for Bluetooth connection to be made. Normally, complete in 1-2sec.