

User manual





Need help?

Online help: http://www.philips.com/support For interactive help, downloads and frequently asked questions.

What's in the box?

Please check that the following items are packed in the Philips SPC900NC box. They are provided to help you set up and use your Philips SPC900NC.








Philips SPC900NC WebCam

Installation CD-ROM including manual

Quick Installation Guide

Legend of functions



1 Viewing angle

For manually changing the vertical angle of the WebCam.

2 Quicklaunch button

For quick and easy start-up of the VLounge Advanced software.

3 Rotating lens

For adjusting the focus of the image manually.

4 Clamp with rubber rims

For attaching the WebCam to your monitor.

5 USB connector

For connecting the WebCam to a USB port of the PC / laptop. The WebCam will derive its power from the PC / laptop when it is connected.

6 Snapshot button

For taking photos.

7 Built in digital microphone

For adding sound when video chatting and recording.

8 Screw thread

For moutning the WebCam to a tripod.

9 Activity LED

Lights up when the WebCam is in use.

Contents

- 2 Need help?
- 3 What's in the box?
- 4 Legend of functions
- 5 Contents
- 6 Welcome

7 Things you should know

- 7 Safety precautions
- 7 Copyright

8 Installation

- 8 Installing the WebCam software
- 10 Connecting the WebCam to your PC / laptop

II WebCam settings

- 11 General controls
- 12 Picture controls
- 15 Audio controls

16 Using the applications

- 16 VLounge Advanced
- 16 Skype
- 17 MSN Messenger
- 18 Yahoo! Messenger
- 18 AOL Instant Messenger
- 18 Making snapshots using Windows® XP

19 Technical specifications

20 Important information

- 20 Disclaimer
- 20 FCC compliance
- 21 Environmental information
- 21 System requirements
- 21 Disclaimer of warranty
- 21 Limitations of damages

Welcome

The Philips SPC900NC WebCam you have just purchased is manufactured to the highest standards and will give you years of trouble-free use. Brilliant images and blazing colors, that's what you get with the SPC900NC WebCam. Forget about installing interface cards and separate power supplies, because you don't need them any more. Power is supplied direct to the WebCam through the USB cable and the WebCam returns audio and video straight to your PC / laptop!

After installation, the new WebCam can be used for all sorts of applications, such as:

- Video conferencing: use the Philips SPC900NC WebCam for video chatting and conferencing (the Philips SPC900NC WebCam works with Skype, MSN Messenger, Yahoo! Messenger and AOL Messenger);
- Video e-mail /Video capture: create your own video presentations, video mail, product demonstrations, training videos, Internet clips etc.;
- Snapshot images: use images in presentations, create postcards, or send them via e-mail or on diskette. The WebCam works with all applications that use the TWAIN interface to acquire an image.
- Editing and special effects: after recording the images you want with the Philips SPC900NC WebCam, the images can be easily edited using image or video editing programs.

The following sections in this manual give a step-by-step description of the installation process and explain how to use the Philips SPC900NC WebCam.

Things you should know

Please read the following instructions carefully, and retain them for future reference. It may be helpful to have the instructions for use for the PC / laptop at hand for reference.

Safety precautions

Observe the following guidelines to ensure that the WebCam will operate safely and to prevent defects.

- Do not use your WebCam in environments outside the following range: temperature: 0°C to 40°C, relative humidity: 45% ~ 85%.
- Do not use or store your WebCam in/under:
 - direct sunlight exposure;
 - very humid and dusty environment;
 - near any kind of heat sources.
- If your WebCam gets wet, dry it with soft cloth as soon as possible.
- If the lens is dirty, Do NOT touch the lens with your fingers.
- Clean the outside of the WebCam with a soft cloth.
- Do NOT use cleaning fluids based on alcohol, methylated spirit, ammonia, etc.
- Do NOT attempt to disassemble or repair your WebCam by yourself. Do not open the WebCam. In the event of technical difficulties return it to your Philips retailer.
- Do NOT use your WebCam in the water.
- Protect the WebCam from oil, vapour, steam, moisture, and dust.
- Never point the WebCam lens at the sun.

Copyright

Copyright[©] 2003 by Philips Consumer Electronics B.V. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without prior written permission from Philips. Brands and product names are trademarks or registered trademarks of their respective companies.

Installation

Installing the WebCam software

The software supplied only works on PC's / laptop's with the operating systems Microsoft[®] Windows[®] 98SE, ME, 2000 and XP.

Notes!

- Unplug all your USB devices (except USB keyboard and USB mouse) before you start.
- Do not plug in your USB WebCam yet. Run the Installation CD-ROM first.
- Have your Windows® CD-ROM at hand.
- The SPC900NC WebCam is 'XP Plug & Play'. This means if you are running Windows XP and you have installed Service Pack 2 and the latest Microsoft Windows XP updates you don't need to install the SPC900NC WebCam driver. Simply plug in the WebCam and you can start using your SPC900NC WebCam.
- I Place the installation CD-ROM in your PC's / laptop's CD-ROM / DVD drive.
 - > After a couple of seconds the the 'Language selection' screen appears automatically.

Note!

If the 'Language selection' screen does not appear automatically, open the Microsoft[®] Windows[®] Explorer and double click on the 'Set-up.exe' icon in the CD-ROM directory.

- 2 Select your language and click on the 'OK' button.
 - > The following screen appears.
- 3 Select at least the 'SPC900NC WebCam Driver' and 'Philips VLounge Advanced'.

Click on the 'Next' button.



elect Components Chocce the components Setup will in			
Choose the components Setup Hill in	stal.		
Select the components you want to in A tail.	nstall, and clear the c	omponents you do not want	to
SPC900NC WebCam Driver		Description	
Philips VLounge Advanced	· .	Install HebCamDriver	
Acrobal PDF Manual			
	100000		
Space Required on C. Space Available on C.	37760 K. 33189984 K		
Space Analysis of C.	001000001		

Installation



- > The following software license agreement appears.
- 4 Click on 'Yes' to continue the installation.


Philips SPC900NC WebCam	×
Setup Status	
SPC900NC WebCam Setup is perfo	orming the requested operations.
Installing:	
C:\Program Files\Philips\SPC900N	C WebCam\TrayMin.exe
	99%
	Cancel
	Calca

> The following screen, including a progress bar, appears.

- PROPOSED VALUES CONTRACTOR OF A CONTRACTOR OF
- > The following screen appears when the installation was successful.
- 5 Click on 'Finish'.
- **6** Restart your PC / laptop when you have finished installing the software.
 - > The V(ideo)-Lounge Advanced desktop shortcut **()** will be installed after installation.
 - > Via VLounge Advanced you have access to all WebCam-related software. See 'Using the applications'.
- 7 You can now connect your WebCam.

Installation

Connecting the WebCam to your PC / laptop



- 1 Be sure to run the installation CD first, before connecting the WebCam to the PC / laptop.
- 2 Turn on the PC / laptop.
- Connect the USB plug of the USB cable to the USB port of the PC / laptop.
 The WebCam will now derive its power from the PC / laptop.
- 4 Use the clamp and the two rubber rims to attach the WebCam to your PC monitor or laptop screen or fold out the clamp and place the WebCam on your desk.

The Philips SPC900NC video property can be changed from within an application, or independently by clicking the VProperty icon '**(()** which can be found in the Windows taskbar bottom right of your screen. Most applications can show a 'live preview' video image on your monitor. Always use this option to see the effect of changed settings on your screen.

General controls

	Properties					_		X
	General	Picture	Audio					
)-		- 9 ()	Flickerless image Region	Γ	On C Euro	ope (50 Hz	off •	
) —) —		e D	Face tracking Digital zoom Level	₽ 1	On C On C	4.5	off © off ©	
.) —			Picture enhancer Level Trimension demo mode	_	on 💿	,	off ©	
			OK			ancel	Apply	

① Flickerless Image

The Flickerless option should only be used under flickering light conditions (e.g. fluorescent or neon lamps) to prevent flickering or strangely coloured video images. If this option is used under normal lighting conditions the video image may be overexposed.

2 Face tracking

If you enable the face tracking option the WebCam will track your face. This will give your more convenience while video chatting, because you don't need to sit still during your video conversation.

3 Digital zoom

Use the digital zoom option if you would like to get an object closer.

④ Picture enhancer

Use the picture enhancement option if you would like to increase the sharpness and the details of the image produced by your SPC900NC WebCam. The picture enhancement feature enables Philips patented Pixel Plus technology. By using the level bar you can adjust the level of Pixel Plus added to the live video of your WebCam.

Picture enhancement technology is powered by Philips Trimension.



Picture controls

	Properties X
(5)	General Picture Audio
(6) —	Full automatic control 🔽
$\bigcirc -$	Frame rate 10 fps
8-	Reset Auto Exposure On C Off C
9-	Restore Gain
10	Save Auto White Belance On C Off C
(11) —	Indeer O Outdeer O Fuorescense O
(12) —	Red Blue O
(13) —	Brightness
(14)	Gamma
(15) —	J SaturationJ
š	Black & White On C Off C
(16)	Backlight compensation On C Off C Mirror On C Off C
(17) —	Mirror On C Off C
18 —	OK Cancel Apply

(5) Full automatic control: on/off

This full automatic control mode provides a very easy way to get the best out of your Philips SPC900NC WebCam. Or you can choose to have maximum manual control over the WebCam settings by switching the full automatic control mode off. Full automatic control 'on' is the preferred setting for normal use.

Techniques active within full automatic control mode are:

- Automatic exposure control and automatic white balance control, to provide the best video source signal possible;
- Automatic frame rate selection for improved WebCam sensitivity in low light conditions.

6 Frame rate

You can use the scroll open menu to set the frame rate of the video you wish to capture. E.g. 30 fps means that the WebCam will capture video of 30 frames per second.

Auto exposure & exposure slider

The exposure is the amount of light received by the sensor and is determined by how long the sensor is exposed to capture a snapshot or video frame. The result depends on the sensitivity of the sensor. The WebCam will find the optimal setting if you select the auto exposure option. You can use the exposure slider if you would like to set the WebCam according to your personal preferences.

(8) Reset

Press this button if you would like to reset the WebCam settings to the default factory settings.

(9) Save

Press this button if you would like to save your personal preferred settings

(10) Restore

Press this button if you would like to restore your personal preferred settings

(1) Auto White balance

Most light sources are not 100% pure white but have a certain 'color temperature'. Normally our eyes compensate for lighting conditions with different color temperatures. If the Auto White balance is selected, the WebCam will search for an object of which the WebCam knows the color temperature of and will compensate all the other colors in the view of the WebCam accordingly.

You can also select the 'Indoor', 'Outdoor' and 'Fluorescence' options to provide the WebCam with more information to find the right setting. You can use the 'Red' and 'Blue' sliders if you would like to set the WebCam according to your personal preferences.

(12) Brightness

Brightness enables you to adjust the brightness of the displayed image or video to suit your own preference. Use the slider to find your preferred setting.

(13) Contrast

Contrast enables you to control the ratio between dark and light according to your own preference. Use the slider to find your preferred setting.

(14) Gamma

Gamma enables you to brighten dark areas within the displayed image or video and visualize more details without over-exposing already light areas.

Use the slider to find your preferred setting.

(15) Saturation

Saturation enables you to set the colour reproduction from black and white to a full colour image or video according to your own preference.

Use the slider to find your preferred setting.

(16) Black and white

The 'Black and white' checkbox is used to switch from colour images to black and white and back.


17 Backlight compensation

Turn on the backlight compensation to improve the image quality when you have a scene where the background has a high illumination level (for instance when you are sitting in front of a bright light).

18 Mirror

Clicking the 'Mirror Image' checkbox flips the image horizontally. You can use this feature when you want to use the Philips SPC900NC and monitor as a mirror, or to take pictures of mirrored images.

Audio controls



(19) Volume slider

This slider provides manual control over the microphone volume.

20 Start

Test the audio level by clicking on the 'Start' button.

Using the applications

VLounge Advanced

All applications can be accessed via the Philips V(ideo)-Lounge Advanced application.VLounge Advanced is the central application for easy access to your Philips WebCam and all image and video applications installed during setup.

- Start VLounge Advanced through the Windows QuickLaunch menu in your taskbar, via the program group 'SPC900NC WebCam', or by clicking the VLounge Advanced icon () on the desktop.
- PHILIPS
 VLounge Advanced

 File
 Edit
 Help

 File
 Edit
 Help

 Captore
 1093 captore

 Wickes
 Image 1
 Image 2

 File
 Image 1
 Image 2

 Image 1
 Image 2
 Image 3

 Image 1
 Image 4
 Image 5

 Image 7
 Image 6
 Image 12

 Image 7
 Image 6
 Image 12
- > The VLounge Advanced application will now be initiated and the VLounge selection screen appears.

- In the 'Capture' menu you can transfer, preview, edit, e-mail, print and organise your photos and video recordings.
- For additional support read the 'Help' documentation within the 'Help' option of the menubar of VLounge Advanced.

Skype

You can download and install Skype via the Skype website:

http://www.skype.com.

Please follow the on-screen instructions during downloading and installation of Skype.

Using the applications

MSN Messenger

You can download and install MSN Messenger via Microsoft MSN Messenger websites. In the list below you will find the website address for your country for downloading MSN Messenger:

Austria - http://messenger.msn.at Belgium (Dutch) - http://messenger.msn.be Belgium (French) - http://messenger.fr.msn.be Denmark - http://messenger.msn.dk Finland - http://messenger.msn.fi France - http://messenger.msn.fr Germany - http://messenger.msn.de Italy - http://messenger.msn.it The Netherlands - http://messenger.msn.nl Norway - http://messenger.msn.no Portugal - http://messenger.msn.com Spain: - http://messenger.msn.es Sweden - http://messenger.msn.se Switserland (German) - http://messenger.msn.ch Switserland (French) - http://messenger.fr.msn.ch United Kingdom - http://messenger.msn.co.uk USA - http://messenger.msn.com

Please follow the on-screen instructions during downloading and installation of MSN Messenger.

Using the applications

Yahoo! Messenger

You can download and install Yahoo! Messenger via Yahoo! Messenger websites. In the list below you will find the website address for your country for downloading Yahoo! Messenger:

Austria - http://messenger.yahoo.com Belgium - http://dk.messenger.yahoo.com/ Denmark - http://dk.messenger.yahoo.com/ Finland - http://messenger.yahoo.com/ Germany - http://de.messenger.yahoo.com/ Italy - http://it.messenger.yahoo.com/ The Netherlands - http://messenger.yahoo.com/ Norway - http://no.messenger.yahoo.com/ Portugal - http://no.messenger.yahoo.com/ Portugal - http://messenger.yahoo.com/ Spain - http://es.messenger.yahoo.com/ Sweden - http://se.messenger.yahoo.com/ Switserland - http://messenger.yahoo.com/ United Kingdom - http://uk.messenger.yahoo.com

Please follow the on-screen instructions during downloading and installation of Yahoo! Messenger.

AOL Instant Messenger

You can download and install AOL Instant Messenger via the America Online website. Please find below the website address for downloading AOL Instant Messenger:

http://www.aim.com/

Please follow the on-screen instructions during downloading and installation of AOL Instant Messenger.

Making snapshots using Windows® XP

You can use Microsoft[®] Windows[®] XP to make snapshots with your Philips SPC900NC WebCam.

If you need additional support, please refer to the 'Help' topics of Microsoft[®] Windows[®] XP. Search for 'Get picture'.

Technical specifications

SensorVGA CCD
Video resolution (Max.)VGA (640 x 480)
Image resolution (Max.)I.3 MP (1280 x 960)
Illumination
Integrated lensF=2.8
Data formatI420, IYUV
InterfacingUSB 2.0 compatible (2.1 m USB cable)
MicrophoneBuilt in digital microphone
PowerSupplied via USB cable
Voltage requirements

Important information

Disclaimer

Philips makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Philips assumes no responsibility for any error that may appear in this document. Philips makes no commitment to update nor to keep current the information contained in this document.

FCC compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- I this device may not cause harmful interference, and
- **2** this device must accept any interference received, including interference that may cause undesired operation.

Note!

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any unauthorized modification to this equipment could result in the revocation of the authorization to operate the equipment.

Important information

Environmental information

Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

WARNING

Plastic bags can be dangerous. To avoid danger of suffocation, keep this bag away from babies and small children.

System requirements

- Microsoft[®] Windows[®] 98SE/2000/ME or XP;
- Pentium[®] III, 500 Mhz or equivalent;
- 128MB RAM and 100 MB free hard disk space;
- One free USB port and CD-ROM or DVD drive.

Disclaimer of warranty

The software on the CD-ROM supplied is sold 'as is' and without warranties whether expressed or implied. Because of the various software and hardware environments into which this program may be put, no warranty of fitness for a particular purpose is offered.

Limitations of damages

The vendor will not be liable for any indirect, special, incidental or consequential damages (including damages for loss of business, loss of profits, or the like), whether based on breach of contract, tort (including negligence), product liability or otherwise, even if the vendor or its representatives have been advised of the possibility of such damages and even if a remedy set forth herein is found to have failed its essential purpose.



