

## Addendum User Manual

### Light Ring Operation Clarification for TAFB1

This document serves to clarify the actual operation of the light ring feature on the TAFB1, which differs from what is stated in the manual.

### Current Manual Description vs. Actual Operation

The manual states that the light ring operation is tied specifically to Dolby Atmos detection. However, the actual behavior is different and more inclusive:

- The light ring activates whenever height channel audio is active, not just during Dolby Atmos playback
- Height channel activation occurs during:
  - Dolby Atmos content
  - Upmixed audio
  - AI surround mode selection

### Correct Light Settings Behavior

The light settings should be understood as follows:

- **AUTO:** Light ring turns on for 10 seconds when height channel becomes active
- **ON:** Light ring stays on continuously when height channel is active
- **OFF:** Light ring remains off regardless of audio format or height channel status

This clarification supersedes the information provided in the manual on page 23.