






1



2



3



3 Overview

- ① Cool shot button
- ② Temperature settings
- ③ Airflow settings
- ④ Hanging loop
- ⑤ Moisture protect button
- ⑥ Nozzle
- ⑦ Diffuser
- ⑧ Air inlet grille

4 Dry your hair

- 1 Connect the plug to a power supply socket.
- 2 Attach the nozzle (⑥) or volume diffuser (⑦) for your styling needs.
- For precise drying, attach the nozzle on the hair dryer. The nozzle enables you to direct the airflow straight at the brush or comb with which you are styling your hair.
- To enhance volume for curls and bouncy style, attach the diffuser on the hair dryer. Hold the hairdryer vertically and place the hair in a circular motion in between pins and move towards scalp slowly.
- To add volume at the roots, insert the pins into your hair by making rotating movements. It helps to dry your hair roots and scalp without hot spot.
- 3 Adjust the airflow switch (③) and temperature switch (②) to suitable positions.
- 4 Switch on MoistureProtect (⑤) for more protection. The moisture protect is on when using for the first time.
 - ↳ The purple LED light on the product indicates the moisture protect sensor is on.

Switch	Settings	Function
MoistureProtect	⑤	Protect the hair from overheating and preserve the natural hydration of your hair
Temperature	☹ Hot	Dry shower-wet hair quickly
	恒温 Thermoprotect	Dry your hair at a constant caring temperature
	●	Gently dry the hair
Airflow	II	Strong airflow and fast drying
	I	Gentle airflow and styling
	○	Switch off

- 5 Press the cool shot button (①) for cool airflow to fix your style.

After use:

- 1 Switch off the appliance and unplug it.
- 2 Place it on a heat-resistant surface until it cools down.
- 3 To disconnect the nozzle or volume diffuser, pull it off the hairdryer.
- 4 Press the latch to detach the air inlet grille (⑧) to remove hair and dust.
- 5 Clean the appliance by a damp cloth.
- 6 Keep it in a safe and dry place, free of dust. You can also hang it with the hanging loop (④).

5 Guarantee and service

If you need information e.g. about replacement of an attachment or if you have a problem, please visit the Philips website at www.philips.com.cn/support or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guarantee leaflet. If there is no Consumer Care Centre in your country, go to your local Philips dealer.

6 Troubleshooting

Problem	Cause	Solution
The appliance does not work at all.	The power socket to which the appliance has been connected may be broken.	Check the appliance is plugged in correctly. Check the fuse for this power socket in your home.
	The appliance may have overheated and switched itself off.	Unplug the appliance and let it cool down for a few minutes. Before you switch on the appliance again, check the grilles to make sure they are not blocked by fluff, hair, etc.
	The appliance may not be suitable for the voltage to which it has been connected.	Ensure that the voltage indicated on the type plate of the appliance corresponds to the local power voltage.
There is bad smell for the first-time of use.	The smell may come from the new appliance.	The smell will gradually disappear after a few uses. Please try to dry/style your hair in a well-ventilated room.
There is burning smell when drying/styling my hair.	If there is some dust or residue left in the appliance, it may be burnt due to the high temperature and produce odor.	Turn off the appliance and wait until it cools down. Check if any residues left. Remove the dirty stuffs from the appliance and keep it clean.

简体中文

感谢您的惠顾，欢迎光临飞利浦！为了您能充分享受飞利浦提供的支持，请在 www.philips.com.cn/welcome 注册您的产品。

1 重要事项

使用产品之前，请仔细阅读本用户手册，并妥善保管以供日后参考。

- 警告：请勿在靠近水的地方使用本产品。
- 在浴室内使用产品后需拔下插头，即使产品已关闭，近水放置仍存在危险。
- 警告：不要在盛水的浴缸、淋浴、洗脸盆或其他器皿附近使用本器具。
- 警告符号注释：禁止在洗澡或淋浴时使用。

• 使用后务必拔下产品的插头。

- 如果产品过热，它将自动关闭电源。拔掉产品插头，让其冷却几分钟。再次启动产品之前，请检查出风口，确保其未被绒毛、头发等杂物堵塞。
- 如果电源软线损坏，为了避免危险，必须由制造商、其维修部或类似部门的专业人员更换。
- 本产品可以由 8 岁或以上年龄的儿童以及肢体不健全、感觉或精神上有所障碍或缺乏相关经验和知识的人士使用，但前提是有人对他们使用本产品进行监督或指导，以确保他们的安全使用，并且让他们明白相关的危害。不得让儿童玩耍本产

品。不要让儿童在无人监督的情况下进行清洁和保养。

为了增加保护，建议在浴室供电的电气回路中安装一个额定剩余工作电流不超过 30mA 的剩余电流装置 (RCD)。详情请向 RCD 安装商咨询。

• 切勿将金属物体插入风口，以免触电。

• 切勿阻塞电吹风风口。

• 连接产品之前，请确保产品上标示的电压与当地电源电压相符。

• 请勿将本产品用于本手册中说明以外的任何其它用途。

• 请勿对假发使用本产品。

• 当产品连接了电源时，切勿让其无人看管。

• 切勿使用由其它制造商生产的，或未经飞利浦特别推荐的任何附件或部件。如果使用此类附件或部件，您的保修将失效。

• 切勿将电源线缠绕在产品上。

• 待产品完全冷却后再存放。

• 使用后请勿拉扯电源线。拔下产品插头时，请握紧插头。

• 切勿用湿手操作本产品。

• 产品只能送到飞利浦授权的服务中心检修。由不合格人员进行修理可能将用户置于极度危险的境地。

电磁场 (EMF)

本飞利浦产品符合所有有关暴露于电磁场的适用标准和法规。

回收

-弃置产品时，请不要将其与一般生活垃圾堆放在一起，应将其交给政府指定的回收中心。这样做有利于环保。

-遵守有关国家和地区关于弃置电子及电器产品的规定。正确弃置产品有助于减少对环境对人类健康产生负面影响。

2 简介

MoistureProtect 电吹风采用创新的保湿传感器技术。该技术专为保持头发的自然滋润而设计。红外传感器可在干发时

测量头发的温度，分析并调整风热，以保持头发的自然滋润。这可为头发和头皮提供先进的保护，防止过热现象产生，让您的秀发更健康、亮泽。我们已经打开了传感器，因此您从一开始就可以享受完善的保护。

产品接通电源后，可自动且持续地释放负离子，令秀发更加顺滑、亮泽。

产品接通电源后，可自动且持续地释放负离子，令秀发更加顺滑、亮泽。

产品接通电源后，可自动且持续地释放负离子，令秀发更加顺滑、亮泽。

3 概览

- ① 冷风喷出钮
- ② 温度设置
- ③ 风速设置
- ④ 挂环
- ⑤ Moisture Protect 按钮
- ⑥ 集风嘴
- ⑦ 扩散风嘴
- ⑧ 进风口

4 吹干头发

- 1 将插头连接至电源插座。
- 2 根据造型需要安装集风嘴(⑥)或扩散风嘴(⑦)。

English

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com.cn/welcome.

1 Important

Read this user manual carefully before you use the appliance and keep it for future reference.

- **WARNING:** Do not use this appliance near water.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.
- **WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- Always unplug the appliance after use.
- If the appliance overheats, it switches off automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grilles to make sure they are not blocked by fluff, hair, etc.
- If the main cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the

hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- For additional protection, we advise you to install a residual current device (RCD) in the electrical circuit that supplies the bathroom. This RCD must have a rated residual operating current not higher than 30mA. Ask your installer for advice.
- Do not insert metal objects into the air grilles to avoid electric shock.
- Never block the air grilles.
- Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.
- Do not use the appliance for any other purpose than described in this manual.
- Do not use the appliance on artificial hair.
- When the appliance is connected to the power, never leave it unattended.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not wind the main cord round the appliance.
- Wait until the appliance has cooled down before you store it.
- Do not pull on the power cord after using. Always unplug the appliance by holding the plug.
- Do not operate the appliance with wet hands.
- Always return the appliance to a service centre authorized by Philips for examination or repair. Repair by unqualified people could result in an extremely hazardous situation for the user.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Recycling

-Do not throw away the appliance with the normal household waste at the end of its life, but hand it in an official collection point for recycling. By doing this, you help to preserve the environment.

-Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

2 Introduction

The MoistureProtect dryer has an innovative new sensor technology called the Moisture Protect sensor. This technology has been specifically designed to preserve the natural hydration of your hair. The infrared sensor measures the temperature of your hair while drying it, diagnoses your hair and adapts the temperature to preserve its natural hydration. This gives advanced protection to your hair and scalp from overheating and therefore keeps your hair healthier and shinier. We've already turned the sensor on so you can enjoy maximum protection right from the start.

When the appliance is powered on, ions are automatically and continuously dispensed, reducing frizz and providing additional shine.



- 要集中风力，请将集风嘴安装到电吹风上。集风嘴可以将气流集中到您用于造型的发梳上。
- 要提高头发蓬松度，塑造丰盈且有弹性的造型，可将扩散风嘴安装到电吹风上。垂直握住电吹风，将头发放置在梳齿之间进行旋转，并缓慢移动至发根。要增加发根的丰盈度，可将扩散风嘴的梳齿插入头发，作旋转运动。这有助于吹干发根和头皮，且不会烫伤。
- 将风速开关 (③) 和温度开关 (②) 调至适当的位置。
- 打开 MoistureProtect ⑤ (⑤) 以带来更多保护。首次使用时，保湿功能是打开的。
 - 产品上的紫色 LED 指示灯用于指示保湿传感器已开启。

开关	设置	功能
Moisture-Protect	⑤	防止头发过热，保持头发的自然滋润
温度	🌀 热风	快速吹干湿透的头发
	恒温	在恒定护理温度下吹干头发
	●	轻柔地吹干头发
风速	II	产生强风，快速吹干头发
	I	产生柔风，用于定型
	○	关闭

- 按冷风喷出按钮 (①) 可获得冷风用于定型。

使用后：

- 请关闭产品并拔下电源插头。
- 将产品置于隔热表面上，直至其冷却。
- 要卸下集风嘴或扩散风嘴，请将其从电吹风中拉出。
- 按下门锁拆下进风口盖 (⑧) 以清除毛发和灰尘。
- 用湿布擦拭产品。
- 将产品存放在安全、干燥、清洁的位置。您也可以使用挂环 (④) 将产品挂起存放。

5 保修与服务

如果您需要了解有关信息（如更换附件的相关信息）或有任何疑问，请访问飞利浦网站 www.philips.com.cn/support。您也可以与您所在国家/地区的飞利浦客户服务中心联系。在全球保修卡中可找到其电话号码。如果您所在的国家/地区没有飞利浦客户服务中心，请向当地的飞利浦经销商求助。

6 故障排除

问题	原因	解决方法
产品完全无法工作。	产品所连接的电源插座可能已损坏。	检查设备已正确插入。 检查您家中电源插座的保险丝。
	产品可能过热，因此自动断电。	拔掉产品插头，让其冷却几分钟。再次打开产品电源之前，请检查出风口，确保没有被绒毛、头发等杂物堵塞。
	产品连接的电源电压可能与产品电压不符。	确保产品型号铭牌上标示的电压与当地电源电压相符。
首次使用时有异味。	气味可能来自新产品。	使用几次后，气味将逐渐消失。请尝试在通风良好的房间内吹干头发/造型。
吹干头发/造型时有烧焦的气味。	如果产品中残留了一些灰尘或残留物，则可能会因高温而燃烧，并产生气味。	关闭产品电源，等待其冷却。检查是否有残留物。 从产品中取出脏物，并保持清洁。

保留备用

出版日期：2021-10-19

PHILIPS

产品：飞利浦电吹风
型号：HP8281
额定电压：220V~
额定频率：50Hz
额定输入功率：2200 W
生产日期：请见产品本体
产地：中国广东东莞



珠海经济特区飞利浦家庭电器有限公司
珠海市金湾区三灶镇定湾二路365号
全国顾客服务热线：4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.15-2008, GB4343.1-2018及 GB17625.1-2012制造



保修及服务

飞利浦提供二年全球联保服务，在产品保修期限内，若发生因制造工艺或元器件造成的质量问题，飞利浦中国维修服务中心将为持有真实有效购物凭证的消费者提供免费维修服务，或视情况更换零件，部件或整机产品。保修期自真实有效购物凭证所示日期开始起算。消费者在质保期内或质保期后，皆可在中国区享受飞利浦售后维修服务，若该产品非在中国区域内销售，则可能因未储备所需零件导致维修时间较长。若您需洽询相关资讯，请关注飞利浦官方微信公众号“飞利浦健康生活”。

同时，根据国家三包政策，所购产品在7日内（含）发生质量问题的，可凭发票联系销售商进行退换货；所购产品在15日内（含）发生质量问题的，可凭发票联系销售商进行换货。

飞利浦始终致力于为为消费者提供更为便捷的服务体验，根据用户需求，提供多种寄修服务（个护类和母婴护理类产品）：

- 用户可将故障产品快递至飞利浦特约维修站，待产品修复后，飞利浦特约维修站会快递回给用户，用户需承担来回的快递运费。（此寄修服务仅限于个护类产品）
- 母婴护理类产品提供先寄后取的双向免运费寄修服务，飞利浦特约维修站和用户远程确认产品故障后，会先安排邮寄新主机给用户，随后再取回故障机。

保修条款

在购买日起的二年内，凡经本公司特约维修站人员确认为正常使用情况下，因制造工艺或元器件损坏所引起的性能问题，您都将获得免费保修服务。

此免费服务不包括时常更换的易耗零配件及附件（如剃须刀刀网、刀头，牙刷机刷头，洁面刷刷头，脉冲光脱毛器探头，婴儿辅食机杯子，刀具等），辅助装置，运输费及维修人员上门服务费。

飞利浦使用原厂配件提供保修服务。为确保消费者尽快正常使用产品，创造优质服务体验，飞利浦可选择以更换部件的方式提供快速维修服务，而不进行元件级维修。更换下来的零部件或整机所有权将归飞利浦拥有并回收处理。

注：为快速维修而更换的部件，包括电动牙刷/洁牙器手柄、剃须刀手柄、洁面刷手柄、电动吸乳器主机等为产品部件而非整机，如非维修必要在更换时不另配产品附件或包装。

免费维修或更换零配件后的产品保修期为下列期限中的较长者：

- 原保修期的剩余期限
- 维修或更换零部件后交付您之日起90日
- 适用的法律规定的期限

用户请保留此卡。

此卡若经涂改即作废。

此卡须联同有效的购物凭证一起使用方为有效。

以下情况将不能获得免费服务。

- 使用不当引起的人为损坏，例如接入不当电源、使用不当配件、不适当之安装、不遵循说明书使用、错误使用或疏忽而造成损坏等、因运输及其他意外而造成之损坏、非经本公司认可之维修和改装、其他因不可抗力（如自然灾害、电压异常等）造成的损坏。
- 一般家庭以外使用（如工业、商业用）而造成的损坏。
- 正常使用引起的产品老化、磨损等，但不影响产品的正常使用。

质保卡作为在规定期限及条件之内进行免费维修的保证，并不限制消费者的法定权利。

飞利浦提供2年全球联保服务，在产品由飞利浦正式销售的所有国家中，都提供保修和保修期满后的维修服务。申请保修时，您需提供真实有效的购物凭证，且申请日期需在保修期限之内。

保修条款如有细微调整或变更，均以飞利浦官方网站保修政策为准。

加入飞利浦会员

注册会员即享官网购物专属会员价，更多飞利浦会员回馈等你来拿。

扫一扫 立即加入



或搜索并关注 微信公众号
“飞利浦健康生活”

消费者服务热线：
4008 800 008（用户需承担本地通话费）



飞利浦微信售后小程序



网址：www.philips.com.cn

4222.005.0422.8

产品中有害物质的名称及含量		有害物质					
部件名称	马达	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
负离子发生器		X	○	○	○	○	○
电子元件		X	○	○	○	○	○
电源线		X	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
X：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

*该表格中所显示的“有害物质”在产品正常使用情况下不会对人身和环境产生任何伤害。

*该表格中所显示的“有害物质”及其存在的部件向消费者和回收处理从业者提供相关材料物质的存在信息，有助于产品废弃时的妥善处理。