



## 1 Insert batteries







## 2 Connect TV



Connect the Scart socket on the TV to the Scart socket (to TV) on the Streamium System with the supplied Scart cable. If your TV has no Scart socket, please see page 12 of the user's manual.

## 3 Connect speakers and antenna

Match the colours of the speaker cables and of the speaker sockets!




**1** Connect the speaker cables to the base of the subwoofers.

**2** Mount the 2 front speakers (white, red socket) onto the 2 subwoofers.

**3** Mount the 2 mini speaker stands onto the 2 rear speakers (blue, grey socket) and connect the corresponding speaker cables.

**4** Position the speakers.



**5** Connect the speaker cables to the Streamium System.

**6** Connect the FM and the MW antenna.

**7** After making all other connections connect the mains cable to MAINS ~ on the Streamium System and to the wall socket.

## 4 Install the tuner

- 1 Press TUNER on the remote control.
- 2 Press and hold VIEW FAVORITES on the remote control for 5 seconds.  
→ AUTO PROGRAM FAVORITE STATIONS? is displayed.
- 3 Press the red button (SUBTITLE) on the remote control to start the installation of radio stations.  
→ It may take several minutes to search and store the radio stations.

## 5 Switch on the TV

- 1 Switch on your TV.
- 2 Press AUX on the remote control of the Streamium System.
- 3 Set the TV to the correct audio/video channel for the Streamium System: AV IN, AUX, EXT1, 2, ...  
→ The Philips Streamium startup screen will appear on the TV screen.


**If you have any problems with the picture quality, please read page 15 of the user's manual.**

## 6 Install the Philips Media Manager

With the installation of the Philips Media Manager software on your computer, you can make the media files on your computer available to the Streamium System.

- 1 Download the latest version of the Philips Media Manager software at "My.Philips.com" or insert the supplied CD-ROM into the CD-ROM drive of your computer.
- 2 Double-click the "PMMSetup.exe" file to install the Philips Media Manager software on your computer(s). During the installation you will be asked which media files should be added to the Philips Media Manager.


## 7 Option A




**You have**

- a computer with a free USB port (USB 2.0 recommended)
- Windows 98 SE or later

With the installation of the supplied wireless USB adapter on your computer you get a wireless connection to the Streamium System. Then you can access the media files of your computer with your Streamium Home Entertainment System.



computer



computer


### Install the supplied wireless USB adapter on your computer

- 1 Insert the installation disc of the USB adapter into the disc drive of your computer. The installation guide on the CD-ROM will start automatically.
- 2 Follow the on-screen instructions on the computer. Connect the wireless USB adapter to the free USB port on your computer when the installation guide asks you to do so.

### Play music, picture and video from your computer with the Streamium System


- 1 Press PC LINK on the remote control.  
→ The computer name will appear on the TV screen.
- 2 Press to access music, pictures and video on your computer.

**If you have trouble connecting to the computer, press PC LINK again. See page 21 of the user's manual for additional help.**



or

## Option B



**You have**

- broadband Internet
- a wireless base station (not included)
- computer connected to the wireless network  
PC: Windows 98 SE or later;  
Apple Macintosh: Mac OS 10.1.5 or higher

First, make sure all computers of your network connect to the Internet and to each other.


### Play online music, picture and video services with the Streamium System

- 1 Press INTERNET on the remote control.  
→ You will be asked to enter your email address.
- 2 Use the remote control to enter your email address and press to confirm.  
Example: Press twice for "@". To delete a character, press .
- 3 You will receive an email with instructions on how to create your user account at "My.Philips.com".
- 4 After creating your user account, press INTERNET on the remote control to access online media services.

### Play music, picture and video from your computer with the Streamium System

- 1 Press PC LINK on the remote control.  
→ The available computer names will appear on the TV screen.
- 2 Select a computer and press to access music, pictures and video on the computer.

**If you have trouble connecting to the Internet or to your computers, press INTERNET or PC LINK again. See pages 19-20 in the user's manual for additional help.**



## 8 Select and play media



- 1 Press ▲ or ▼ to move up or down in the menu.
- 2 Press ► to enter the menu to the right.




- 3 Repeat step 1 and 2 to navigate to the desired playable item (Internet radio station, movie, album, track, ...)



- 4 Press ►OK to play the playable item.
  - To go back to the previous (left) menu, press ◀.
  - To stop playback, press ■.


## 9 Play a disc



- 1 Press DVD on the remote control.




- 2 Press DISC 1 (OPEN/CLOSE ▲) to open tray 1.
- 3 Insert a disc into tray 1.
- 4 Press DISC 1 (OPEN/CLOSE ▲) to close tray 1.



- 5 Press ►OK to start playback. Some discs will start automatically.
  - To skip to previous or following chapters/tracks, press ◀◀ or ▶▶ repeatedly.

Please visit <http://My.Philips.com>



connectedplanet