



EN User manual ZH-T 使用手冊



© 2021 Philips Domestic Appliances Holding B.V. All rights reserved. 6508 000 0744 9 (08/05/2021)

English

Important

Read this important information leaflet carefully before you use the rice cooker and save it for future reference.

Danger

- The appliance must not be immersed.

Warning

- This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities,

- or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.
This appliance should be positioned in a stable situation with the handles (if any) positioned to avoid spillage of the hot liquids.
This appliance is intended to be used in household and similar applications such as:
staff kitchen areas in shops, offices and other working environments;
farm houses;
by clients in hotels, motels and other residential type environments;
bed and breakfast type environments.
If the power cord set is damaged, it must be replaced by a cord set available from the manufacturer.
The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
Surface of the heating element is subject to residual heat after use.
WARNING: Make sure to avoid spillage on the power connector to avoid a potential hazard.

- WARNING: Always follow the instructions and use the appliance properly to avoid potential injury.
According to the instructions prescribed in this user manual, use a soft damp cloth to clean the surfaces in contact with food and make sure to remove all the food residues stuck to the appliance.
Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect it.
Only connect the appliance to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.
Do not use the appliance if the plug, the power cord, the inner pot, the sealing ring, or the main body is damaged.
Do not let the power cord hang over the edge of the table or worktop on which the appliance stands.
Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
Do not plug in the appliance or press any of the buttons on the control panel with wet hands.

- Caution
Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
Do not expose the appliance to high temperatures, nor place it on a working or still hot stove or cooker.
Do not expose the appliance to direct sunlight.
Place the appliance on a stable, horizontal, and level surface.
Always put the inner pot in the appliance before you put the plug in the power outlet and switch it on.
Do not place the inner pot directly over an open fire to cook rice.
Do not use the inner pot if it is deformed.
The accessible surfaces may become hot when the appliance is operating. Take extra caution when touching the appliance.
Beware of hot steam coming out of the steam vent during cooking or out of the appliance when you open the lid. Keep hands and face away from the appliance to avoid the steam.
Do not lift and move the appliance while it is operating.
Do not exceed the maximum water level indicated in the inner pot

- to prevent overflow which might cause potential hazard.
Do not place the cooking utensils inside the pot while cooking, keeping warm or reheating rice.
Only use the cooking utensils provided. Avoid using sharp utensils.
To avoid scratches, it is not recommended to cook ingredients with crustaceans and shellfish. Remove the hard shells before cooking.
Do not insert metallic objects or alien substances into the steam vent.
Do not place a magnetic substance on the lid. Do not use the appliance near a magnetic substance.
Always let the appliance cool down before you clean or move it.
Always clean the appliance after use. Do not clean the appliance in a dishwasher.
Always unplug the appliance if not used for a longer period.
If the appliance is used improperly or for professional or semiprofessional purposes, or if it is not used according to the instructions in this user manual, the guarantee becomes invalid and Philips refuses liability for any damage caused.

Electromagnetic fields (EMF)
This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.





- 繁體中文
重要事項
使用電飯煲前，請先閱讀本重要資訊手冊，並妥善保管以供日後參考。
危險事項
本產品不得浸水。
警告
本產品並不適合身體感覺或心智能力低下人士（包括兒童），或缺乏知識及經驗人士使用，除非該人士已接受其他負責其安全之人士就使用本產品的監督或指導。
兒童應受監督以確保他們不會以本產品玩耍。
本產品應置於固定位置，把手應移至合適方向（如有），以防止灼熱液體濺出。
此產品適用於家居及類似的場所，譬如：
店舖、辦公室和其他工作環境的員工廚房；
農舍；
供酒店、汽車旅館或其他居住環境中的住客使用；
給提供住宿加早餐的旅館使用。
如果電源線組損壞，必須以製造商提供的電線組替換。

- 本電器不得以外部計時器或其他遙控系統操作使用。
加熱元件表面可能會在使用過後尚有餘熱。
警告：請避免電源適配器洩漏，避免發生危險事故。
警告：請遵循此說明並適當地使用本產品，避免發生潛在傷害。
根據用戶手冊中所載之指引，請使用柔軟的濕布清潔與食物接觸的表面，確保清除所有沾粘於產品中的食物殘渣。
在連接本產品前，請檢查產品註明的指示電壓與當地電源電壓是否對應。
僅將本產品連接上接地的電源插座。務必確保插頭已穩固插入電源插座。
如插頭、電源線、內鍋、密封圈或機身受損，切勿使用本產品。
請勿讓電源線懸掛於放置在本產品的桌面或工作檯邊緣。
將插頭插入電源插座前，確保加熱元件、溫度感應器及內鍋外部清潔乾爽。
請勿用濕手插入本產品的電源，或按下控制面板的按鈕。

- 注意
請勿使用任何其他廠商製造而非 Philips 特別建議使用的配件或零件。如使用該等配件或零件，您的保障將會失效。
請勿將產品暴露於高溫之中，也不要放置於正在使用或仍然燙熱的爐子或廚具上。
請勿將產品暴露於直射陽光下。
將產品放置於穩固、平坦的水平表面上。
將插頭插入電源插座並開啟之前，務必將內鍋放入電壓鍋裡。
請勿將內鍋直接放置在開放火源上煮飯。
如內鍋變形，則請勿使用。
產品運作期間，可接觸的表面或會變熱。接觸本產品時必須格外小心。
烹調期間，應留意蒸氣通氣孔噴出的熱蒸氣；開蓋時，亦應留意本產品噴出的熱蒸氣。將雙手及臉部遠離本產品，以免受蒸氣燙傷。
產品運作時，請勿將其抬起或移動。
請勿超出內鍋內部註明的最高水位，以防止液體溢出，避免發生危險事故。






- 烹調、保暖或翻熱米飯期間，請勿將廚具放入鍋內。
僅使用隨附的廚具。避免使用尖銳的廚具。
為了避免刮花，不建議連同甲殼類或貝類烹調材料。烹調前取下硬殼。
請勿將金屬物件或異物插入蒸氣通氣孔。
請勿將磁性物質放在蓋上。請勿在磁性物質附近使用本產品。
清潔或移動本產品之前，務必讓本產品冷卻下來。
使用後請清潔本產品。請勿將本產品放入洗碗機內清洗。
如長時間不使用本產品，務必拔除本產品的插頭。
如不當使用本產品、使用本產品作專業或半專業用途，或沒有按照本用戶手冊的說明使用本產品，保用將會無效，而 Philips 亦拒絕承擔任何造成的損毀。

電磁場 (EMF)
這款 Philips 產品符合一切有關電磁場暴露的適用安全標準及條例。



Tip
After the cooking is finished, stir the brown rice and loosen it immediately to release excessive moisture for fluffy rice.

Note
Depending on the cooking conditions, the bottom portion of the brown rice may become slightly browned.



Congee and Soup (Fig 6)

Note
It is normal to find the congee stickier if it left in keep warm mode for too long. Do not exceed the maximum water level indicated in the inner pot, as this may cause the multicooker to overflow.

Table with 3 columns: Menu, Default cooking time, Cooking time regulation range. Rows: Congee, Soup.








Table with 3 columns: Menu, Default cooking time, Cooking time regulation range. Rows: Reheat.

- 1 Loosen the cooled rice and evenly distribute it in the inner pot.
2 Pour some water onto the rice to prevent it from becoming too dry. The quantity of the water depends on the amount of rice.
3 Close the lid of the rice cooker, and put the plug in the power socket.
4 Press <Left> or <Right> until the Reheat function is selected.
5 Press Start to start the cooking.
6 When the cooking is finished, the cooking indicator will be off. The rice cooker switches to the keep warm mode automatically.
The Warm indicator lights up.

Reheat (Fig 7)

Table with 3 columns: Menu, Default cooking time, Time regulation range. Row: Reheat.

- 1 Measure the brown rice using the measuring cup provided. Wash the brown rice thoroughly, and put the pre-washed rice in the inner pot.
2 Add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Then smooth the rice surface.

Brown (Fig 5)

Table with 3 columns: Menu, Default cooking time, Cooking time regulation range. Row: Brown.





Cake (Fig 8)

Table with 3 columns: Menu, Default cooking time, Cooking time regulation range. Row: Cake.

- 1 Whisk the ingredients for cake well.
2 Coat the inner pot with some butter or cooking oil, and then pour the cake mixture into it.
3 Close the lid of the rice cooker, and put the plug in the power socket.
4 Press <Left> or <Right> until the Cake function is selected.
5 Press Start to start the cooking.
6 When the cooking is finished, the cooking indicator will be off. The rice cooker switches to the keep warm mode automatically.
The Warm indicator lights up.
7 Open the lid and carefully take out the inner pot to cool down.
8 After the inner pot is cool down, put a plate or cake rack on top of the pot, and then flip over to take the cake out.

How to cook cakes

- 1 Preparation of raw material:
Small quantity:
- 3 eggs
- 100g white sugar (about 2/3 cup)
- 100g cake powder (about 1 cup)
- 50g butter (about 1/3 cup)
- 18g milk (about 1/10 cup)



Reheat (Fig 7)

- 1 Loosen the cooled rice and evenly distribute it in the inner pot.
2 Pour some water onto the rice to prevent it from becoming too dry. The quantity of the water depends on the amount of rice.
3 Close the lid of the rice cooker, and put the plug in the power socket.
4 Press <Left> or <Right> until the Reheat function is selected.
5 Press Start to start the cooking.
6 When the cooking is finished, the cooking indicator will be off. The rice cooker switches to the keep warm mode automatically.
The Warm indicator lights up.
7 Open the lid and carefully take out the inner pot to cool down.
8 After the inner pot is cool down, put a plate or cake rack on top of the pot, and then flip over to take the cake out.

How to cook cakes

- 1 Preparation of raw material:
Small quantity:
- 3 eggs
- 100g white sugar (about 2/3 cup)
- 100g cake powder (about 1 cup)
- 50g butter (about 1/3 cup)
- 18g milk (about 1/10 cup)

English

1 Your rice cooker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.Philips.com/welcome.

What's in the box (Fig 1)

Table with 2 columns: Item, Description. Rows: Rice cooker main unit, Measuring cup, Power cord, Warranty card, Rice scoop, Steam basket, User manual.

Overview (Fig 2)

Table with 2 columns: Number, Description. Rows: 1-17.

Controls overview (Fig 3)

Table with 2 columns: Number, Description. Rows: 18-24.

2 Using the rice cooker

Tip
To cancel the cooking programs, press Warm/Off button, the rice cooker

Before first use

- 1 Take out all the accessories from the inner pot. Remove the packaging material of the inner pot.
2 Before first use, boil water and clean the rice cooker.

3 Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see chapter "Cleaning").

Note

- Make sure all parts are completely dry before you start using the rice cooker.

Rice (Fig 4)

Table with 3 columns: Menu, Default cooking time, Cooking time regulation range. Rows: Quick, Rice.

- 1 Measure the rice using the measuring cup provided. Wash the brown rice thoroughly, and put the pre-washed rice in the inner pot.
2 Add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Then smooth the rice surface.

Note

- Each cup of uncooked rice normally gives 3 cups of cooked rice. Do not exceed the quantities indicated on the inside of the inner pot.
The level marked inside the inner pot is just an indication. You can always adjust the water level for different types of rice and your own preference. If the voltage is unstable at the area you live, it is possible that the rice cooker overflows.
Besides following the water level indications, you can also add rice and water at 1:1-1:2 ratio for rice cooking. Do not exceed the quantities indicated on the inside of the inner pot.
Use a separate container to wash the rice to avoid damaging the non-stick coating of the inner pot.
Make sure that the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element or the magnetic switch.
The Quick function is for cooking rice only.

3 Wipe the outside of the inner pot dry, then put the inner pot in the rice cooker. Check if the inner pot is in proper contact with the heating element (Fig 2 and 3).

4 Close the lid of the rice cooker, and put the plug in the power socket (Fig 2 and 3).

5 Press <Left> or <Right> to choose Brown (Fig 5).

6 Press the Start button to start the cooking (Fig 6).

7 When the cooking is finished, the cooking indicator will be off. The rice cooker switches to the keep warm mode automatically. The Warm indicator lights up.

