

隨時為您提供協助

請至以下網址註冊您的產品並取得支援：
www.philips.com/welcome

HD2089



EN User manual ZH-TW 使用手冊

PHILIPS



© 2015 Koninklijke Philips N.V.

4241 210 21961

English

1 Your soymilk maker

Congratulations on your purchase, and welcome to Philips!
To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

2 Important

Read this user manual carefully before you use the appliance, and save the user manual for future reference.

Before processing:






- Never add contents (including water) above MAX (the maximum level indication) or below MIN (the minimum level indication).
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
- For their safety, do not allow children to play with the appliance. Keep the appliance and its power cord out of the reach of children.
- Before you connect the appliance to the power, make sure that the voltage indicated on the appliance corresponds to the local power voltage.
- This appliance can only be used with a grounded plug. Make sure that the plug is firmly inserted into the power outlet.
- Make sure that your hands are dry before you insert the plug into the power outlet.
- Make sure surface of both the upper and lower coupler is free from liquid or any conductive medium before putting the lid onto the cup.
- Make sure the surface of both the upper plug connector and the power cord connector is free from liquid or any conductive medium before putting the top unit into the pot.
- Never connect this appliance to a timer switch, to avoid a hazardous situation.
- Before you insert the plug into the power outlet, make sure that the appliance is assembled correctly.
- Make sure that you clean the appliance before use (see the "Cleaning before first use" section).
- Do not use this appliance to heat up soymilk or other liquid foods.
- Never use the appliance for dry heating.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips or similarly qualified persons to avoid a hazard.
- Do not replace parts of the appliance yourself.
- Make sure that the water you add into the soymilk maker is warm in ambient temperature.
- This appliance is intended for household use only.
- This appliance only can be used at areas whose elevation is lower than 2000 meters.

During processing:

- Do not touch the steam vent and the metal parts of the appliance to avoid burns or scalding.
- Do not use this appliance on an unstable or uneven surface.
- Keep the appliance and its power cord out of the reach of children.
- Do not disconnect the power cord or remove the top unit before processing is complete.
- If you have to stop processing, disconnect the power cord before you perform other operations.
- If there is a power outage no less than 3 minutes after processing, do not immediately restart the soymilk maker. Empty the contents, and then put in new ingredients before restarting. Otherwise, the contents will stick to the pot or overflow, or the appliance will set off a long alarm.

After processing:

- To prevent steam scalding, keep a certain distance from the soymilk maker before you turn and lift the top unit.
- Be careful of the trapezoidal blade mill on the top unit, do not cut yourself or others with it.
- To prevent steam scalding, keep a certain distance from the soymilk maker before you turn and lift the top unit.
- Be careful of the trapezoidal blade mill on the top unit, do not cut yourself or others with it.
- Disconnect the power before you continue other operations.
- Before cleaning or disassembling the appliance, disconnect the power cord from the power outlet.



- To prevent a short circuit or an electric shock, do not immerse the base of the pot unit in water as there is a heat vent at the bottom, otherwise water will drip into the electronic components through the heat vent.
- Use a microwave oven to heat up cold soymilk. Do not use this appliance to heat it, as the contents will stick to the inner side of the pot.
- Some foods may discolor the overflow sensor. This is perfectly normal.
- Store the power cord in cool and dry place. To prevent electric shock, do not use the power cord to connect other appliances.

Electromagnetic Fields (EMF)


This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

3 Overview

Product overview (fig. 1)

① Handle of the top unit	⑧ Upper plug
② Control Panel	⑨ Lower part of the top unit
③ Top unit seal (removable)	⑩ Pot unit
④ Overflow sensor - prevent overflowing	⑪ Base
⑤ Trapezoidal blade mill	⑫ Upper plug connector
⑥ Steam vent cap (Removable)	⑬ Pot handle
⑦ Steam vent	⑭ Power cord connector

Controls overview



① Functional indicators	Soymilk	② Program selection button
	Rice paste	③ Start button
	Fruit/veggie drink	④ Easy clean button
	Chunky soup	⑤ Timer display
	Pureed soup	

4 Cleaning before first use (fig. 2)

Method

Pour boiling water into the pot, put the top unit into it, then soak for 10 minutes. (fig. 1 to 6)
Clean the appliance (see the "Cleaning" section).

5 Using the appliance (fig. 3)

Warning

- If you wish to cancel a function after it has started, do not turn and lift the top unit to prevent the facial scalding. You can unplug the power cord, re-plug it, and then selected another function. If the appliance has processed more than 3 minutes, make sure to empty and replace the ingredients and water before restarting the new function.

Measure ingredients as instructed in the recipe. You can adjust the quantity to fit your personal taste. Do not adjust the quantity sharply.

- Clean the supplied measuring cup and stand by:
 - To extend the lifetime of the trapezoidal blade mill, soak the soybeans (2 hours in summer and 4 hours in winter), and wash them thoroughly before processing.
- Turn the top unit anti-clockwise and lift it up. (fig. 1 to 2)
- Put the soybeans evenly at the bottom of the pot. (fig. 3)
- Pour water into the pot. Make sure the water level is between 上水位 (the maximum level indication) and 下水位 (the minimum level indication). (fig. 4)
- Put the top unit into the pot, and turn it clockwise to tightly close the top unit. Make sure that the upper plug is correctly inserted into the connector. (fig. 5 to 6)
- Insert the power cord and connect the power. (fig. 7)
- Press the program selection button (●) to select the function you need. (fig. 8)
 - The selected function indicator lights up and the appliance sounds once.
- Press the start button (●) to start processing. (fig. 8)
 - For Soymilk, you will hear 6 beeps after about 30 minutes, and the process is complete. (fig. 9)
 - For Rice paste, you will hear 6 beeps after about 26 minutes, and the process is complete. (fig. 9)
 - For Fruit/veggie drink, you will hear 6 beeps after about 4 minutes, and the process is complete. (fig. 9)
 - For Chunky soup, you will hear 6 beeps after about 40 minutes, and the process is complete. (fig. 9)
 - For Pureed soup, you will hear 6 beeps after about 25 minutes, and the process is complete. (fig. 9)

Note

- All functions, except Fruit/Veggie Drink, will be in keep warm mode for an hour after they are complete. The function indicator flashes in keep warm mode, and 00 displays on the screen. After the warm keeping is finished, the appliance beeps 5 times, the screen goes off, and the function indicator remains on.
- For Soymilk, Rice paste and Pureed Soup, the appliance constantly stirs the ingredients in keep warm mode. The process is completed and you can unplug the appliance at any time. The food is ready to serve.

- After processing, disconnect the power. Hold the handle of the pot tightly with one hand, then turn it anti-clockwise and lift the top unit with the other hand. (fig. 10 to 12).
- Stir the content well. Then, pour it out directly to the drinking glass, and it is ready to serve. (fig. 13) No filtering is needed. You can add some sugar and stir before serving.

Tip

- After processing, serve at once to avoid oxidation.
- To keep the appliance more durable, wait about 20 minutes or above until the appliance cools down before next use.

6 Cleaning (fig. 4)

Notes

- Disconnect the power and remove the power cord before cleaning or disassembling this appliance.
- To prevent scalding, do not touch the top unit, steam vent cap, inner side of the pot before they cool down.
- Be careful of the trapezoidal blade mill during cleaning to avoid cutting yourself and others.

Warning

- Do not immerse the top unit in water, otherwise, the appliance may malfunction and cannot work.

- Turn the top unit anti-clockwise and lift it up. (fig. 1)
- Rinse the lower part of the top unit, the overflow sensor, the trapezoidal blade mill, and the inner side of the pot with water. Use a cleaning pad to remove the residues. (fig. 2)
- Remove and clean the top unit seal. (fig. 2)
- Remove and clean the steam vent upper cap, the lower cap, and the seal with water. (fig. 3 to 5)
- Use a cleaning pad and water to clean the inner side of the pot. (fig. 6)
- Use a dry cloth to clean the top unit handle, control panel, and power cord connector. The outside of the pot can be cleaned with a damp cloth.

Tip

- Clean the appliance immediately after use.
- Make sure to properly assemble the top unit seal and the steam vent seal back to the top unit and the steam vent respectively after cleaning. Sealing edge must point outward. (fig. 5 and 7)
- If the steam vent cap, the steam vent seal, or the top unit seal is damaged or lost, contact the Philips Consumer Care Center in your country to purchase the new parts.

Easy cleaning

- Promptly clean the residue on the appliance; otherwise, the residue will dry up and stick on the appliance, and become difficult to remove. When this happens, you can use the easy clean function to heat and soak the inner side of the pot and clean the appliance easier.
 - To prevent the residue from smelling, clean the appliance immediately after use.
- Pour water into the pot. Make sure the water level is between 上水位 (the maximum level indication) and 下水位 (the minimum level indication).
 - Put the top unit into the pot. Make sure that the upper plug is correctly inserted into the connector.
 - Insert the power cord and connect the power.
 - Press the easy clean button (●).
 - After about 8 minutes, you will hear 6 beeps, indicating that the easy clean function is complete.
 - Clean the appliance as instructed in the "Cleaning" section.

7 Recipes

For more recipes you can visit Philips MyKitchen website www.philips.com/kitchen.

Soymilk

Recipe	Ingredients	Cooking method
Soymilk	70g of soybeans (a full cup)	Wash and soak the soybeans thoroughly. Place them into the pot. Add water up to the middle of 上水位 (MAX) and 下水位 (MIN). After connecting to the power, select 濃醇豆漿 (Soymilk). Once done, the appliance will sound. Pour the red beans and millet milk to the glass. Then, mix well to taste.
Black bean milk	80g of black beans (a full cup)	
Mung bean milk	85g of mung beans (a full cup)	

Rice paste

Recipe	Ingredients	Cooking method
Complete nutritious rice paste	35g of rice (around 1/2 cup); 15g of millet (around 1/5 cup); 10g of black sesame seeds; 10 peanuts (with shells removed); 5 walnut flesh; 5 chinese dates (with stones removed)	Wash rice, millet, and peanuts. Crush the walnut flesh and break the chinese dates into small pieces. Place them all into the pot. Add water up to the middle of 上水位 (MAX) and 下水位 (MIN). After connecting to the power, select 營養米糊 (Rice Paste). Once done, the appliance will sound. Pour the complete nutritious rice paste to the glass. Finally, add some crystal sugar to taste.

