



PHILIPS

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome. With your new epilator you can remove unwanted hair quickly, easily and effectively. It is suitable for removing hair from your legs, underarms and bikini line.

The rotating discs catch even the shortest hairs (down to 0.5mm) and pull them out by the root.

The hairs that grow back are soft and thin. Epilating with this new appliance leaves your skin smooth and hair-free for several weeks.

This epilator comes with the following attachments:

Sensitive area cap

The sensitive area cap has been specially designed to epilate sensitive areas, such as your underarms and bikini line. It minimises the pulling sensation of epilation in sensitive areas with long-lasting results.

Double wavy massage attachment

The double wavy massage attachment helps to make the depilation extra gentle. It minimises the pulling sensation and gives a more pleasant sensation during epilation. The massage attachment pivots for optimal contour following and can be easily detached for better cleaning.

General description (Fig. 1)

- A** Double wavy massage attachment
- B** Sensitive area cap
- C** Epilating discs
- D** Epilating head
- E** On/off slide
- **O** = off
- **I** = normal speed
- **II** = high speed
- F** Socket for appliance plug
- G** Small plug
- H** Adapter
- I** Cleaning brush

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Keep the appliance and the adapter dry.
- Do not use the appliance near or over a washbasin or bath filled with water (Fig. 2).
- Do not use the appliance in the bath or in the shower (Fig. 3).
- If you use the appliance in the bathroom, do not use an extension cord (Fig. 4).

Warning

- Only use the appliance in combination with the adapter supplied.
- Do not use the appliance or the adapter if it is damaged.
- If the adapter is damaged, always have it replaced with one of the original type in order to avoid a hazard.
- The adapter contains a transformer. Do not cut off the adapter to replace it with another plug, as this causes a hazardous situation.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Caution

- Only epilate the underarms and bikini line with the sensitive area cap attached.
- This appliance is only intended for removing women's body hair on areas below the neck: underarms, bikini area and legs. Do not use it for any other purpose.
- To prevent damage and injuries, keep the **running** appliance (with or without attachment) away from scalp hair; eyebrows, eyelashes, clothes, threads, cords, brushes etc.
- Do not use the appliance on irritated skin or skin with varicose veins, rashes, spots, moles (with hairs) or wounds without consulting your doctor first.

People with a reduced immune response or people who suffer from diabetes mellitus, haemophilia or immunodeficiency should also consult their doctor first.

Your skin may become a little red and irritated the first few times you use the epilator. This phenomenon is absolutely normal and quickly disappears. As you use the appliance more often, your skin gets used to epilation, skin irritation decreases and regrowth becomes thinner and softer. If the irritation has not disappeared within three days, we advise you to consult a doctor.

Do not use the epilating head, sensitive area cap or double wavy massage attachment if it is damaged or broken, as this may cause injury.

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Using the appliance

Note: Clean the epilating head before first use.

Epilation tips

- When you use the appliance for the first time, we advise you to try it out on an area with only light hair growth to get accustomed to the epilation process.
- Epilation is easier just after taking a bath or shower. Make sure your skin is completely dry when you start epilating.
- Make sure your skin is clean, entirely dry and free from grease. Do not use any cream before you start epilating.
- Epilation is easier and more comfortable when the hair has the optimum length of 3–4 mm. If the hairs are longer, we recommend that you shave first and epilate the shorter regrowing hairs after 1 or 2 weeks.
- When you epilate for the first time, we advise you to epilate in the evening, so that any reddening that develops can disappear overnight.
- While epilating stretch your skin with your free hand. This lifts up the hairs and helps to minimise the pulling sensation.
- For optimal performance, place the appliance on the skin at right angles (90°) with the on/off slide pointing in the direction in which you are going to move the appliance. Guide the appliance across the skin against the direction of hair growth in a slow, continuous movement without exerting any pressure.
- On some areas, e.g. the underarms, hair may grow in different directions. In this case, it may be helpful to move the appliance in different directions to achieve optimal results.
- To relax the skin, we advise you to apply a moisturising cream after epilation.
- Fine hair that regrows might not grow up to the skin surface. The regular use of an exfoliating sponge or cream (e.g. during showering) helps to prevent ingrowing hair as the gentle scrubbing action removes the upper skin layer and fine hair can get through to the skin surface.

Connecting the appliance

- 1** Insert the appliance plug into the appliance (Fig. 5).
- 2** Insert the adapter into the wall socket.

Epilating the legs

If you are new to epilation, we advise you to start epilating with the double wavy massage element. This attachment relaxes the skin and minimises the pulling sensation of epilation.

If you already have some experience with epilation, you can simply use the epilating head without any attachment.

Only use the double wavy massage attachment on your legs.

- 1** Put the double wavy massage attachment on the epilating head (Fig. 6).
- The procedure for placing the attachments onto the appliance is the same for all attachments.
- 2** Select the desired speed to switch on the appliance (Fig. 7).

Preferably use speed II. Switch to speed I for areas with little hair growth, for hard-to-reach areas and for areas where bones are located directly beneath the skin, such as knees and ankles.

3 Stretch the skin with your free hand to make the hairs stand upright.

4 Place the epilator perpendicularly onto the skin with the on/off slide pointing in the direction in which you are going to move the appliance (Fig. 8).

5 Move the appliance slowly over the skin, against the direction of hair growth.

Press the appliance lightly onto the skin.

Epilating the underarms and bikini line

Your epilator comes with a sensitive area cap that reduces the number of active epilating discs. This makes the appliance ideal for epilating the sensitive areas of the body, such as the underarms and bikini line. The first few times you use the appliance, these areas are particularly sensitive to pain, but after repeated use the pain sensation diminishes.

Note: You get the best results in the most comfortable way when the hairs are not too long (approx. 4mm).

1 Thoroughly clean the area to be epilated to remove any residues of deodorant, cream etc. Then dab the area dry.

2 Put the sensitive area cap on the epilating head (Fig. 9).

3 Switch on the appliance.

Preferably use speed II. Switch to speed I for areas with little hair growth and for hard-to-reach areas.

4 Stretch the skin with your free hand. When epilating the underarms, raise your arm to stretch the skin.

5 Place the appliance perpendicularly onto your skin, with the on/off slide pointing in the direction in which you are going to move the appliance.

6 Move the appliance slowly over the skin, against the direction of the hair growth.

- Epilate your bikini line as shown in the figure (Fig. 10).
- Epilate your underarms as shown in the figure. Move the appliance in different directions (Fig. 11).

Cleaning and maintenance

Note: Make sure the appliance is switched off and unplugged before you start to clean it.

Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.

- Never rinse the appliance or the adapter under the tap (Fig. 12).
- Keep the appliance and the adapter dry (Fig. 13).

Cleaning the attachments

1 Remove any attachment (double wavy massage attachment or sensitive area cap) from the epilating head (Fig. 14).

2 Remove loose hairs from the attachment with the cleaning brush.

3 Rinse the attachment under the tap while turning it.

4 Dry the attachment before you use or store it.

Cleaning the epilating head

1 Push the epilating head in the direction of the arrows on the back of the appliance (1) and remove it (2) (Fig. 15).

2 Remove loose hairs with the cleaning brush (Fig. 16).

3 Rinse the epilating head under the tap for 5–10 seconds while turning it (Fig. 17).

4 Shake the epilating head firmly (Fig. 18).

Dry the epilating head thoroughly with a tea towel.

Note: Make sure the epilating head is completely dry before you place it back onto the appliance.

Replacement

All parts of the appliance can be replaced. If you need to replace one or more of the following parts, go to your Philips dealer or an authorised Philips service centre:

- appliance itself
- epilating head
- sensitive area cap
- double wavy massage attachment
- cleaning brush
- adapter

Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 19).

Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

Problem	Cause	Solution
Poor epilating results.	You move the appliance in the wrong direction.	Move the appliance against the direction of hair growth, with the on/off slide pointing in the direction in which you move the appliance.
	You place the epilating head on the skin at the wrong angle.	Make sure that you place the appliance on the skin at an angle of 90° (see chapter 'Using the appliance').
	You used a (depilatory) cream prior to epilation.	Make sure your skin is clean, entirely dry and free from grease. Do not use any cream before you start epilating.
	The hairs are too short.	Sometimes hairs are too short to be caught. The optimal length for easy removal of the hairs is 3-4mm. The hairs that are not caught during this session will be long enough to be removed when you epilate the next time. You can also try to catch the hairs by moving the appliance across the skin a few more times.
	The sensitive area cap is on the epilating head when you epilate your legs.	Do not use the sensitive area cap when you epilate your legs, as the cap reduces the number of active epilating discs. NB: Never use the epilator without the sensitive area cap when you epilate your underarms or bikini line.
The appliance does not work.	The socket to which the appliance is connected is not live.	Make sure the socket is live. If you have connected the epilator to the socket in a bathroom cabinet, you may need to switch on the bathroom light to activate the socket.

Problem	Cause	Solution
I cannot remove the epilating head from the appliance.	You try to pull it straight off.	Push the epilating head in the direction of the arrows on the back of the appliance before you pull it off the appliance (see chapter 'Cleaning and maintenance').

제모 헤드의 물을 수건으로 완전히 닦아내십시오.

참고: 제품에 다시 끼우기 전에 제모 헤드가 완전히 말라 있어야 합니다.

교체

제품의 모든 부품은 교체가 가능합니다. 다음 부품을 교체하려면 필립스 대리점 또는 필립스 지정 서비스 센터로 문의하십시오

- 제품 전체
- 제모 헤드
- 민감 부위용 캡
- 이중 웨이브 마사지 액세서리
- 청소용 브러시
- 어댑터

환경

- 수명이 다 된 제품은 일반 가정용 쓰레기와 함께 버리지 마시고 지정된 재활용 수거 장소에 버리십시오. 이런 방법으로 환경 보호에 동참하실 수 있습니다 (그림 19).

품질 보증 및 서비스

보다 자세한 정보가 필요하시거나, 사용상의 문제가 있을 경우에는 필립스전자 홈페이지 (www.philips.co.kr)를 방문하시거나 필립스 고객 상담실로 문의하십시오. 전국 서비스센터 안내는 제품 보증서를 참조하십시오. *(주)필립스전자: (02)709-1200 *고객 상담실: (080)600-6600(수신자부담)

문제 해결

이 란은 제품을 사용하면서 가장 일반적으로 경험하게 되는 문제와 그 해결 방법을 제시합니다. 발생한 문제를 아래 정보로 해결할 수 없는 경우에는 필립스 고객 상담실로 문의하십시오.

문제점	원인	해결책
제모가 잘 되지 않습니다.	제모기를 움직이는 방향이 잘못되었습니다.	전원 스위치가 제품을 움직이려는 방향으로 향하게 하고, 체모가 자라는 반대 방향으로 제모기를 움직이십시오.
제모 헤드와 피부가 이루는 각도가 잘못되었습니다.	제모기가 피부와 수직(90°)이 되게 세워졌는지 확인하십시오(‘제품 사용’ 란 참조).	
제모하기 전에 (제모) 크림을 발랐습니다.		피부가 깨끗하고 물기나 유분이 없어야 합니다. 크림을 바르지 말고 체모를 제거하십시오.
체모가 너무 짙습니다.		체모가 너무 짙으면 체모가 되지 않을 수 있습니다. 제모하기 가장 좋은 길이는 3-4mm입니다. 아직 제거하기 어려운 체모는 좀 더 기다린 후 충분히 자라면 제모하십시오. 또는 제품을 피부에서 여러 번 움직여도 짙은 체모를 제거할 수 있습니다.

문제점	원인	해결책
제품이 작동하지 않습니다.	제품을 연결한 콘센트에 이상이 있습니다.	콘센트가 작동하는지 확인하십시오. 옥실 내 콘센트에 제모기를 연결한 경우 콘센트가 작동하려면 옥실 전등을 켜야 할 수 있습니다.

제품에서 제모 헤드가 분리되지 않습니다.	제모 헤드를 바로 잡아당겼기 때문입니다.	제품에서 제모 헤드를 잡아당기기 전에 제품 뒷면에서 화살표 방향으로 제모 헤드를 누르십시오(‘청소 및 유지관리’ 참조).
------------------------	------------------------	---

ปัญหา	สาเหตุ	การแก้ไขปัญหา
เครื่องไม่ทำงาน	เดาเสียงปลักไฟเสีย	หากต้องการกำกั้นบวมเรวนขา ไม่ควรใช้ไฟครับสำหรับ บริเวณที่บวมมาก เช่นขา หรือขาที่ทำงานมากจัดหนัก ควรจะห้ามให้ล้างความผิด ลักษณะน้ำยัง หมายเหตุ: ห้ามใช้เจลหรือเจลชนิดน้ำ บริเวณที่บวมเช่นบริเวณแนว ขอบบิกนี่ตาก ไม่ได้ประกอบ หากครอบคลุมบวมผิวที่ ขอบบางลงบนตัวใหญ่
ผู้ป่วยไม่สามารถเดินได้	ให้คุณลองถีบหัว ก่อน ออกตรวจ	ควรดูดไขมันในเส้นเลือดที่มีภาระ ไฟฟ้าอยู่ หากคุณทำการเขื่อม ต่อศรีษะแล้วขึ้นด้วยตัวเอง รับในห้องน้ำ คุณอาจต้องปิด ไฟห้องน้ำเพื่อให้กระแสไฟ เข้าสู่รับเสื้อก่อน

ผู้ป่วยไม่สามารถเดินได้
ตัวใหญ่ของขาตัวเดียว

問題	原因	解決方法
毛髮過短。	毛髮過短的話，是無法刮除的。輕鬆除毛的理想毛髮長度是 3-4 公釐。現階段無法刮除的毛髮，下次除毛時就長得夠長了。您也可以將本產品在皮膚上多移動幾次，盡量刮除毛髮。	
進行腿部除毛時，敏感部位保護蓋位於拔毛刀頭上。	進行腿部除毛時，請勿使用敏感部位保護蓋，因為保護蓋將減少作用中的除毛夾輪數量。注意：進行腋下及比基尼線的除毛時，一定要將精密保護蓋裝入得體刀。	
本產品無法運作。	連接除毛刀的插座沒有電。	請確認插座有電。若您已將得體刀連接到浴室櫥櫃的插座，您可能需要打開浴室電源才能開啟插座電源。
我無法從產品上拆下拔毛刀頭。	請將它直接拔出。	將拔毛刀頭往產品背面箭頭的方向推，再從本產品上拔出(請參閱「清潔與維護」單元)。

问题	原因	解决方法
毛发过短。	有时，毛发过短不易脱毛。处于3-4毫米的最佳长度时，脱毛过程会很轻松。本次脱毛过程中未脱除的毛发，将在下次脱毛时生长到适合脱毛的长度。您也可以尝试将产品在皮肤上多移动几个回合，脱去很短的毛发。	
为腿部脱毛时，在脱毛刀头上安装了敏感区域保护盖。	脱去腿部毛发时不应使用敏感区域保护盖，因为它会减少转动脱毛夹轮的数量。注意：在为腋下或比基尼线部位脱毛时，切勿在未安装敏感区域保护盖的情况下使用该脱毛器。	
产品不能工作。	产品所接的插座没通电。	确保插座已通电。如果连接脱毛器的插座是浴室的插座，则可能需要打开电灯才能使插座通电。
无法从产品上卸下脱毛刀头。	您尝试将其直接拉出。	将脱毛刀头从产品中拉出之前，应先按照产品背面的箭头方向推动脱毛刀头（见“清洁和保养”一章）。