




© 2010 Koninklijke Philips Electronics N.V.  
All rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

Printed in China  
DC220\_93\_QSG\_V1.0



Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)




Clock Radio for iPhone/iPod  
DC220

## Quick start guide

- 1 Connect
- 2 Setup
- 3 Enjoy

## What's in the box




Main unit



AC power  
adaptor



MP3 LINK cable




User Manual  
Quick Start Guide

## 1 Connect

### A Connect power

- 1 Connect one end of the AC adaptor to the DC IN socket on the main unit.
- 2 Connect the other end of the AC adaptor to the wall outlet.



**PHILIPS**

## 2 Setup

### A Set time and date

- 1 Dock the iPod / iPhone on the unit.
- 2 Open the iPod / iPhone.
  - ↳ Time and date information on the iPod / iPhone transfers to the unit automatically.

#### To set time and date manually:

- 1 In standby mode, press and hold **DATE • AUTO TUNE/TIME SET** for 2 seconds.
  - ↳ [24 HR] begins to blink.
- 2 Press **TUNING +/-** or **⏮/⏭** to select 12/24 hour format.
- 3 Press **DATE • AUTO TUNE/TIME SET** to confirm.
  - ↳ The hour digits begin to blink.
- 4 Press **TUNING +/-** or **⏮/⏭** to set the hour.
- 5 Press **DATE • AUTO TUNE/TIME SET** to confirm.

↳ The minute digits begin to blink.

- 6 Repeat steps 4-5 to set the minute, year, month, and day.

### B Set the alarm timer

You can set two alarms which go off at different time.

- 1 Ensure that you have set the clock correctly.
- 2 Press and hold **AL 1** or **AL 2** for 2 seconds.
  - ↳ [AL 1] or [AL 2] begin to blink.
- 3 Press **SOURCE** repeatedly to select an alarm sound source: iPod/iPhone, iPod/iPhone playlist, FM tuner, or buzzer.
- 4 Press **AL 1** or **AL 2**.
  - ↳ Hour digits begin to blink.
- 5 Press **TUNING +/-** or **⏮/⏭** repeatedly to set the hour.

## 2 Setup

- 6 Press **AL 1** or **AL 2** to confirm.
  - ↳ Minute digits begin to blink.

- 7 Repeat steps 5-6 to set the minute.

- 8 Repeat steps 5-6 to select whether to ring alarm the whole week, on weekdays, or at weekend.

- 9 Repeat steps 5-6 to set the alarm volume.

#### Activate and deactivate the alarm timer

- 1 Press **AL 1** or **AL 2** repeatedly to activate or deactivate the timer.
  - ↳ If the timer is activated, [**AL 1**] or [**AL 2**] is displayed.
  - ↳ If the timer is deactivated, **AL** before [AL1] or [AL2] disappears.

#### Repeat alarm

- 1 When the alarm rings, press **BRIGHTNESS/REP ALM**.
  - ↳ The alarm repeats ringing minutes later.

#### \* Tip

- You can press **⏮/⏭** to adjust the interval to repeat alarm.

#### Stop alarm ring

- 1 When the alarm rings, press the corresponding **AL 1** or **AL 2**.
  - ↳ The alarm stops but the alarm settings remain.

## 3 Enjoy

### A Play from iPod/iPhone

- 1 Place the iPod/iPhone into the dock.
- 2 Press **SOURCE** repeatedly to select iPod/iPhone source.
  - ↳ The connected iPod/iPhone plays automatically.
  - To pause/resume play, press **⏮/⏭**.
  - To skip to a track, press **⏮** / **⏭**.
  - To search during play, press and hold **⏮/⏭**, then release to resume normal play.

### B Program radio stations automatically

- 1 In the tuner mode, press and hold **DATE • AUTO TUNE/TIME SET** for more than 2 seconds to activate automatic program mode.
  - ↳ [AUTO] (auto) displays.
  - ↳ All available stations are programmed in the order of waveband reception strength.
  - ↳ The first programmed radio station is broadcast automatically.

#### \* Tip

- Detailed functions and features are described in the user manual.