Clock Radio AJL308

Register your product and get support at www.philips.com/welcome

Quick Start Guide Guide de démarrage rapide Guía de Inicio Rápido Schnellstartanleitung Gids voor een snelle start Guida Rapida Κρατκοε ργκοβοдсτβο Οδηγός ταχείας έναρξης



Thanks for buying **Philips AJL308 clock radio**.

Our **Quick Start** guides you through just some of the features on the set. Please read our instruction booklet to really rise & shine!



English

I. Connecting power

 Connect the supplied mains adapter to the set's 9V DC jack and the plug into a wall outlet.

II. Setting time and date

- 1. Press MENU.
- 2. Use ◀▶ to highlight "Clock".
- Use ▲ ▼ to select a field of "Time Set" and "Date (Year-Month-Day)".
- 4. Press OK to confirm.
- 5. Press or hold down ▲ ▼ to set the values.
- 6. Press **OK** to confirm.
- 7. Repeat Steps 3-6 to set other values of "Time Set and "Date (Year-Month-Day)".
- After finishing the setting, press CLOCK, TUNER, PICTURE or MUSIC to exit the setup menu.

Helpful hint:

In the clock mode, to zoom the picture displayed, press and hold **CLOCK** for around 2 seconds, then press **OK** repeatedly to enlarge picture or resume to normal size, and use ◀▶▲ ▼ to pan the enlarged picture through. To exit the zoom mode, press **CLOCK** again.

Before zoom



After zoom



III. Setting/Activating alarm time

You can set two different alarm times.

- 1. Press CLOCK.
- Hold down ALARM 1 or ALARM 2 for about 2 seconds, then release.
- 3. Press or hold down ▲ ▼ to set hour.
- 4. Press ALARM 1 or ALARM 2 to confirm.
- 5. Press or hold down ▲ ▼ to set minute.
- 6. Press ALARM 1 or ALARM 2 to confirm.
- Press again ALARM 1 or ALARM 2 to activate alarm setting.

IV. Switching off the alarm

OR.

- Press **REPEAT ALARM** / BRIGHTNESS CONTROL' to enable repeat alarm in 9 minutes.
- To switch off alarm completely, press ALARM 1
 or ALARM 2 repeatedly until (((a) is changed
 to A.
 - → When alarm is deactivated, displays. When it is activated, ((displays.

Helpful hint:

- During alarm call, if no button is pressed, alarm call will last 30 minutes.
- To set the alarm sound with specific music, select desired music in the "Alarm Music" of the Clock menu.



V. Tuner

- 1. Press TUNER.
- 2. Press MENU.
 - →The Tuner menu appears.
- 3. Press ▼ to select "Tuner Auto Program".
- **4.** Press **OK** to start the auto search and programming.
 - → 20 available stations are programmed (FM).
- **5.** Press ▲ ▼ once or more to select your desired station.
- In TUNER mode, to turn off radio, press OK.To turn on radio, press OK again.
- To auto tune to a radio station, press and hold press and hold

 ▶ for about 2 seconds, then release. (To store particular station, refer to "Manual programming" of Tuner section in the user manual.)

VI. Using USB device or SD/MMC

To listen to music or view photo, you need to connect a USB device and/or memory card to AIL308.

- Plug a compatible USB device and/or memory card (SD or MMC card) to USB port and/or card slot of AlL308.
 - →The folder(s) indicating the inserted device(s) appears.
- 2. Press ▲ ▼ to select the folder of USB device (if present) or memory card (if present).
- 3. Press **OK** to open the folder.
 - →The set will auto switch to picture mode.
- To switch to music mode, press MUSIC.
- To switch back to picture mode, press PICTURE.
- 4. Select the file you want to play.
- 5. Press OK to play.

Helpful hint:

 You may change still picture display format on the screen by selecting "Widescreen" or "Normal" under "Display Format" option in the "General" menu.

Wide screen



Normal



VII. Setting sleep

- In TUNER or MUSIC mode, press SLEEP until your desired sleep option is displayed.
 - → The current **Tuner** or **Music** playback will continue.

OR.

- In CLOCK or PICTURE mode, press SLEEP until your desired sleep option is displayed.
 - → The built-in relaxation music will start playback.

Helpful hint:

 There are several built-in relaxation music, select your desired one in the "Sleep Timer Music" option of the "General" menu.

VIII. Brightness control

Press REPEAT ALARM / BRIGHTNESS CONTROL repeatedly to cycle screen brightness through 4 levels

IX. Screen auto dim

To avoid strong light emitting from the unit at night time, the auto dim function can be used to adjust the brightness to the lowest level automatically.

- To turn on auto dim, in the General menu, set On in "Auto Dim Timer", then set desired start time in "Auto Dim Start", and set desired end time in "Auto Dim End".
 - → During auto dim time span, press any button to increase screen brightness, and it will last for 10 seconds.

X. Using the stand

The set is equipped with a stand on the bottom panel. To set the unit for a different viewing angle, take the stand out, then place it back by reversing (see the figure below) the side of the stand.

