



© Royal Philips Electronics N.V. 2012
All rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

DC290_12_QSG_V3.0



Register your product and get support at
www.philips.com/welcome


Docking Entertainment System
DC290



Quick start guide

- 1 Connect
- 2 Setup
- 3 Enjoy

What's in the box




Main unit



Remote control



MP3 link cable




User Manual
Quick Start Guide

1 Connect

A Connect power

- 1 Connect the AC power cord to the wall outlet.



PHILIPS

EN

2 Setup

A Set time and date

- 1 In standby mode, press and hold **SET TIME/PROG** for 2 seconds.
↳ Hour digits start to blink.
- 2 Press **OK/▶II** to select the 12/24 hour format.
- 3 Press **◀|▶** to set the hour.
- 4 Press **SET TIME/PROG** to confirm.
↳ The minute digits begin to blink.
- 5 Repeat steps 3-4 to set the minute, year, month, and day.

B Set the alarm timer

You can set two alarms which go off at different time.

- 1 Ensure that you have set the clock correctly.
- 2 Press and hold **ALM 1** or **ALM 2** for 2 seconds.
↳ [AL 1] or [AL 2] begin to blink.

- 3 Press **SOURCE** on the top panel to select an alarm sound source: iPod/iPhone, FM tuner, or buzzer.
- 4 Press **ALM 1** or **ALM 2**.
↳ The hour digits begin to blink.
- 5 Press **◀|▶** repeatedly to set the hour.
- 6 Press **ALM 1** or **ALM 2** to confirm.
↳ The minute digits begin to blink.
- 7 Repeat steps 5-6 to set the minute.
- 8 Repeat steps 5-6 to select whether to ring alarm the whole week, on weekdays, or at weekend.
- 9 Repeat steps 5-6 to set the alarm volume.

* Tip

- If you set iPod/iPod playlist as the sound source, you must create a playlist in iTunes called "PHILIPS" and import it to your iPod/iPod.
- If no playlist is created in the iPod/iPhone or there is no song in the playlist, the unit will wake to songs in the iPod/iPhone.

2 Setup

Activate and deactivate the alarm timer

- 1 Press **ALM 1** or **ALM 2** repeatedly to activate or deactivate the timer.
↳ If the timer is activated, [AL 1] or [AL 2] is displayed.
↳ If the timer is deactivated, [AL 1] or [AL 2] disappears.

Repeat alarm

- 1 When the alarm rings, press **BRIGHTNESS/REP ALM**.
↳ The alarm repeats ringing minutes later.

* Tip

- ↳ You can press **◀|▶** to adjust the interval to repeat alarm.


Stop alarm ring

- 1 When the alarm rings, press the corresponding **ALM 1** or **ALM 2**.
↳ The alarm stops but the alarm settings remain.


3 Enjoy

A Play from iPod/iPhone

- 1 Lift up the iPod/iPhone dock on the top panel.



- 2 Place the iPod/iPhone into the dock.



3 Enjoy

- 3 Press **iPhone/iPod** to select iPod/iPhone source.

↳ The connected iPod/iPhone plays automatically.

- To pause/resume play, press **OK/▶II**.
- To skip to a track, press **◀|▶**.
- To search during play, press and hold **◀|▶**, then release to resume normal play.
- To go back to the previous iPod/iPhone menu, press **MENU**. To scroll through the menu, press **◀|▶**.
- To confirm a selection, press **OK/▶II**.
↳ If no key is pressed for more than 10 seconds, **OK/▶II** acts back as the play/pause key.

B Program and listen to radio stations

- 1 In the tuner mode, press and hold **SET TIME/PROG** for more than 2 seconds to activate automatic program mode.
↳ [AUTO] (auto) is displayed.
↳ All available stations are programmed in the order of waveband reception strength.
↳ The first programmed radio station is broadcast automatically.
- 2 Press **◀|▶** to select a preset number.

* Tip

- Detailed functions and features are described in the user manual.