



Register your product and get support at
www.philips.com/welcome

Docking Entertainment System
DC220




Quick start guide

- 1 Connect
- 2 Setup
- 3 Enjoy


PHILIPS

EN

What's in the box




Main unit



AC power
adaptor



MP3 LINK cable




User Manual
Quick Start Guide

1 Connect

A Connect power

- 1 Connect the AC power cord and the AC adaptor.
- 1 Connect the AC adaptor to the **DC IN** socket on the main unit.
- 2 Connect the power plug of the AC power cord to the wall outlet.



2 Setup

A Set time and date

- 1 Dock the iPod/iPhone on the unit.
- 2 Open the iPod/iPhone.
 - ↳ Time and date information on the iPod/iPhone transfers to the unit automatically.

To set time and date manually:

- 1 In standby mode, press and hold **DATE • AUTO TUNE/TIME SET** for 2 seconds.
 - ↳ [24HR] begins to blink.
- 2 Press **TUNING +/-** or **⏮/⏭** to select 12/24 hour format.
- 3 Press **DATE • AUTO TUNE/TIME SET** to confirm.
 - ↳ The hour digits begin to blink.
- 4 Press **TUNING +/-** or **⏮/⏭** to set the hour.
- 5 Press **DATE • AUTO TUNE/TIME SET** to confirm.
 - ↳ The minute digits begin to blink.

- 6 Repeat steps 4-5 to set the minute, year, month, and day.

B Set the alarm timer

You can set two alarms which go off at different time.

- 1 Ensure that you have set the clock correctly.
- 2 Press and hold **AL 1** or **AL 2** for 2 seconds.
 - ↳ [AL1] or [AL2] begin to blink.
- 3 Press **SOURCE** repeatedly to select an alarm sound source: iPod/iPhone, iPod/iPhone playlist, FM tuner, or buzzer.
- 4 Press **AL 1** or **AL 2**.
 - ↳ Hour digits begin to blink.
- 5 Press **TUNING +/-** or **⏮/⏭** repeatedly to set the hour.

2 Setup

- 6 Press **AL 1** or **AL 2** to confirm.
 - ↳ Minute digits begin to blink
- 7 Repeat steps 5-6 to set the minute.
- 8 Repeat steps 5-6 to select whether to ring alarm the whole week, on weekdays, or at weekend.
- 9 Repeat steps 5-6 to set the alarm volume.

Activate and deactivate the alarm timer

- 1 Press **AL 1** or **AL 2** repeatedly.
 - ↳ If the timer is activated, [**AL1**] or [**AL2**] is displayed.
 - ↳ If the timer is deactivated, **⏸** before [AL1] or [AL2] disappears.

Repeat alarm

- 1 When the alarm rings, press **BRIGHTNESS/REP ALM**.
 - ↳ The alarm repeats ringing minutes later.

* Tip

- You can press **⏮/⏭** to adjust the interval to repeat alarm.

Stop alarm ring

- 1 When the alarm rings, press the corresponding **AL 1** or **AL 2**.
 - ↳ The alarm stops but the alarm settings remain.

3 Enjoy

A Play from iPod/iPhone

- 1 Place the iPod/iPhone into the dock.
- 2 Press **SOURCE** repeatedly to select iPod/iPhone source.
 - ↳ The connected iPod/iPhone plays automatically.
 - To pause/resume play, press **⏮/⏭**.
 - To skip to a track, press **⏮/⏭**.
 - To search during play, press and hold **⏮/⏭**, then release to resume normal play.

B Program radio stations automatically

- 1 In the tuner mode, press and hold **DATE • AUTO TUNE/TIME SET** for more than 2 seconds to activate automatic program mode.
 - ↳ [AUTO] (auto) is displayed.
 - ↳ All available stations are programmed in the order of waveband reception strength.
 - ↳ The first programmed radio station is broadcast automatically.