

Register your product and get support at
www.philips.com/welcome

SE6580



Quick start guide

- 1 Connect
- 2 Install
- 3 Enjoy

PHILIPS

What's in the box



Handset with belt clip




Charger



Battery door



2 AAA rechargeable
batteries



Power supply



User manual



Guarantee



Do Not Return leaflet



Quick Start Guide


WARNING: Always use the power supply and batteries that came with your phone.

1

Connect

Connect the charger

1. Place the charger near a power outlet.



2. Connect the power cable to the connector on the charger.
3. Connect the other end of the power cable to the power outlet.


2

Install

1. Insert rechargeable batteries and charge.

A

Insert batteries



B

Charge handset for 24 hours



2. Register the handset.

You must register your handset to the base station before you can use it. **Place Handset on Base unit** is displayed on the handset screen. The PIN is required before you can register or unregister handsets. By default, the PIN is 0000.

Easy registration

This type of registration is available when you wish to register your SE6580 on a SE650, SE655 or SE658 base station. For any other Philips base station, please refer to “Manual Registration” below. Moreover, the PIN code of the base station has to be the default one, that is 0000. If you have already changed it, please refer to base station user guide to reset it to default 0000 or refer to Manual Registration below.







1. Insert the unregistered handset into the base station to automatically begin registration.
2. **Registering...** is displayed on the screen.
 - Upon successful registration, a validation tone is emitted on the base (except for SE650) then on the handset, and the handset number (1 to 8) will be assigned by the base automatically.
 - If the easy registration fails, please refer to “Manual Registration” below.

Manual registration

1. Power on the handset.
2. On the base station, press and hold handset locator (●) for 3 seconds. A beep sounds to indicate that the base station is ready to accept registration. (No beep sounds on the SE650.)

Note

If no action is taken on the handset within 90 seconds, the registration procedure will be aborted. If this happens, repeat from Step 1.

3. On the handset, press , scroll  to **Advanced Set** and press  **Select**.
4. Scroll  to **Register** and press  **Select**.
5. Enter the PIN when prompted and press  **OK** to confirm.

Registering... is displayed on the screen.

- Upon successful registration, a validation tone is emitted and the handset number (1 to 8) is assigned by the base station automatically.

Note

This procedure is valid for Philips base stations. For other brands of base stations, please refer to base station user guide.



3

Enjoy



Make a call

Dial the number (maximum 24 digits) and press  or .


OR

Press  or  to take the line, and dial the number.


Answer a call

When the phone rings, press  or .

End a call










To end a conversation, press .

Adjust earpiece or speaker volume

During a call, scroll  to select from **level 1** to **level 5**.

Set the ring tone

There are 15 ring tones available on your handset.


1. Press , scroll  to **Personal Set**, and press  **Select**.
2. Scroll  to **Handset Tones** and press  **Select**, then scroll  to **Ring Tones** and press  **Select**.
3. Scroll  to your desired melody. The melodies will play as you scroll to them.
4. Press  **Select** to set the ring tone.

A validation tone is emitted and the screen returns to the previous menu.

Troubleshooting

For more information, please refer to the User Manual that came with your phone.

Problem

- There's no dialling tone!
- Caller does not hear me clearly!
- **Searching...** is displayed on handset and  icon is blinking!
- Caller number is not displayed!

Solution

- No power: Check the connections.
- Batteries are empty: Charge the batteries.
- Move closer to the base station.
- Wrong line cord used: Use the line cord provided.
- Move closer to the base station.
- Move the base station at least one metre (yard) away from any electronic appliances.
- Move closer to the base station.
- Make sure that your base station is on.
- Reset your unit and restart handset registration.
- Service is not activated: Check your subscription with your network operator.

Welcome to Philips!

Register your product and get support at
www.philips.com/welcome

Need help?

User Manual

Refer to the User Manual that came with your phone.

Online Help

www.philips.com/support

©2008 Koninklijke Philips Electronics N.V.

All rights reserved

Reproduction in whole or in part is prohibited without the written consent of the copyright owner



Please Recycle
Printed in China

3111 285 49901 (US-EN)
UUZZ10693ZZ(0)